

**IB-11B022**

**MACROPRO II™ FOR WINDOWS™**

**DECEMBER 1998**

# **MACROPRO II™**

**FOR WINDOWS™**

## **INSTRUCTION BOOK**

**INDUSTRIAL INDEXING SYSTEMS, Inc.**

**Revision - B**  
Approved By:

Proprietary information of Industrial Indexing Systems, Inc. furnished for customer use only.  
No other uses are authorized without the prior written permission of  
**Industrial Indexing Systems, Inc.**

## TABLE OF CONTENTS

<b>Introduction</b>	<b>Section 1</b>
<b>Programming Language Concepts</b>	<b>Section 2</b>
<b>Control and Motion Concepts</b>	<b>Section 3</b>
<b>DeltaMax DeviceNet</b>	<b>Section 4</b>
<b>Analyzer</b>	<b>Section 5</b>
<b>Instruction Reference &amp; Examples</b>	<b>Section 6</b>
<b>Glossary</b>	<b>Section 7</b>
<b>Appendix</b>	<b>Section 8</b>

# MACROPRO II<sup>TM</sup>

FOR WINDOWS<sup>TM</sup>

Section 1 - Introduction



INDUSTRIAL INDEXING SYSTEMS, INC.

**SECTION 1 - INTRODUCTION****Table of Contents**

<i>Introduction</i>	3
<b>Overview</b>	3
<b>Highlights</b>	4
<b>Manual Conventions</b>	5
<i>Getting Started</i>	6
<b>System Requirements</b>	6
<b>Installing MacroPro II</b>	6
<b>Release Information</b>	7
<b>Application Development</b>	7
<b>Selecting a function using the IDE</b>	7
<b>Creating a Motion Control Program</b>	7
<b>Compiling Your Program</b>	8
<b>Testing Your Program</b>	8
<b>Running Your Program</b>	8

*This page is intentionally left blank.*

## Introduction

This document is one in a series of technical documents supporting Industrial Indexing Systems DeltaMax Servo Controller. This particular document provides information about the MacroPro II Development System for Windows™, which serves as a tool to assist the user in the development of motion control programs.

## Overview

The MacroPro II Development System is intended to be used with the DeltaMax programmable motion controllers.

The MacroPro II Development System runs under the Microsoft Windows™ environment, providing users a very powerful, flexible and intuitive software approach to program generation and testing.

This manual was written with the assumption that you are somewhat familiar with Personal Computers, MS-DOS and the Microsoft Windows environment.

## Highlights

1. The Integrated Development Environment (IDE) provides access to the major MacroPro II features.
2. The MacroPro II Help System allows:
  - a. Access to on-line documentation whenever needed.
  - b. Search for topic on keyword, history, next/previous.
  - c. The ability to cut and paste examples or documentation into your program.
3. The MacroPro II Editor offers:
  - a. A multi-window, multi-file editing environment.
  - b. Access to the MacroPro II Compiler while editing your program.
  - c. Access to the MacroPro II Analyzer.
  - d. Automatic syntax verification of your program lines.
  - e. Unique color combinations for instructions, comments and errors.
  - f. Standard Windows based file management features.
  - g. On-line documentation.
4. The MacroPro II Compiler provides:
  - a. Program compiler errors that are clear and concise.
  - b. Compiler errors are easily identified and can be located within your program by "double clicking" on the error description.
  - c. The ability to abort compiling and the ability to resume compiling.
5. The MacroPro II Analyzer provides a real time test and analysis facility, including:
  - a. Controller and application program status.
  - b. View and change DeltaMax System User Parameters.
  - c. Program trace features.
  - d. The ability to select data variables and flags from a sorted list.
  - e. The ability to monitor data variables only, flags only or mixed data and flags.

- f. Simultaneous reading and writing of data variables and flags.
- g. Axis controller status flags can be monitored in real time.
- h. A controller information screen provides information on the hardware/firmware in use.
- i. The ability to view your source and symbol files.

## Manual Conventions

Throughout this manual, the following typeface conventions are used:

1. Program instruction names appear in **bold** print.
2. Optional instruction labels appear in *italics*.

### Example 1

The following program line defines a timer (called MONITOR) with a time of 100.

```
wait_1_sec           set_tmr           MONITOR,100
```

The label *wait\_1\_sec* is an optional label. Although it may be needed because the user intends for the program to branch to that label during program execution, it is not required for the instruction **set\_tmr** to be valid.

### Example 2

The first line of the following group of program instructions, is an example of an instruction which requires an instruction label.

```
speed_table           begin_data  
                     data           100,150,200,600,1200  
                     end_data
```

The label **speed\_table** is a required label. This label identifies a place in the program data area, where an array of data can be retrieved. Without the label, we have no way of accessing the data.

## Getting Started

The first step to developing and testing your programs is to install the MacroPro II Development System on your computer. While this is a relatively simple task, it is important to understand the recommended and minimum hardware configuration of your Personal Computer. Once your software has been successfully installed, take a few minutes to read the section which follows regarding the program development cycle. This should give you some insight into the major components of the MacroPro II Development System and how the pieces fit together.

## System Requirements

### System

A 386 class machine is required minimally. A 75MHz Pentium class machine with at least 16MB of RAM is recommended. Performance will also vary depending on the video adapter, driver and video mode you have selected.

### Memory

MacroPro II requires 4MB of memory to operate. Additional memory may be required depending on the size of the programs being developed.

### Disk Space

When fully installed, MacroPro II uses approximately 5MB of disk space. Additional disk space may be required depending on your application(s).

### Windows

You must be running Microsoft Windows Version 3.1 or greater in enhanced mode or Microsoft Windows 95.

## Installing MacroPro II

Like many Windows based applications, a program called SETUP.EXE resides on the MacroPro II Installation Disk and will guide you through the installation process. Basically, you will do the following steps:

### *Microsoft Windows Version 3.1 or greater*

1. Begin Windows by typing win at the MS-DOS prompt and pressing the Enter key. You should be running Windows version 3.1 or greater.
2. Insert the disk labeled Disk 1 in your floppy disk drive.
3. Choose the Run command from the File menu in Windows Program Manager. Type a:setup and press the Enter key (or b:setup if using the drive b:).
4. Follow the instructions on the screen and provide the appropriate responses to the installation options as needed.

### *Microsoft Windows 95*

1. Begin Windows and make sure the user can see the Windows Desktop. Select the START button and click RUN on the START menu.
2. Insert the disk labeled Disk 1 in your floppy disk drive.
3. Type **a:setup** and press the Enter key (or **b:setup** if using the drive b:).
4. Follow the instructions on the screen and provide the appropriate responses to the installation options as needed.

Once the installation process is complete, you should be able to run the MacroPro II Development System by selecting the corresponding icon or running from the Program Manager.

## Release Information

<u>MacroPro II Release</u>	<u>Firmware Number</u>
v1.X	SFO-3901
v2.X	SFO-3902
v3.X	SFO-3903

## Application Development

The MacroPro II Development System provides you with the necessary tools for creating, compiling and testing your motion control programs. A description of the major components of the MacroPro II Development System follows.

### Selecting a function using the IDE

The MacroPro II IDE (Integrated Development Environment) provides easy access to the MacroPro II Editor, Analyzer and Help System. Selections are made by pressing the desired button on the IDE screen. Selecting the Exit button will close down the MacroPro II Development System.

### Creating a Motion Control Program

Application programs are created and/or changed using the MacroPro II Editor. The Editor has a wealth of features that will help streamline the editing of your application programs. The actual text that you enter is often referred to as the **source** file.

## Compiling Your Program

The program **source** file will need to be compiled before it can be run on your DeltaMax Controller. The process of compiling must be initiated by you, although the actual process of compiling is transparent to you.

The Compiler is initiated from the Editor. By pressing the Compile button from the Toolbox, the compile process will begin. The **source** file currently being edited, will be saved. Then, the Compiler checks for syntax errors in your **source** file and builds other files that will be required to run your program.

Typically, the Compiler will build a **symbol** file and an **error** file. These files are built regardless of whether an error was or was not encountered. An optional **listing** file might also be created.

A **trace** file and **executable** file will also be created **if no compile errors were discovered**. The Compiler will always indicate whether a compile was successful, unsuccessful or was aborted by the programmer.

Since the **executable** file will only be created if there were no Compiler errors, it follows that only compiled programs without errors can be run on the DeltaMax Controller.

## Testing Your Program

Application programs are tested using the MacroPro II Analyzer. The Analyzer is used to transmit, start, stop and autostart your application program at the DeltaMax. The Analyzer also provides the tools to watch program variables, trace program execution and monitor the status of the DeltaMax Controller and related axes, I/O and other events.

If the Analyzer is selected from the Editor, the currently selected file will be used **provided that file has been successfully compiled and is error free**. Other application programs to be run can be selected while in the Analyzer assuming that they are error free.

While in the Analyzer, you will have easy access to all program **source** and **symbol** file information which will prove useful as your program is being tested.

## Running Your Program

Once your program has been successfully tested, you are ready to setup your DeltaMax Controller so that the program will run automatically on system power-up. There is one way to do this.

Through the Analyzer select the "Actions" topic, then select "Run w/ AutoStart". Your application program will run automatically each time power to the DeltaMax Controller is enabled.

# MACROPRO II<sup>TM</sup>

FOR WINDOWS<sup>TM</sup>

Section 2 - Programming  
Language Concepts



INDUSTRIAL INDEXING SYSTEMS, INC.

---

**SECTION 2 - PROGRAMMING LANGUAGE CONCEPTS****Table of Contents**

<i>Programming Language Concepts</i>	3
<b>Program Statement Format</b>	3
<b>Comments</b>	4
<b>Blank Lines</b>	4
<b>Label Lines</b>	5
<i>Program Compiler</i>	6
<b>Configuring the Compiler</b>	6
<b>The MPRO2.INI File</b>	6
<b>Compile Time Problems</b>	7
<b>Aborting the Compiler</b>	7
<b>Compiling is Complete</b>	8
<b>Compiler Output</b>	8
<i>Compiler Directives</i>	9

*This page is intentionally left blank.*

## Programming Language Concepts

A program is an organized group of statements that can be executed by a DeltaMax Controller. Application programs reside in a section of non-volatile memory in the controller.


Memory allocation is as follows:

Program Area:	64,000 bytes
Integer Data Area + Float Data Area:	16,000 bytes
Integer Constants Area + Float Constants Area:	16,000 bytes
Extended Memory - Motor Axis:	27,000 bytes
Extended Memory - Pseudo Axis:	27,000 bytes

## Program Statement Format

Program *statements* are, in many ways, similar to the statements of the BASIC computer language. Each statement may consist of up to 4 parts; a *label*, an *instruction*, a list of *parameters*, and an optional *comment*. This format is illustrated in Figure 2.1.

1. *label* - A label can be from one (1) to twelve (12) characters in length, and may consist of both upper and lower case letters, numbers and the underscore character. Labels must begin in column 1 of the program line. Labels are optional. If no label is used, at least one blank must be at the beginning of the line.
2. *instruction* - This part of the line consists of any valid MacroPro II Programming Language command. Instructions must be typed in lower case letters. At least one blank must precede the instruction and at least one blank must follow the instruction.
3. *parameters* - This part of the program line consists of the information, if any, processed by the instruction. It must be separated from the instruction by one or more spaces.
4. *comment* - This field can contain any explanatory information about the program line. It must be separated from the preceding field by at least two spaces. Program lines which contain only comments must have an exclamation point (!) in column 1.



**Figure 2.1 - Program Instruction Format**

The label portion of the statement is not always required, depending on the type of instruction used. It is required for instructions which define variables, text strings, arrays, or equated values.

There are instructions which do not require a list of parameters. However, there are usually one or more parameters for an instruction. In the example in Figure 2.2, two parameters are required.

<i>label</i>	<b>set_speed</b>	axis_1,300	<i>comment</i>
--------------	------------------	------------	----------------

**Figure 2.2 - Instruction With Two Parameters**

## Comments

Comments provide a means for a programmer to describe the functions being performed by a particular instruction or group of instructions. It is important to note that comments do not use any of the storage within the program memory space. The liberal use of comments is highly recommended. There are two ways to implement comments in a program:

1. An entire line of text can be dedicated as a comment line by placing an exclamation point (!) in the first character position of the line.
2. Comments can be placed at the end of an instruction line by leaving at least two spaces between the last parameter in the instruction and the beginning of the comment.

Comments of both formats are included in the sample program shown in Figure 2.3.

## Blank Lines

Blank lines may be entered in the program to make it easier to read. For example, a subroutine might be separated from the main body of the program by one or more blank lines. As with comments, blank lines do not use any storage within the program.

## Label Lines

Program lines containing only a label are allowed. It is often handy to place a line containing only a label just ahead of an instruction it references. In this way, it is easier to insert new instructions in the program if necessary during the testing process. Lines containing only a label use no storage within the program.

<u>LABEL</u>	<u>OPERATION</u>	<u>PARAMETERS</u>	<u>COMMENT</u>
	<b>declare</b>	ON	
POS_1	<b>equ</b>	81920	two turns CW
POS_2	<b>equ</b>	-81920	two turns CCW
LIFT	<b>equ</b>	1	use axis 1
LIFT_DOWN	<b>equ</b>	93	down flag
LIFT_BUSY	<b>equ</b>	94	busy flag
NO_FAULT	<b>equ</b>	0	I/O zero
! do initialization functions			
	<b>turn_on</b>	NO_FAULT	show no fault
	<b>drive_on</b>	LIFT	enable drive
	<b>set_speed</b>	LIFT,50	500 rpm speed
	<b>set_ac_dc</b>	LIFT,20	rev/sec/sec
! set a local zero at current position			
	<b>set_local</b>	LIFT	
! begin main program loop			
<i>restart</i>			
<i>loop1</i>	<b>position</b>	LIFT,POS_1	go 2 turns CW
	<b>if_stat_on</b>	LIFT_DOWN,fault	check error
	<b>if_stat_on</b>	LIFT_BUSY,loop1	wait for done
<i>loop2</i>	<b>position</b>	LIFT,POS_2	go 2 turns CCW
	<b>if_stat_on</b>	LIFT_DOWN,fault	check error
	<b>if_stat_on</b>	LIFT_BUSY,loop2	wait for done
	<b>goto</b>	restart	do it all again
<i>fault</i>	<b>turn_off</b>	NO_FAULT	signal error
	<b>sys_return</b>		

Figure 2.3 - Sample Application Program

## Program Compiler

The MacroPro II Compiler converts DeltaMax application programs from human readable instructions (**source files**) to numeric codes (**executable files**) which can be interpreted and acted upon by the DeltaMax Controller.

In addition, the Compiler produces information which is used by the MacroPro II Editor and MacroPro II Analyzer to simplify the programming and testing processes. The user can specify that an optional listing file be created when desired.

The Compiler is invoked by the user from the MacroPro II Editor, by pressing the Compile button.

## Configuring the Compiler

The user may request that a **listing** file be created during the compile process. This is typically a rather large file containing a considerable amount of detail regarding the compiled file. This information is of little importance to most users. It is, however, available to those users with a need to know.

A **listing** file will be created, if the "List file=ON" string is read from the "[Compiler]" section of the file MPRO2.INI. This file will be found in your WINDOWS directory.

A **listing** file will not be created if the "List file=OFF" string is read from the "[Compiler]" section of the file MPRO2.INI.

By default, a **listing** file will not be created.

## The MPRO2.INI File

The Compiler will attempt to read the MPRO2.INI file from the WINDOWS directory at the start of the compile process. This file should minimally contain lines similar to those listed below.

The following lines indicate the directory containing the file MPRO2.OPC.

```
[Environment]
Exec dir=c:\directory
```

The following lines indicate the path and name of the last file used.

```
[Last File]
Last file=c:\prokdir\name.prg
```

The following lines indicate whether a listing file should be produced at compile time.

```
[Compiler]  
List file=ON
```

## Compile Time Problems

Initiating the Compiler is a very simple task. However, there are a number of conditions which might cause the Compiler to abort. The Compiler will attempt to read the MPRO2.INI file from the WINDOWS directory at the start of the compile process. The process will be aborted, with an error message, for any of the following reasons:

1. The MPRO2.INI file was not found in the WINDOWS directory.
2. The "[Environment]" section was not found.
3. The "Exec dir=" string was not found within the "[Environment]" section.
4. The MPRO2.OPC file was not found in the directory listed in the "[Environment]" section.
5. The path and filename passed to the Compiler is illegal or does not exist.

Should you encounter any of these problems, verify that your MPRO2.INI file is located in the proper directory and has the correct syntax as described above.

## Aborting the Compiler

Once the compile process has begun, you may abort that process if necessary. A dialog box will be displayed, indicating the current pass of the Compiler and the percent complete for that pass (the Compiler is a four pass process, where passes 2 and 4 do most of the work). An ABORT button will also be shown.

Press this button to abort the compile process at any time. The Compiler will display a message box, requesting that you confirm whether to abort or not. Press the YES button to confirm the abort or NO to resume compiling. The Compiler will pick up where it left off, if you decide to resume.

## Compiling is Complete

When the compile process is complete, a message box will be displayed indicating that the compile was successful or not successful.

If successful, the Program Size (in bytes) and the Data Size (in bytes) will be displayed.

If unsuccessful, a message will be displayed indicating the number of errors detected.

In either case, you must press the OK button in the message box in order to continue.

## Compiler Output

The MacroPro II Compiler will generate the following files:

1. The **listing file** is an optional file. It will be created if specified in the MPRO2.INI file. The listing file has the program file extension **.lst**. It will be created even if program errors were detected.

The **listing file** consists of:

- a. An EQUATE Table - This table lists all symbols defined in **equ** statements. Its contents are symbol name, decimal symbol value, and hexadecimal symbol value.
  - b. A LABEL Table - This table contains all program statement labels and their equivalent addresses.
  - c. A CONSTANTS Table - This consists of a list of all constants used. This table consists only of addresses and values.
  - d. A DATA Table - This table contains all the data variables used in the program. Each entry in this table consists of the variable name, followed by its address in both decimal and hexadecimal formats.
  - e. A PROGRAM Listing - This portion consists of a listing of each program line together with the DeltaMax numerical equivalent of the program line. Any errors detected in a program line will be listed at the end of the listing file.
2. An **error file** is always created and always includes some header information. When errors are detected, they are written to this file. The information regarding each error includes; program source file, line number and error description. The **error file** has the program file extension **.err**. It is used by the MacroPro II Editor to assist in locating and correcting errors.

3. A **symbol file** is always created. This file contains all symbol, label, and data definitions. The **symbol file** has the program file extension **.sym**. It is used by the Analyzer to assist in the testing and analysis process.
4. The **executable file** is only created when no compiler errors are detected. This file contains the compiled program in DeltaMax machine instruction format. The **executable file** has the program file extension **.mcx**. The Analyzer transmits this file to the DeltaMax Controller where it will be executed.
5. The **trace file** is only created when no compiler errors are detected. This file contains the information needed by the Analyzer to translate trace information into source program lines. This file has the program file extension **.dbg**. The **trace file** is only used by the Analyzer.

## Compiler Directives

Compiler directives are a class of instructions which simplify such operations as defining constants, data arrays and cams, or which cause the MacroPro II Compiler to function in a particular way. These instructions have no direct effect on the DeltaMax Controller. Their purpose is to simplify the programmer's task.

A list of compiler directive instructions and their formats is shown in Figure 2.4.

<b>Instruction</b>	<b>Format</b>	<b>Instruction</b>	<b>Format</b>
begin_data	label	<b>begin_data</b>	
begin_cam	label	<b>begin_cam</b>	
cam		<b>cam</b>	value,value,etc.
data		<b>data</b>	value,value,etc.
declare		<b>declare</b>	mode
dim	label	<b>dim</b>	size
dim	label	<b>dim</b>	controller#,size
end_cam		<b>end_cam</b>	
end_data		<b>end_data</b>	
equ	label	<b>equ</b>	value
float	label	<b>float</b>	
float_dim	label	<b>float_dim</b>	size
integer	label	<b>integer</b>	
text	label	<b>text</b>	"ASCII string"

Figure 2.4 - Compiler Directives



# MACROPRO II<sup>TM</sup>

FOR WINDOWS<sup>TM</sup>

Section 3 - Control and Motion Concepts



INDUSTRIAL INDEXING SYSTEMS, INC.

**SECTION 3 - CONTROL AND MOTION CONCEPTS****Table of Contents**

<i>Flags</i>	5
<b>Flag Categories</b>	5
<b>DeltaMax Internal Status Flags</b>	5
<b>Timers</b>	6
<b>Controller Flags</b>	6
<b>DeltaMax Controller Status Flags</b>	6
<b>DeltaMax Pseudo Axis Controller Status Flags</b>	7
<b>Flag Descriptions</b>	8
<b>Flag Instruction Summary</b>	10
<i>Arithmetic Instructions</i>	11
<b>Arithmetic Overview</b>	11
<b>Integer and Floating Point Arithmetic</b>	13
<b>Array Manipulation</b>	13
<b>Byte Operations</b>	14
<b>Bit Oriented Operations</b>	15
<b>Arithmetic Functions</b>	15
<b>Arithmetic Instruction Summary</b>	16
<i>Program Flow Instructions</i>	17
<b>Branching Instructions</b>	17
<b>Subroutine Control</b>	17
<b>The Select Statement</b>	18
<b>Program Branching Instructions</b>	19
<i>Motion Instructions</i>	20
<b>Motion Preparation Instructions</b>	20
<b>Position Data</b>	20
<b>Speed (Velocity) Data</b>	20
<b>Acceleration Data</b>	20
<b>Global And Local Zeroes</b>	20
<b>Motion Preparation Instructions</b>	21
<b>Digital Compensation</b>	21

---

<b>Velocity Control Instructions</b>	<b>23</b>
<b>Positioning Instructions</b>	<b>24</b>
<i>Piecewise Profiles</i>	<i>25</i>
<b>Building Profile Data Tables</b>	<b>25</b>
<b>Piecewise Profiles And Master Slave</b>	<b>28</b>
<b>Reading Controller Position</b>	<b>28</b>
<b>Master Slave Concepts</b>	<b>29</b>
<b>Simple Lock (Electronic Gearbox)</b>	<b>30</b>
<b>Useful Facts About Simple Lock Mode</b>	<b>30</b>
<b>Lock Methods For Simple Lock</b>	<b>32</b>
<b>Lock Method 1</b>	<b>32</b>
<b>Lock Method 4</b>	<b>34</b>
<b>Lock Method 6</b>	<b>34</b>
<b>Electronic Cams</b>	<b>35</b>
<b>Master Scaling</b>	<b>35</b>
<b>Data Scaling</b>	<b>36</b>
<b>Important Notes Regarding Electronic Cams</b>	<b>36</b>
<b>Calculating Electronic Cams</b>	<b>37</b>
<b>Electronic Cam Lock Methods</b>	<b>40</b>
<b>Lock Method 0</b>	<b>42</b>
<b>Lock Method 5</b>	<b>42</b>
<b>Lock Method 8</b>	<b>42</b>
<b>Lock Method 9</b>	<b>42</b>
<b>Sample Electronic Cam Application</b>	<b>42</b>
<b>Piecewise Lock</b>	<b>45</b>
<b>Master Angle Bus</b>	<b>45</b>
<b>Master Angle Bus Cautions</b>	<b>47</b>
<b>Fiber Optic Network</b>	<b>47</b>
<b>Master/Slave Instructions</b>	<b>49</b>
<i>Programmable Limit Switches</i>	<i>50</i>
<b>DeltaMax PLS Functions</b>	<b>50</b>
<b>Programming using PLS's</b>	<b>50</b>
<b>Processing of programs using PLS's</b>	<b>51</b>

---

<b>Execution of programs using PLS's</b>	<b>51</b>
<b>Programmable Limit Switch Instructions</b>	<b>52</b>
<i>Interrupts</i>	<b>53</b>
<b>Software Interrupts</b>	<b>53</b>
<b>Hardware Interrupts</b>	<b>54</b>
<b>Interrupt Instructions</b>	<b>55</b>
<i>Extended Memory Operations</i>	<b>56</b>
<b>Extended RAM</b>	<b>56</b>
<b>Extended RAM Programming</b>	<b>56</b>
<b>Extended Memory Limitations</b>	<b>57</b>
<i>Analog Input/Output</i>	<b>58</b>
<b>Capabilities of Analog Input/Output</b>	<b>58</b>
<b>Analog Controller Functional Description</b>	<b>58</b>
<b>Power-Up States for Analog I/O Channels</b>	<b>58</b>
<b>Analog Instructions</b>	<b>59</b>
<i>User Serial Ports</i>	<b>60</b>
<b>Serial Port Initialization</b>	<b>61</b>
<b>Important Notes Regarding Serial Ports</b>	<b>62</b>
<b>Serial Instructions</b>	<b>63</b>

*This page is intentionally left blank.*

## Flags

A flag is a bit in memory representing the current state of a timer, axis status, I/O or other condition. The DeltaMax has reserved a storage area in memory for 256 flags. A flag can be either on (1) or off (0).

There are a number of program instructions dealing with flags. In fact, taken as a group, flag instructions may be one of the largest groups of program instructions.

There are flag instructions to read inputs, to turn outputs on and off, to start and stop timers, to read motor activity and fault conditions and to read, set and clear user program switches.

Figure 3.1 lists the flags used for the DeltaMax Controller.

## Flag Categories

The following are the major categories of flags:

### DeltaMax Internal Status Flags

FLAG #	FUNCTION	CATEGORY
0 - 15 16 - 23 24 - 31 32 - 71	INPUTS ONLY OUTPUTS OR HARDWARE PLS SOFTWARE PLS FLAGS RESERVED FLAGS	INPUT/ OUTPUT
72 - 79	PROGRAMMABLE TIMERS	TIMER
80 - 95 96 - 111 112 - 119 120 - 127 128 - 207	CONTROLLER #1 STATUS FLAGS PSEUDO AXIS STATUS FLAGS ANALOG STATUS FLAGS EXTENDED STATUS FLAGS NOT USED	CONTROLLER STATUS
208 - 255	GENERAL PURPOSE USER FLAGS	USER

**Figure 3.1 - DeltaMax Internal Status Flags**

## Timers

DeltaMax Controllers provide 8 user programmable timers. These timers have a resolution of 10 milliseconds per "tick".

Timers are used by first setting the timer to the desired number of counts or ticks. This enables the flag associated with the timer. It will remain enabled until the specified time has passed.

## Controller Flags

The following are categories of various controller flags:

### DeltaMax Controller Status Flags

#1	DESCRIPTION
80	NOT USED
81	LOCK PENDING
82	FOLLOWING ERROR
83	MASTER/TEST MODE
84	CAM/PW PROFILE SIZE EXCEEDED
85	COMMAND INVALID IN THIS STATE
86	NOT USED
87	OVERDRAW FAILED
88	JOGGING
89	INDEXING
90	CALCULATION IN PROGRESS
91	HARDWARE INTERRUPT ARMED
92	FORCED DECEL IN PROGRESS
93	DOWN
94	BUSY
95	MASTER/SLAVE LOCK

**Figure 3.2 - DeltaMax Controller Status Flags**

## DeltaMax Pseudo Axis Controller Status Flags

#2	DESCRIPTION
96	NOT USED
97	NOT USED
98	NOT USED
99	NOT USED
100	CAM/PW PROFILE SIZE EXCEEDED
101	COMMAND INVALID IN THIS STATE
102	NOT USED
103	NOT USED
104	JOGGING
105	INDEXING
106	CALCULATION IN PROGRESS
107	NOT USED
108	FORCED DECEL IN PROGRESS
109	NOT USED
110	BUSY
111	NOT USED

**Figure 3.3 - DeltaMax Pseudo Axis Controller Status Flags**

## Flag Descriptions

### LOCK PENDING

This flag is set during lock modes 3, 8 or 9 between the time that the lock instruction is issued and the time that the master angle crosses the specified angle. The angle is specified in the **set\_trig\_pw** command for lock mode 3 or **set\_trig\_cam** for lock mode 8 or 9 and can be crossed from either direction.

### FOLLOWING ERROR

A following error occurs when the difference between the actual transducer angle and the expected transducer angle is outside the allowable range. The angles are compared every 100 ms. The allowable error is +/- 17 degrees if the motor shaft is motionless and +/- 180 degrees if the motor shaft is moving.

### MASTER/TEST MODE

This flag will be set if the axis has been put into the Master/Test mode. All motor fault conditions will have been reset. This is the default, power on state for the DeltaMax Controller. The servo amplifier will have been disabled and no checks for servo following errors will be made.

### CAM SIZE EXCEEDED/PIECEWISE PROFILE ARRAY FULL

This flag will be set if the number of cam array data elements exceeds 28K bytes, or if the number of piecewise profile segments exceeds 99.

### COMMAND INVALID IN THIS STATE

This flag will be set whenever the axis is requested to execute a command that cannot be executed at that moment. This typically occurs when program steps are out of logical order. An example would be the situation where the axis is currently jogging and is then commanded to **index** without first completing a **f\_decel** instruction and waiting for the motor to stop.

### OVERDRAW FAIL

This flag will be set when in the position profile the overdraw speed was not reached.

### JOGGING

This flag will be set when a **jog\_cw**, **jog\_ccw**, **track\_spd**, **l\_track\_spd**, **vel\_cw** or **vel\_ccw** command is executed. This flag will be cleared after completing a **f\_decel** operation.

### INDEXING

This flag will be set when a **index** or **position** command is executed. This flag will be cleared after completing the selected move.

### CALCULATING PIECEWISE PROFILE

This flag will be set while a Piecewise Profile is being calculated. It will be cleared otherwise.

### CALCULATING PLS DATA

This flag will be set while Programmable Limit Switch data is being calculated.

**HARDWARE INTERRUPT ARMED**

The axis controller has received a hardware interrupt instruction and is monitoring its respective hardware interrupt input line.

**FORCED DECEL IN PROGRESS**

This flag will be set when an **f\_decel** or **unlock** command is executed and the axis is still in motion.

**DOWN**

This flag will be set if a FOLLOWING ERROR is encountered (FOLLOWING ERROR is described above).

**BUSY**

This flag will be set when the axis is busy performing a motion related operation, for example **jog\_cw**. If an axis card experiences a **DOWN** condition while the **BUSY** flag is set, **BUSY** will remain set.

**MASTER/SLAVE LOCK**

This flag will be set when a **lock** command is executed. It will be cleared when a **f\_decel**, **unlock**, or **drive\_off** command is executed.

**BUSY PROCESSING**

This flag is set when the axis task handler is executing a lengthy command to prevent the program instruction task handler from initiating another program instruction for the specified axis. The following program instructions cause this flag to be set: **calc\_cam\_sum**, **calc\_unit\_cam**, **drive\_on**, **drive\_off**, **over\_draw**, **delta\_comp** and **prep\_profile**.

## Flag Instruction Summary

<b>Instruction</b>	<b>Format</b>		
blk_io_in	<i>label</i>	<b>blk_io_in</b>	input flag#,variable
blk_io_out	<i>label</i>	<b>blk_io_out</b>	output flag#,variable
clr_flag	<i>label</i>	<b>clr_flag</b>	user flag#
if_flag_off	<i>label</i>	<b>if_flag_off</b>	user_flag#,address_label
if_flag_on	<i>label</i>	<b>if_flag_on</b>	user_flag#,address_label
if_io_off	<i>label</i>	<b>if_io_off</b>	I/O flag#,address_label
if_io_on	<i>label</i>	<b>if_io_on</b>	I/O flag#,address_label
if_stat_off	<i>label</i>	<b>if_stat_off</b>	status_flag#,address_label
if_stat_on	<i>label</i>	<b>if_stat_on</b>	status_flag#,address_label
if_tmr_off	<i>label</i>	<b>if_tmr_off</b>	timer_flag#,address_label
if_tmr_on	<i>label</i>	<b>if_tmr_on</b>	timer_flag#,address_label
set_flag	<i>label</i>	<b>set_flag</b>	user_flag
set_tmr	<i>label</i>	<b>set_tmr</b>	timer_flag#,ticks
set_ms_tmr	<i>label</i>	<b>set_ms_tmr</b>	timer_flag#,ticks
turn_off	<i>label</i>	<b>turn_off</b>	I/O flag#
turn_on	<i>label</i>	<b>turn_on</b>	I/O flag#

Figure 3.4 - Flag Instructions

## Arithmetic Instructions

Several types of arithmetic functions are available, including:

1. 32 bit integer arithmetic
2. 64 bit floating point (double) arithmetic
3. Array manipulation
4. Byte operations
5. Bit set and bit clear operations
6. Absolute, negate and square root functions

Each of these items will be explained in more detail below.

## Arithmetic Overview

There are a variety of arithmetic-based operations and support functions which are supported in MacroPro:

- o Integer arithmetic.
- o Floating point (double) arithmetic.
- o Integer variables (treated as 32-bit / 4 byte locations).
- o Floating point variables (treated as 64-bit / 8 byte locations).
- o Arithmetic operations
 

o Addition	+	
o Subtraction	-	
o Multiplication	*	
o Division	/	
o Shift logical left	<<	} Integers Only
o Shift logical right	>>	
o Logical AND	&	
o Logical OR		
o Rotate left	{{	
o Rotate right	}}	
- o Arithmetic comparators
 

o Assignment	=
o Greater than	>
o Greater than or equal to	>=
o Less than	<
o Less than or equal to	<=
o Not equal to	<>

- o Arithmetic functions
  - o Square root                   **let**    x = SQR(y)
  - o Absolute value               **let**    z = ABS(value)
  - o Negate                       **let**    t = NEG(r)
  
- o Arrays/memory allocation
  - o Simple memory allocation
    - array\_name   **dim**            100
    - .
    - .
    - label        **let**            array\_name[x] = variable
  
  - o Axis Controller memory allocation using 28K volatile storage
    - array\_name   **dim**            axis\_controller\_#, #\_of\_4-byte\_words
    - .
    - .
    - label        **let**            array\_name[x] = variable
  
  - or
  - label        **let\_byte**       array\_name[x] = variable
  
- o Arithmetic assignment using simple equations
  - label   **let**            a = b
  - label   **let**            a = b + 5
  - label   **let**            a = b / 1789.123
  
- o Arithmetic compare/jump using simple equations
  - label   **if**             x < 10, under\_ten
  
- o Arithmetic assignment of single byte variables
  - label   **let\_byte**       array\_name[0]=pos
  - label   **let\_byte**       pos = array\_name[0]
  
- o Bit manipulation instructions
  - label   **set\_bit**        bit\_number, variable
  - label   **clr\_bit**        bit\_number, variable
  
- o Bit compare/jump instructions
  - label   **if\_bit\_set**    bit\_number, variable, addr\_label
  - label   **if\_bit\_clr**    bit\_number, variable, addr\_label

## Integer and Floating Point Arithmetic

Program variables will occupy 32 bits (4 bytes) of storage when defined as integers and 64 bits (8 bytes) when defined as floats. Arithmetic statements operate on these 4 or 8 byte variables. The format for arithmetic instructions is similar to that of the **LET** statement used in BASIC:

*label*            **let**            **result = variable1 + variable2**

where **result** is the result of the operation, **variable1** and **variable2** are the variables to be operated on. The symbol for addition "+" is used for purposes of illustration. Note that multiple operations in a single **let** statement are *not allowed*.

For example,

*label*            **let**            **a = b + c**

is acceptable, but

*label*            **let**            **a = b + c / d**

is not.

Calculations requiring multiple operations must be performed using multiple **let** statements. Spaces between variable names and operators should not be used.

Mixing data types is allowed. For example, **result**, **variable1** and **variable2** above can be defined as floats, integers or both. The operating system will automatically convert the variable types as it deems necessary. When assigning a floating point calculated result to an integer variable, the fractional portion will be truncated. No rounding will take place.

## Array Manipulation

A data array is a group of 32 or 64 bit variables which can be referenced by the same variable name. Data arrays are usually defined using a **dim** or **float\_dim** instruction or by use of the **begin\_data**, **data**, and **end\_data** instructions. Data array subscripts are zero based. The **INSTRUCTION SUMMARY** provides additional information on these instructions.

For example, to set aside ten 32 bit storage locations to contain a table of positions, the instruction

**position            dim            10**

could be used. Within the program, the first position in the table would be referred to as **position[0]**. The value within brackets is known as the array subscript. Note that for a table of ten values, the array subscript ranges from 0 to 9. Array subscripts can be a constant, an expression, or an integer variable. They cannot be floating point variables.

Special forms of the **let** instruction serve to store information in and retrieve information from data arrays. In our position table example, the instruction

*label*            **let**            **p=position[3]**

would retrieve the fourth position from the array and store that value in the variable **p**. To store a value in a data array, the instruction

*label*            **let**            **position[3] = x**

would be used.

To use a value from an array in arithmetic instructions, it is necessary to retrieve the value into a non-array variable, perform the arithmetic operation, and then store the result back in the array.

## Byte Operations

Special instructions for the manipulation of byte oriented data such as electronic cams or strings of characters. This special instruction, the **let\_byte**, is similar to the special case of the **let** statement for handling data arrays. For example, to access the fourth character of the text string **f\_name**, the instruction

*label*            **let\_byte**        **a = f\_name[3]**

could be used. To store data into a byte oriented data array, the instruction format

*label*            **let\_byte**        **f\_name[3] = a**

would be used.

The **let\_byte** instruction does not support any arithmetic operations. To perform arithmetic on byte oriented data, it is necessary to retrieve the byte into a conventional variable, perform the arithmetic, and store the result back into the byte array. The **let\_byte** instruction treats byte information as unsigned.

## Bit Oriented Operations

A set of instructions are available for setting (turning on) and clearing (turning off) individual bits within a 32 bit data value. These instructions can be useful when setting up variables for use with the **set\_map** and **set\_mcf** instructions. A complementary set of bit testing instructions allow program branching to take place depending on the state of a single bit in a 32 bit data value.

These bit oriented instructions cannot be used with variables declared as floating point.

## Arithmetic Functions

A select group of arithmetic functions are included for commonly required calculations. These functions are listed in Figure 3.5. The format of these functions is:

*label*            **let**            **result = function(x)**

where **function** represents the function name.

<b>Function</b>	<b>Description</b>
abs(x)	Returns the absolute value of x.
sqr(x)	Returns the square root of x. NOTE: If x is negative or zero, zero is returned.
neg(x)	Returns the two's complement of x.

**Figure 3.5 - Arithmetic Functions**

## Arithmetic Instruction Summary

<b>Instruction</b>	<b>Format</b>		
clr_bit	<i>label</i>	<b>clr_bit</b>	bit#,variable
dim	<i>label</i>	<b>dim</b>	100
dim	<i>label</i>	<b>dim</b>	controller#,100
float_dim	<i>label</i>	<b>float_dim</b>	45
float	<i>label</i>	<b>float</b>	
if	<i>label</i>	<b>if</b>	op1 <i>compare</i> op2, jump_address
integer	<i>label</i>	<b>integer</b>	
let_byte	<i>label</i>	<b>let_byte</b>	destination=source
let	<i>label</i>	<b>let</b>	variable=op1 <i>operation</i> op1
set_bit	<i>label</i>	<b>set_bit</b>	bit#,variable

**Figure 3.6 - Arithmetic Instructions**

## Program Flow Instructions

Normally, program instructions execute in an orderly, sequential fashion. Sometimes, it is desirable to alter this sequential order based on the status of an I/O module, the result of a calculation, the detection of a motor fault, or some other condition. Program flow instructions provide this capability.

There are three general classes of program flow instructions - branching, subroutine control, and the select statement. A special type of program flow instruction based on interrupts is described separately.

## Branching Instructions

There are two types of branching instructions - unconditional and conditional. The **goto** and **restart\_at** instructions are the only unconditional branch instructions other than subroutine control instructions, which are covered separately.

Conditional branching instructions are handled as follows:

1. Test the specified condition.
2. If the condition is true, transfer program control to the specified address.
3. If the condition is false, continue by executing the next sequential instruction.

Conditional instructions can test the status of DeltaMax flags, the result of an arithmetic comparison, the status of bits in a variable, or whether characters are present at a serial port.

## Subroutine Control


When designing a program, it is often desirable to place a group of commonly used instructions into a unit called a subroutine. The subroutine can then be called from anywhere within the program. Subroutines must begin with a labeled statement. The label on this initial statement is often referred to as the subroutine name. Subroutines must end with a **return\_sub** instruction.

The **gosub** instruction is then used to transfer program control to the subroutine. The subroutine instructions are then executed until the **return\_sub** instruction is encountered. At that point, program control returns to the instruction immediately following the **gosub** instruction.

## The Select Statement

Often, the process of controlling program flow is more complex than testing a flag and branching if the flag is set. For example, it may be necessary to choose among several alternatives based on a user entered menu selection. In cases like these, the **select** instruction group provides an effective means of controlling program flow.

Figure 3.7 illustrates how the **select** instruction might be used.



A program may contain up to 32 **select** statement groups. Each group may contain up to 100 **case** instructions.

## Program Branching Instructions

<b>Instruction</b>	<b>Format</b>	<b>Instruction</b>	<b>Format</b>
case	<i>label</i>	<b>case</b>	number
default	<i>label</i>	<b>default</b>	
end_select	<i>label</i>	<b>end_select</b>	
exit_select	<i>label</i>	<b>exit_select</b>	
gosub	<i>label</i>	<b>gosub</b>	subroutine label
goto	<i>label</i>	<b>goto</b>	address_label
if	<i>label</i>	<b>if</b>	value1 op value2,address_label
if_bit_clr	<i>label</i>	<b>if_bit_clr</b>	bit#,value,address_label
if_bit_set	<i>label</i>	<b>if_bit_set</b>	bit#,value,address_label
if_char	<i>label</i>	<b>if_char</b>	port#,address_label
if_flag_off	<i>label</i>	<b>if_flag_off</b>	user_flag#,address_label
if_flag_on	<i>label</i>	<b>if_flag_on</b>	user_flag#,address_label
if_io_off	<i>label</i>	<b>if_io_off</b>	I/O flag#,address_label
if_io_on	<i>label</i>	<b>if_io_on</b>	I/O flag#,address_label
if_no_char	<i>label</i>	<b>if_no_char</b>	port#,address_label
if_stat_off	<i>label</i>	<b>if_stat_off</b>	status_flag#,address_label
if_stat_on	<i>label</i>	<b>if_stat_on</b>	status_flag#,address_label
if_tmr_off	<i>label</i>	<b>if_tmr_off</b>	timer_flag#,address_label
if_tmr_on	<i>label</i>	<b>if_tmr_on</b>	timer_flag#,address_label
restart_at	<i>label</i>	<b>restart_at</b>	address_label
return_sub	<i>label</i>	<b>return_sub</b>	
select	<i>label</i>	<b>select</b>	value

**Figure 3.8 - Program Branching Instructions**

## Motion Instructions

Motion instructions are divided into five classes:

1. Pre-motion Preparation
2. Velocity Control
3. Incremental and Absolute Positioning
4. Piecewise Profiles
5. Master/Slave Operations

## Motion Preparation Instructions

### Position Data

DeltaMax Controllers maintain position data as a 32 bit number. The least significant 12 bits of this number represent the position of the feedback transducer. The most significant 20 bits are used as a signed turns counter. The range of valid positions is from -524,288 to +524,288 turns, assuming 4096 bits per motor revolution. Positive positions represent a displacement from zero in the clockwise direction.

Incremental distances are expressed in a manner similar to position data. For example, an incremental distance of two turns would be expressed as 8192 ( $2 \times 4096$ ). Positive distances represent clockwise motion.

### Speed (Velocity) Data

DeltaMax Controllers process speed data in RPM. Speeds may range from 0 to 5800 RPM in whole number increments. In special cases, speed values can be scaled down by a factor of 256 to provide fractional speed control.

### Acceleration Data

Acceleration (accel/decel) data is expressed in revolutions/second<sup>2</sup>. Accelerations may range from 1 to 1600 revolutions/second<sup>2</sup>. In special cases, acceleration values can be scaled down by a factor of 256 to provide very slow acceleration rates.

### Global And Local Zeroes

DeltaMax Controllers can maintain both a global and a local zero. Global zero usually refers to a fixed machine home position, and is often established by moving a load until it contacts a sensor. Local zero can be thought of as a floating home position. Local zero is often used when moving a known distance from the global zero, setting the local zero, and then performing a series of motions relative to the new zero position. The local zero may then be cleared.

## Motion Preparation Instructions

Motion preparation instructions are used to condition a controller prior to executing any motion. They are used to turn on the drive (amplifier), to set speeds and acceleration rates, and to set and clear zero positions.

On power up, DeltaMax Controllers set their turn counters to zero. The low order 12 bits of its position are also set to zero.

<b>Instruction</b>	<b>Format</b>		
clr_local	<i>label</i>	<b>clr_local</b>	controller#
delta_comp	<i>label</i>	<b>delta_comp</b>	controller#,AJ2,AJ3,AJ4,AJ7,AJ8,AJ9
drive_off	<i>label</i>	<b>drive_off</b>	controller#
drive_on	<i>label</i>	<b>drive_on</b>	controller#
set_ac_dc	<i>label</i>	<b>set_ac_dc</b>	controller#,rate
set_gl_ccw	<i>label</i>	<b>set_gl_ccw</b>	controller#
set_gl_cw	<i>label</i>	<b>set_gl_cw</b>	controller#
set_local	<i>label</i>	<b>set_local</b>	controller#
set_speed	<i>label</i>	<b>set_speed</b>	controller#,speed

**Figure 3.9 - Motion Preparation Instructions**

## Digital Compensation

The DeltaMax Controller provides a means of digital compensation at the drive, through the use of a **delta\_comp** command. The programmer has access to the following drive parameters:

<b>ADJUSTMENT PARAMETER</b>	<b>SYMBOL</b>	<b>SETTING RANGE</b>	<b>DEFAULT SETTING</b>	<b>DESCRIPTION</b>
LOAD INERTIA RATIO	<b>AJ2</b>	0-00.0 Times	1.0 Times	Sets the baseline frequency response of the driver using the ratio of the load inertia/motor inertia for a rigidly coupled load. If the load is not rigidly coupled, the value entered may vary from the calculated value. If the value is set too high, the motor and driver may become unstable and oscillate.

HIGH FREQUENCY RESPONSE	<b>AJ3</b>	0.1-20.0	1.0	Sets the high frequency response of the driver. The higher the number the more responsive. If the value is set too high, the motor and driver may become unstable and oscillate. The value in AJ3 is unitless and works in concert with AJ2.
POSITION LOOP DC GAIN	<b>AJ4</b>	1-200 RAD/SEC	30 RAD/SEC	Sets the DC gain of the position control loop. A higher value in AJ4 results in stiffer, faster response. If the value is set too high, the motor and driver may become unstable & oscillate.
ZERO SPEED GAIN REDUCTION	<b>AJ7</b>	0-10000	0	Sets the amount of gain reduction at zero speed.
FEED FORWARD GAIN	<b>AJ8</b>	0-2.0 TIMES	1.0 TIMES	Sets the feed forward gain in the position loop. A value of 50% results in 0.0 following error. Less than 50% will produce a lag between the actual motor position and the commanded position and greater than 50% produces a lead. The lead or lag will be proportional to speed at non 50% settings.
NOTCH FILTER FREQUENCY	<b>AJ9</b>	100-20000 RAD/SEC	6000 RAD/SEC	Sets the notch frequency of a velocity loop anti-resonance filter. This filter can be used to cancel machine or servo resonance. Power must be turned OFF then ON for this parameter to take effect.

**Table 3.1**

The **delta\_comp** values are based on 0 being the minimum value of the corresponding drive parameter and 100% being the maximum value.

The default values will be loaded and stored in the drive each time the controller is reset. When a new **delta\_comp** instruction is issued the new values will be sent to the drive.

## Velocity Control Instructions

Velocity control instructions are used in applications where control of motor speed is the objective. Velocity control instructions are listed in Figure 3.10.

DeltaMax Controllers provide several different types of velocity control instructions. Choice of instruction is usually determined by the requirements of the application. Each of the different types is described below.

1. Jog instructions cause the axis controller to run its motor at a constant velocity until commanded to stop. Direction of rotation is determined by the instruction -- **jog\_cw** or **jog\_ccw**. Velocity may not be changed while the motor shaft is moving.
2. Track speed instructions allow on-the-fly speed changes. Unlike jog instructions, direction of rotation is determined by the sign of the speed variable, with positive values indicating clockwise rotation. Two forms of the track speed instruction are provided. The **track\_spd** instruction covers speeds in the range of -3600 to 3600 RPM with a resolution of 1 RPM. The **l\_track\_spd** instruction covers speeds from -128 to +127.99 RPM in increments of 1/256 RPM.
3. Velocity instructions provide speed control with very low acceleration rates. Like the jog instructions, direction of rotation is determined by the instruction syntax. When a controller receives a **vel\_cw** or **vel\_ccw** command, it divides its present acceleration rate by 256 before using it. Speed, but not direction, may be changed while in velocity mode by issuing another velocity instruction with the new speed.
4. To stop a motor shaft, the **f\_decel** instruction is used. This instruction causes the motor to decelerate to zero speed at the currently programmed deceleration rate.

<b>Instruction</b>	<b>Format</b>		
f_decel	<i>label</i>	<b>f_decel</b>	controller#
jog_ccw	<i>label</i>	<b>jog_ccw</b>	controller#
jog_cw	<i>label</i>	<b>jog_cw</b>	controller#
l_track_spd	<i>label</i>	<b>l_track_spd</b>	controller#,speed
track_spd	<i>label</i>	<b>track_spd</b>	controller#,speed
vel_ccw	<i>label</i>	<b>vel_ccw</b>	controller#
vel_cw	<i>label</i>	<b>vel_cw</b>	controller#

**Figure 3.10 - Velocity Control Instructions**

## Positioning Instructions

DeltaMax Controllers support both absolute and incremental positioning. Absolute motions are made relative to the zero or home position established by the controller. Incremental motions are made relative to the current motor position. An absolute move is referred to as a **position**. An incremental move is called an **index**.

<b>Instruction</b>	<b>Format</b>		
incr_com	<i>label</i>	<b>incr_com</b>	controller#,bits,interrupts
index	<i>label</i>	<b>index</b>	controller#,distance
mod_index	<i>label</i>	<b>mod_index</b>	controller#,speed,rate,distance,degree
mod_position	<i>label</i>	<b>mod_position</b>	controller#,speed,rate,abs_position,degree
position	<i>label</i>	<b>position</b>	controller#,abs_position
set_offset	<i>label</i>	<b>set_offset</b>	controller#,offset

**Figure 3.11 - Positioning Instructions**

## Piecewise Profiles

Piecewise Profiles provide a simple means of defining complex motion profiles as a series of profile segments. Each segment consists of a target speed, accel/decel rate and distance.

DeltaMax Controllers perform Piecewise Profiles according to the following guidelines:

- A. If the present motor speed is LESS than the speed specified by the next profile segment, then:
  1. Accelerate to the new speed.
  2. Continue at the new speed until the distance specified has been moved. NOTE - some of the distance is used during acceleration.
  
- B. If the present motor speed is GREATER than the speed specified by the next profile segment, then:
  1. Continue at the old speed until the specified distance less the distance needed to decelerate has been traveled.
  2. Decelerate to the new speed.

## Building Profile Data Tables

Profile data tables are organized as a series of profile segments. Each profile segment consists of a target speed (in RPM), an acceleration value (in revs/second<sup>2</sup>) and a distance (in bits). The last profile segment in a profile must contain a zero speed. All profile segments in a given profile must contain direction values of the same sign.

Probably the most convenient method of creating Piecewise Profile tables would be to use the **data** statement. The following defines a three segment profile.

```

prodata      begin_data
                data          500,100,6.2*4096
                data          1000,200,8.6*4096
                data          0,150,15.2*4096
                end_data

```

The profile above can be described as follows:

1. Accelerate to 500 RPM at an acceleration rate of 100 revs/sec<sup>2</sup>, continue until the motor has turned 6.2 revolutions (including acceleration distance).
2. Accelerate to 1000 RPM at an acceleration rate of 200 revs/sec<sup>2</sup>. Continue at that speed until the motor has traveled 8.6 additional turns (including acceleration distance).

3. Continue at 1000 RPM as long as necessary, then decelerate to zero speed at a deceleration rate of 150 revs/sec<sup>2</sup>. The distance traveled in this segment is 15.2 motor revolutions (including deceleration distance).
4. The total distance traveled in the profile is 30 revolutions.

The following program statements could be used to execute the segments discussed above.

### Program Example

```

!
!----- FLAG DEFINITION -----
!
CALCULATI    equ        90
NG
BUSY         equ        94

!
!----- SEGMENT DATA -----
!
pw_data      begin_data
              data      500,100,6.2*4096
              data      1000,200,8.6*4096
              data      0,150,15.2*4096
              end_data
              .
              .

!
!----- CALCULATE THE PROFILE -----
!
ck_calc      prep_profile 1,pw_data          send profile
              if_stat_on  CALCULATING,ck_calc wait for calcs
              get_pstat   1,status
              if           status<>0,calc_error error routine
              .

!
!----- BEGIN RUNNING THE PROFILE -----
!
wt_busy      exec_profile 1                  do the profile
              if_stat_on  BUSY,wt_busy      wait til done
              .
              (instructions performed when execution is ok)
              .

!
!----- ERROR HANDLER -----
!
calc_error   let_byte    segment=status[3]   get segment in error

```

```

let_byte      error=status[2]      get error code
.
(process errors here)
.
.

```

Piecewise Profiles may also be calculated in the program and stored in an array in the appropriate format. This format is always:

<b>speed, accel, distance</b>	<b>Segment #1</b>
<b>speed, accel, distance</b>	<b>Segment #2</b>
.	.
.	.
.	.
<b>speed, accel, distance</b>	<b>Segment #x</b>

The maximum number of profile segments allowed in a Piecewise Profile is 96. Note that the last segment in a Piecewise Profile must have a zero speed.

In the DeltaMax Controllers, Piecewise Profile data shares the same memory area as cam data. Piecewise profile data is always placed in the axis extended memory area starting at location zero.

## Piecewise Profiles And Master Slave

It is possible to send a Piecewise Profile to the axis extended memory and to instruct the controller to execute the profile whenever an external device reaches a specified angular position. Refer to the section on **LOCK METHOD 3** in **MASTER SLAVE CONCEPTS** for a discussion of this technique.

<b>Instruction</b>	<b>Format</b>		
exec_profile	<i>label</i>	<b>exec_profile</b>	controller#
get_pstat	<i>label</i>	<b>get_pstat</b>	controller#,status
prep_profile	<i>label</i>	<b>prep_profile</b>	controller#,array_label
set_trig_pw	<i>label</i>	<b>set_trig_pw</b>	controller#,master_angle

**Figure 3.12 - Piecewise Profile Instructions**

## Reading Controller Position

DeltaMax Controllers provide instructions for reading the current transducer position of the axis controller, as well as the position of the "pseudo axis." It is possible to read two types of position data from an axis controller:

1. Actual Position - The **get\_pos** instruction returns the actual position of the corresponding transducer.
2. Commanded Position - The **get\_com** instruction returns the commanded position for the specified controller. Commanded position is usually slightly different than actual position. The difference is referred to as following error.

**NOTE:** The "pseudo axis" commanded position is always equal to actual position.

<b>Instruction</b>	<b>Format</b>		
get_com	<i>label</i>	<b>get_com</b>	controller#,variable
get_fol_err	<i>label</i>	<b>get_fol_err</b>	controller#,variable
get_pos	<i>label</i>	<b>get_pos</b>	controller#,variable

**Figure 3.13 - Instructions to Read Controller Position**


## Master Slave Concepts

The DeltaMax Controller provides a mode of operation whereby the motion of one axis, called a master axis, can be used to control the motion of a slave axis and/or Programmable Limit Switches.

A Slave Axis can use the Master Axis position to determine its own position and speed according to various methods described in subsequent sections of this chapter.

In the DeltaMax, the Master Axis transmits its current position transducer reading onto the designated data bus every 1 millisecond. A Slave Axis or Programmable Limit Switch listening on that bus will retrieve this position and use it to determine its own position. This high speed data rate allows for very accurate tracking and smooth operation.

There are currently three modes of operation for the slave axis. In simple lock, or "electronic gearbox" mode, a simple ratio is applied to the master position/speed data and the results used to directly determine the proper slave axis position and speed. In electronic cam mode, the slave axis moves through a pre-programmed path (the electronic cam) dependent on the rotation of the master axis. In Piecewise lock, the slave executes a Piecewise Profile when the master axis reaches a specified angle. Each of these modes is explained in detail below.



**Figure 3.14 - Simple Lock Illustration**

## Simple Lock (Electronic Gearbox)

In simple lock mode, the position of the master axis is used directly to determine the proper slave axis position and speed. Figure 3.14 illustrates simple lock mode. In this example, the master axis and slave axis were positioned to zero before entering master slave lock. The slave axis has a ratio of 2.00.

**NOTE:** Note the motion profile of the slave in relation to the master. The slave axis always travels at twice the speed of the master. The distance traveled by the slave is twice that of the master.

### Useful Facts About Simple Lock Mode

1. Ratios are treated as 12 bit fractions. To express a ratio of 1.0, the actual argument in the ratio instruction would be 4096.
2. Allowed values for ratio are from -32768 to +32767 bits. Positive ratios cause the slave axis to turn in the same direction as the master; negative ratios cause counter rotation.
3. When a program is started, the default ratio value for the slave axis is one-to-one (+4096 bits).
4. The recommended sequence for establishing master/slave lock is as follows:
  - A. If necessary, position the master and/or slave to the desired locations.
  - B. Establish the accel/decel rate of the slave. For certain lock methods, a high acceleration rate is needed to insure that the slave axis closely maintains the configured ratio between itself and the master axis.
  - C. Issue a **set\_map** instruction to start the information flow between the master and the slave.
  - D. Lock the slave axis using the simple lock mode (mode 1).
  - E. Set the desired ratio for the slave axis.
  - F. Proceed with the desired motion for the master axis.Steps D through E can be used to lock on to a master axis already in motion.
5. A typical sequence for ending simple lock is:
  - A. Unlock the slave axis using the **unlock** instruction.
  - B. Determine that the slave axis has stopped by testing its **BUSY** status flag.
  - C. Set the ratio for the slave axis to zero.

- D. Terminate the master angle passing process by issuing a **set\_map** instruction with no source axis.
- 6. Ratio may be changed at any time during simple lock mode. The slave axis will simply break lock, accelerate or decelerate at the currently programmed rate to match the master speed at the new ratio, and re-enter lock.
- 7. While in master/slave lock, a slave axis will ignore all motion instructions except forced deceleration. Issuing a **f\_decel** or **unlock** instruction will break lock and cause the slave axis to stop.

## Lock Methods For Simple Lock

There are four lock methods which can be used in simple lock applications. Each method and its function are outlined in Figure 3.15.

Lock Method	Description
1	Simple lock with acceleration limit. Slave tracks master position as long as currently set accel/decel rate is not exceeded.
2	Velocity Lock. Slave tracks master velocity, with accel/decel rate limit.
4	Simple lock with no acceleration limit.
6	Keyway to Keyway lock. Ratio is forced to be 1.0. On receipt of lock command, slave axis aligns its position transducer to match that of master. Accel/decel rate limit is used.

**Figure 3.15 - Lock Methods for Simple Lock**

Details for each of these lock methods are presented below.

### Lock Method 1

Lock Method 1 provides the electronic equivalent of a gearbox. The electronic gearbox or ratio is driven by the master angle from one of the master angle buses. The master angle is processed by the previously specified **ratio** instruction and an offset is added, resulting in an effective master position used to drive the slave command position.

When the **lock** instruction is executed, with a Lock Method of 1, the axis controller calculates the instantaneous offset between the master angle processed by the ratio and the slave command position. Once the offset is calculated, master slave lock is accomplished. Once every 1 millisecond thereafter, the slave axis position is updated based on the new master position.

The slave motion is limited by the previously executed **set\_ac\_dc** instruction and further limited to a maximum speed of 5800 RPM. The limiting of the slave acceleration rate can be an advantage in systems that have rough or rapidly changing master speeds. The limited acceleration on the slave dampens the slave motor and smoothes out the operation.

The **ratio** instruction can be executed while in Lock Method. When the **ratio** instruction is executed, the slave controller stops executing the equation above and reverts to simply slewing at the **set\_ac\_dc** rate until the slave reaches the new target speed as if lock were in place. When the speed is matched, a new offset is calculated and the equation above is executed.

It is important to note that after a **ratio** instruction is executed, a new offset is used. The **JOGGING** status flag is on while the slave axis is changing from one speed to another. This flag goes off when the ratio lock equation starts executing.

The acceleration rate may be changed during the slew from one speed to another caused by a ratio change. A **set\_ac\_dc** prior to the **ratio** instruction will cause the slew acceleration rate to change.

The limiting of slave speed and acceleration results in some interesting situations. For example, if the master is turning when the **lock** instruction is executed, the slave motor will accelerate at the specified acceleration rate until the equation above is satisfied. In actual practice the slave motor will accelerate above what would appear to be the final speed in order to make up the angular phase difference lost during acceleration. The resulting motion profile is shown in Figure 3.24

Since the slave is limited in both speed and acceleration, a situation may occur where the slave can never reach final lock speed. The same situation can occur if the effective master is changing speed faster than the slave can change speed because of the acceleration limit. As a rule of thumb, the slave acceleration rate should be set to at least 5 times the expected rate of change of the effective master




Figure 3.16 - Lock on a Moving Master

## Lock Method 4

Lock Method 4 is identical to Lock Method 1, except that the slave is not limited by the specified slave acceleration rate. This means that during lock, the slave is commanded directly by the effective master position.

**NOTE:** Any perturbations or roughness in the master will be passed onto the slave with no rate limiting.

The **ratio** instruction can be executed during Lock Method 4. When a new **ratio** is executed, the slave controller breaks lock, slews to new lock speed at the specified acceleration rate and relocks using the above equation. The **JOGGING** status flag is on during the slew period. Note that after the slew period a new offset is calculated. The acceleration rate may be changed during slew by executing a **set\_ac\_dc** instruction prior to the **ratio** instruction.

## Lock Method 6

Lock Method 6 allows the user to align the angle of the slave device with the angle of the master device. The ratio in Lock Method 6 is fixed at 1:1 and may not be changed. The slave controller acceleration rate is limited by the previously executed **set\_ac\_dc** instruction. The slave top speed is also limited to 5800 RPM.

When the **lock** instruction is executed, the slave controller executes the following equation every 1 millisecond.

$$\text{Slave Angle} = \text{Master Angle}$$

This equation is executed modulo 1 turn (4096 bits) of the master. This means that when the **lock** instruction is executed, the slave will move, at the acceleration rate specified, in the shortest direction to bring the master and slave absolute angles into alignment. Note that Lock Method 6 can cause movement when **lock** is executed even if the master is at rest.

The slave acceleration and speed are limited. Hunting can occur if the master rate of change is greater than the specified slave acceleration rate. The rule of thumb of having the slave acceleration rate at least 5 times the expected master rate of change is applicable. The limited acceleration rate can be used to smooth a master with perturbations (roughness).

## Electronic Cams

The DeltaMax Controller provides a mode of operation that effectively emulates mechanical cams. In the electronic cam mode, slave axes follow digital cams based on the rotation of a master axis.

Electronic cams are tables of incremental motor moves. Each incremental value occupies one byte of memory in the DeltaMax and has an allowable range of -127 to +127. (A value of 128 is used to signal the end of the cam). As the master axis turns, its position is continually transmitted onto the data bus. The slave controller uses the current master position to determine the proper index into the electronic cam array. As the index moves through the cam table, the incremental distances are added together to form the proper slave axis position. Linear interpolation is performed between elements in the cam array. When the end of the cam table is reached, the process begins again at the beginning of the table.

The key DeltaMax macro instruction for electronic cam mode is the **cam\_data** instruction.

This instruction defines the location of the cam within the axis controller memory. When the cam is defined within Macroprogram memory, this instruction will transmit the cam to the axis controller memory as well. The **cam\_data** instruction will also establish the scaling factor for master position and cam elements. Master and data scaling are explained in the paragraphs below.

## Master Scaling

Master scaling provides a mechanism to control the rate at which the slave axis processes its cam array relative to the rate at which the master axis turns.

In electronic cam mode, the master scale factor refers to the number of times the master position value is divided by 2 (i.e. shifted right) by the slave processor. For example, if a master scale factor of 12 were used, the slave processor would divide the master position value by 4096 ( $2^{12}$ ). The slave processor then compares the least significant 12 bits of the scaled value to the previous scaled master position to determine if it has changed. If the value has changed, the cam array index is changed accordingly.

Figure 3.17 summarizes the effect of master scaling.

<u>Master Scale Factor</u>	<u>Cam Array Advances Every</u>
12	4096 master bits
11	2048 master bits
10	1024 master bits
9	512 master bits
8	256 master bits
7	128 master bits
6	64 master bits
5	32 master bits
4	16 master bits
3	8 master bits
2	4 master bits
1	2 master bits
0	1 master bits

**Figure 3.17 - Master Scaling**

## Data Scaling

In order to insure that each element of an electronic cam is in the range of -127 to +127, it is often necessary to scale the cam data. This is accomplished by dividing the data by  $2^n$  where  $n$  is selected to cause the largest element of the cam array to be less than -127 to +127.

For example, if the largest element in a cam array is 864, we would need to divide by 8 ( $2^3$ ) to reduce the number below 128. The data scale factor in this case would be 3. Data scale factors from zero to 7 are allowed.

## Important Notes Regarding Electronic Cams

The following items should be considered when using electronic cams (Note - These examples assume a positive ratio value is being used):

1. Positive cam data indicates to the slave axis that the slave should travel in the same direction as the master axis.
2. The cam data pointer will always start at the top of the cam table, unless the **set\_cam\_ptr** instruction and lock method 5, 8 or 9 are used.
3. The cam data pointer will move toward the cam data table terminator when the master axis is traveling in the clockwise (CW) direction. The cam data pointer will move away from the cam data table terminator when the master axis is traveling in the counter-clockwise (CCW) direction.

## Calculating Electronic Cams

There are several ways that electronic cam data can be transferred to the axis controller memory:

1. The cam data values can be precalculated and placed in cam tables using the instructions **begin\_cam**, **cam** and **end\_cam**. When the **cam\_data** instruction is executed, the data defined in the cam table will be transferred to the axis controller along with the 'master scale' and 'data scale' values. The cam table terminator character (hex value 0x80) will be automatically transferred by the **cam\_data** instruction, as well.
2. The cam data can be calculated by the program, or off-line by another computing device. This data can then be transferred to the axis memory using a series of **let\_byte** instructions. The programmer in this instance is responsible for sending the cam table terminator character (hex value 0x80) as the last cam data table element. When the **cam\_data** instruction is executed, only the 'master scale' and 'data scale' values are transferred to the axis controller, since it is expected that the data has been previously transmitted.
3. The cam data table can be calculated **by the axis controller** using the **calc\_unit\_cam** instruction. Using this approach, a data table defining the 'shape' of the profile is transmitted to the axis controller. The programmer then issues a **calc\_unit\_cam** instruction which will calculate the cam data table. When the **cam\_data** instruction is executed, only the 'master scale' and 'data scale' values are transferred to the axis controller, since it is expected that the data has been previously calculated.

In applications where it might be desirable to compute an electronic cam based on a predetermined shape, such as a modified sine or trapezoidal type motion profile, the **calc\_unit\_cam** instruction can be used to greatly simplify this process.

The general process for using the **calc\_unit\_cam** instruction is as follows:

### DEFINE THE MOTION SHAPE BY CREATING A 'UNIT CAM' TABLE

1. Either graphically or mathematically describe the motion profile desired. The profile should be a function of distance versus machine angle or other appropriate X-axis value.
2. Measure and tabulate the value of distance at 128 equally spaced X-axis intervals over the duration of the profile.
3. Normalize the distance values by dividing each tabulated value by the largest value in the table.
4. Scale each table value by multiplying it by 65,536 ( $2^{16}$ ).
5. Add a zero element to the beginning of the table and replicate the last element in the table, so that the resulting table has 130 elements.

These steps result in a 'unit cam' table, which can then be used to generate cams of various lengths and number of elements.

### TRANSFER THE 'UNIT CAM' TABLE TO THE CONTROLLER

6. Dimension data storage areas on the axis controller of interest as follows:

<b>cam_area</b>	<b>dim</b>	<b>1,6750</b>
<b>table_area</b>	<b>dim</b>	<b>1,130</b>

The labels 'cam\_area' and 'table\_area' may be named whatever you desire. The dimension numbers must be as shown. It would also be acceptable to have more than one 'cam\_area' defined, as long as the total is equal to 6750 (this is 6750 4-byte elements totaling 27000 bytes). The axis controller expects to find the start of the 'table\_area' at memory location 6750.

7. Load the 'unit cam' table into the axis controllers 'table\_area' using the **let** instruction (the 130 entries in the 'unit cam' table are 4-byte values).

### CALCULATE THE CAM

8. Determine the total distance to be represented by the cam, and the total number of cam elements required.
9. Issue the appropriate **calc\_unit\_cam** instruction. While the axis controller is busy calculating the cam, its status flag for **CALCULATING PW PROFILE** is set.

**NOTE:** It is not necessary to issue a **drive\_on** instruction before executing the **calc\_unit\_cam** instruction.

10. Insert an end of cam character (hex value 0x80) at the appropriate place in the cam array.
11. Issue a **cam\_data** instruction so that the appropriate 'master scale' and 'data scale' are used.

At this point, the axis controller contains a valid electronic cam. Processing can now follow normal cam procedures.

The instruction format for **calc\_unit\_cam** is as follows:

*label*    **calc\_unit\_cam**    **axis#,distance,elements**

where 'axis#' is always 1, 'distance' is the total distance in counts to be traveled and 'elements' is the size of the cam to be generated.

The following example illustrates the **calc\_unit\_cam** instruction and the steps taken to load the predetermined 'unit cam' table named 'trap\_1\_3' into the axis controllers memory:

### Program Example

```

                declare      off
!
!----- FLAG DEFINITION -----
!
CALC          equ          74
DOWN          equ          77
BUSY          equ          78
LOCK          equ          79
AXIS_1        equ          1
BUSY_1        equ          (AXIS_1*16)+BUSY
DOWN_1        equ          (AXIS_1*16)+DOWN
CALC_1        equ          (AXIS_1*16)+CALC
LOCK_1        equ          (AXIS_1*16)+LOCK

cam           dim          1,6750
table         dim          1,130

!
!----- TABLE FOR UNIT TRAPEZOIDAL CURVE 1/3,1/3,1/3 -----
!
trap_1_3      begin_data
              data          0,9,36,81,144,225,324
              data          441,576,729,900,1089,1296,1521
              data          1764,2025,2304,2601,2916,3249,3600
              data          3969,4356,4761,5184,5625,6084,6561
              data          7056,7569,8100,8649,9216,9801,10404
              data          11025,11664,12321,12996,13689,14400,15129
              data          15876,16640,17408,18176,18944,19712,20480
              data          21248,22016,22784,23552,24320,25088,25856
              data          26624,27392,28160,28928,29696,30464,31232
              data          32000,32768,33536,34304,35072,35840,36608
              data          37376,38144,38912,39680,40448,41216,41984
              data          42752,43520,44288,45056,45824,46592,47360
              data          48128,48896,49660,50407,51136,51847,52540
              data          53215,53872,54511,55132,55735,56320,56887
              data          57436,57967,58480,58975,59452,59911,60352
              data          60775,61180,61567,61936,62287,62620,62935
              data          63232,63511,63772,64015,64240,64447,64636
              data          64807,64960,65095,65212,65311,65392,65455
              data          65500,65527,65536,65536
              end_data

```

```

!
!----- LOAD THE UNIT CAM TABLE INTO AXIS #1 STARTING AT LOC 6750 -----
!
load_table      let          ctr=0
load_loop       let          t=trap_1_3[ctr]
                let          table[ctr]=t
                let          ctr=ctr+1
                if           ctr<130,load_loop

!
!----- CALCULATE THE CAM BASED ON UNIT CAM TABLE -----
!
                let          distance=40960
                let          elements=2048
                let          start_of_cam=0

calc_busy       calc_unit_cam  AXIS_1,distance,elements,start_of_cam
                if_stat_on    CALC_1,calc_busy

!
!----- CALCULATE THE CAM SUM FOR THE CAM -----
!
                let          end_of_cam=elements-1

sum_busy        calc_cam_sum   AXIS_1,start_of_cam,end_of_cam
                if_stat_on    CALC_1,sum_busy

!
!----- GET SUM, SHOULD EQUAL REQUESTED CAM DISTANCE -----
!
                get_cam_sum   AXIS_1,sum
                if           sum<>distance,calc_err

!
!----- INDICATE THE CAM TO USE, MASTER SCALE AND DATA SCALE -----
!
                cam_data      AXIS_1,cam,5,0
                ratio         AXIS_1,4096

```

## Electronic Cam Lock Methods

Lock Method	Description
0	Cam lock at beginning of cam data table.
5	Cam lock at current cam pointer position. Used in conjunction with the <b>set_cam_ptr</b> instruction to lock at other than the beginning of the cam data table.
8	Cam Lock at current cam pointer position once the specified master angle is crossed. (See <b>set_trig_cam</b> ).
9	Same as Lock type 8 except execution of the cam is terminated at the last element in the cam.

**Figure 3.18 - Lock Methods for Cam Lock**

A detailed explanation of each of these lock methods follows.

## Lock Method 0

When the **lock** instruction is executed with a lock method of 0, the axis controller puts the cam pointer at the very top of the cam array, creates an instantaneous offset between the absolute master angle (on the selected bus) and 0.00 effective master, then locks the axis to the master. Once per millisecond after the **lock** instruction, the following equation is executed to drive the cam pointer.

$$\frac{(\text{Absolute master angle} * \text{ratio})}{(2^{\text{master scale}})} + \text{offset} = \text{effective master}$$

As this equation executes, the integer part of the effective master causes the cam pointer to move and the fractional part is used to linearly interpolate cam elements. The offset value in the equation is set when the **lock** instruction is executed to yield a 0.00 effective master and is modified each time the cam pointer wraps around to maintain the cam pointer within the cam data array.

If the ratio is changed during **lock** in Lock Method 0, the offset is instantaneously changed to yield the same effective master.

Changing the ratio on the fly during Lock Method 0 does not cause a jump in the cam pointer, but does cause a change in rate or direction of cam pointer movement. Since the slave speed and acceleration rate are not limited, the slave servo may change speed abruptly. Caution should be used when changing the **ratio** during cam execution.

During Lock Method 0, the pointer position in the cam data table can be captured using the **get\_cam\_ptr** instruction.

## Lock Method 5

Lock Method 5 is identical to Lock Method 0, except that the cam pointer is not moved to the top of the cam array when the **lock** instruction is executed. The cam pointer is started at the beginning of the cam element wherever the cam pointer was previously left (from previous cam execution) or a **set\_cam\_ptr** instruction execution.

## Lock Method 8


Lock Method 8 causes execution of a cam to be triggered when a specified master angle is crossed. Execution begins at the current cam pointer (see **set\_cam\_ptr**). The master angle to be used as the trigger will be defined using the **set\_trig\_cam** instruction.

## Lock Method 9

Lock Method 9 is identical to lock method 8 except execution of the cam is terminated when the last element in the cam table is executed.

## Sample Electronic Cam Application

An application requires a slave axis to follow a motion described by the mechanical cam shown in Figure 3.19. It has been determined that 16 cam data points will provide sufficient resolution for this application. The master axis is known to make 4 complete rotations for one cycle of the cam.



**Figure 3.19 - Mechanical Cam**

To implement this application, the following procedure could be used:

1. Measure the radius of the cam at each of 16 equal angle increments around the cam.
2. Convert data to incremental form by subtracting each data point from its successor.
3. Convert the data from inches to position transducer units by applying the proper scaling factor (4096 in this case.)
4. Examine each cam array to find the largest value. Use this value to determine the data scale factor needed to scale the data to the range of -127 to +127.
5. Divide each cam array element by the appropriate value ( $2^n$ , where  $n$  is the data scale factor).
6. Use a master scale factor of 10 (1024 master bits = 1 cam element).

The resulting arrays can then be entered into a program to produce the desired motion. Figure 3.20 shows a graphic representation of the resulting cam motion.




Figure 3.20 - Resulting Master/Slave Motion

## Piecewise Lock

Piecewise Lock, Lock Method 3, provides a means of triggering execution of a Piecewise Profile in a slave axis based on the master reaching a certain angular position. Refer to the Section on Piecewise Profiles for more details

To establish Piecewise Lock, follow the steps outlined below.

1. Build the profile as described in the Piecewise Profile Section.
2. Establish appropriate master angle passing.
3. Issue the **prep\_profile** command to transfer the profile data to the slave axis card.
4. Set up the trigger angle with the **set\_trig\_pw** instruction.
5. Issue the **lock** command with Lock Method set to 3.

When the specified master angle position is reached, the Piecewise profile will be executed.


## Master Angle Bus

The master angle bus is a high speed data highway which links the master/slave functions in a DeltaMax Controller. Each controller has two independent buses, designated as Master Bus A and Master Bus B. The **set\_map** program instruction provides a means for the programmer to specify which controller talks as a master on a given bus and which controller(s) listen as slaves.

There can only be one controller as master on a bus. Any controller may be configured as a slave. One slave controller may not be configured to listen to both masters.

The **set\_map** instruction uses a 4 byte word (32 bits) to define the total configuration. In the 32 bit variable, two (2) bytes are used for each bus. One byte configures which controller is the master and the other byte configures which controllers are the slaves. The **set\_bit** instruction provides a convenient means of setting the proper bits in the **set\_map** variable.

Figure 3.30 shows the configuration of the **set\_map** variable for the DeltaMax.



**Figure 3.21 - DeltaMax Master Angle Bus Configuration**

Consider an example where the pseudo is to be the master axis, and controller 1 is to be a slave. Master Angle Bus A will be used for the data path. The following program instructions could be used to configure the master angle bus:

### Program Example

```

!
!----- DEFINE BITS TO CONFIGURE THE MASTER ANGLE BUS STRUCTURE -----
!
MASTER_2 equ      30          Controller 2 talker on Bus A
SLAVE_1  equ      23          Controller 1 listen on Bus A

!
!----- INITIALIZE THE MASTER ANGLE BUSES - NO ACTIVITY -----
!
        let      mapvar=0
        set_map  mapvar

!
!----- TURN ON THE NECESSARY BITS IN THE VARIABLE mapvar -----
!
        set_bit  MASTER_2,mapvar
        set_bit  SLAVE_1,mapvar

!
!----- CONFIGURE THE BUS STRUCTURE USING THE VARIABLE mapvar -----
!
        set_map  mapvar

```

## Master Angle Bus Cautions

It is important to note that the data being transmitted on a master angle bus is the current master **position transducer reading**. Program instructions such as **set\_local** or **set\_offset** DO NOT affect the data being transmitted on a master angle bus, but DO impact the logical position of an axis. Thus, it is possible to read a position from a master controller using a **get\_pos** instruction and get a position value which does not match the value being transmitted on the master angle bus.

## Fiber Optic Network

Each DeltaMax Controller has a single fiber optic communications port. This port contains a single receiver. This provides a link between an MSC-850/MCF-850 or RFC-100 or an EFC-100 and a DeltaMax. This port must be configured using the **set\_mcf** instruction. Figure 3.22 shows the bit assignments used to define the network data paths.

BIT	SOURCE	DESTINATION
31		
30		
29		
28		
27		
26		
25		
24		
23		
22		
21		
20		
19		
18	FIBER OPTIC RECEIVER	Programmable Limit Switch
17	MASTER ANGLE BUS B	
16	MASTER ANGLE BUS A	
15		
14	PSEUDO AXIS	Master Angle Bus B
13		
12	FIBER OPTIC RECEIVER	Master Angle Bus A
11		
10	PSEUDO AXIS	
9		
8	FIBER OPTIC RECEIVER	
7		
6		
5		
4		
3		
2		
1		
0		

Figure 3.22 - DeltaMax Multi-Function Controller Configuration

**Program Example - DeltaMax Controller #1**

```
!  
!----- BITS USED TO CONFIGURE THE MASTER ANGLE BUS STRUCTURE -----  
!  
MASTER_2      equ      30           Controller 2 talker on Bus A  
SLAVE_1       equ      23           Controller 1 listen on Bus A  
FO_SOURCE_A   equ      8            Fiber Optics is the source for MAB A  
MCF           equ      2            MCF location  
  
!  
!----- DEFINE THE MULTI-FUNCTION CONTROLLER CARD -----  
!  
                let          mcfvar=0  
                set_bit     FO_SOURCE_A,mcfvar  
                set_mcf     MCF,mcfvar  
  
!  
!----- INITIALIZE THE MASTER ANGLE BUSES - NO ACTIVITY -----  
!  
                let          mapvar=0  
                set_map     mapvar  
  
!  
!----- TURN ON THE NECESSARY BITS IN THE VARIABLE mapvar -----  
!  
                set_bit     MASTER_2,mapvar  
                set_bit     SLAVE_1,mapvar  
  
!  
!----- CONFIGURE THE BUS STRUCTURE USING THE VARIABLE mapvar -----  
!  
                set_map     mapvar
```

## Master/Slave Instructions

<b>Instruction</b>	<i>label</i>	<b>Format</b>	
calc_cam_sum	<i>label</i>	<b>calc_cam_sum</b>	controller#,start_element,ending_element
calc_unit_cam	<i>label</i>	<b>calc_unit_cam</b>	controller#,distance,#elements,start_element
cam_data	<i>label</i>	<b>cam_data</b>	controller#,label,ms,ds
data_scale	<i>label</i>	<b>data_scale</b>	controller#,dscale
get_cam_cnt	<i>label</i>	<b>get_cam_cnt</b>	controller#,value
get_cam_end	<i>label</i>	<b>get_cam_end</b>	controller#,value
get_cam_ptr	<i>label</i>	<b>get_cam_ptr</b>	controller#,value
get_cam_strt	<i>label</i>	<b>get_cam_strt</b>	controller#,value
get_map	<i>label</i>	<b>get_map</b>	value
get_map_stat	<i>label</i>	<b>get_map_stat</b>	value
get_mcf	<i>label</i>	<b>get_mcf</b>	controller#,value
get_mcf_stat	<i>label</i>	<b>get_mcf_stat</b>	controller#,value
incr_com	<i>label</i>	<b>incr_com</b>	controller#,bits,interrupts
lock	<i>label</i>	<b>lock</b>	controller#,lock#
master_scale	<i>label</i>	<b>master_scale</b>	controller#,mscale
ratio	<i>label</i>	<b>ratio</b>	controller#,ratio
set_cam_ptr	<i>label</i>	<b>set_cam_ptr</b>	controller#,value
set_map	<i>label</i>	<b>set_map</b>	value
set_mcf	<i>label</i>	<b>set_mcf</b>	controller#,value
set_trig_cam	<i>label</i>	<b>set_trig_cam</b>	controller#,master_angle
set_trig_pw	<i>label</i>	<b>set_trig_pw</b>	controller#,master_angle
switch_cam	<i>label</i>	<b>switch_cam</b>	controller#,start_element
unlock	<i>label</i>	<b>unlock</b>	controller#,mode#

**Figure 3.23 - Master/Slave Instruction Summary**

## Programmable Limit Switches

DeltaMax Controllers provide a means of switching output modules on and off in relationship to the position of a master axis. This function, called Programmable Limit Switch (PLS), is similar to that provided by mechanical cam or drum switches. The DeltaMax Controller provides basic PLS capabilities, which are described in detail below.

### DeltaMax PLS Functions

One of the features of the DeltaMax Controller is the Programmable Limit Switch feature. There are 16 PLS output flags available. These flags can be switched on and off, depending on the position of the master angle being used to drive the PLS function. There are 8 hardware modules and 8 software flags. In the DeltaMax, the 8 hardware modules are associated with 8 physical output modules which correspond to flags 16 to 23.. The eight software outputs correspond to flags 24 to 31 and can be used to trigger software interrupts. The state of all 16 flags can be monitored using the **get\_pls\_out** instruction.

The users' program specifies set points (angles) of the master angle bus where the 16 flags should be turned ON and OFF. During program execution, this angular position is monitored and the outputs are turned ON and OFF according to the programmed set points.

### Programming using PLS's

Before attempting to write a program using the Programmable Limit Switch feature of the DeltaMax, it is important to understand the following:

1. Only one ON and OFF angle may be programmed for each PLS output. When an individual PLS module is programmed more than once using the **set\_pls\_ang** instruction, the new information regarding that module will replace the current information.
2. The ON and OFF set points are interpreted assuming a clockwise direction of rotation. For example, ON at 1000, OFF at 2000, means that the PLS output will be enabled whenever the master angle position is between 1000 and 1999 bits. However, ON at 2000, OFF at 1000, means that the PLS output will be disabled between 1000 and 1999 bits and enabled for the remainder of the master rotation.
3. Individual PLS modules can be disabled and enabled using the **set\_pls\_mask** instruction. Using this instruction, the PLS modules do not need to be reprogrammed.
4. Once a PLS module has been defined, it can only be cleared by using the **clr\_pls** instruction.

## Processing of programs using PLS's

When the controller receives a **set\_pls\_ang** instruction, it searches the programmed data for an existing record for the specified output. If a matching record is found, it will be replaced by the new data.

While this instruction is being processed, the CALCULATION IN PROGRESS flag of the axis controller will be activated. The program must verify that this flag is no longer active before executing subsequent **set\_pls\_ang** instructions. The axis processor will ignore any **set\_pls\_ang** instructions issued while the CALCULATION IN PROGRESS flag is activated.

## Execution of programs using PLS's

The controller monitors data from a master angle bus and turns ON and OFF the outputs at programmed set points. The appropriate bit in the PLS mask value must be set in order for that PLS to be active. A bit which is clear in the PLS mask value indicates a PLS that will not be active, although it remains defined. Once a PLS is defined, that module remains a PLS, even if its' mask bit is cleared. It cannot be used as an output module until a **clr\_pls** instruction is executed.

When a **pls\_mask** instruction is executed and a PLS is enabled, the PLS module will immediately be updated (set or cleared). When a **pls\_mask** instruction is executed and a PLS is disabled, the PLS module will be left in its current state.

**NOTE:** The angular position can come from one of several sources, as programmed by the **set\_mcf** instruction.

### DeltaMax

- A. Pseudo Axis
- B. Master Angle Bus A
- C. Master Angle Bus B
- D. Fiber Optic Receiver

When the DeltaMax is powered down, the PLS (Programmable Limit Switch) configuration is lost. The PLS modules must be programmed again on power up.

## Programmable Limit Switch Instructions

<b>Instruction</b>	<b>Format</b>		
clr_pls	<i>label</i>	<b>clr_pls</b>	controller#,variable
get_angle	<i>label</i>	<b>get_angle</b>	controller#,variable
get_for_ang	<i>label</i>	<b>get_for_ang</b>	controller#,channel#,variable
get_pls_ang	<i>label</i>	<b>get_pls_ang</b>	controller#,pls_angle
get_pls_mask	<i>label</i>	<b>get_pls_mask</b>	controller#,variable
get_pls_out	<i>label</i>	<b>get_pls_out</b>	controller#,variable
preset	<i>label</i>	<b>preset</b>	controller#,variable
set_gl_ccw	<i>label</i>	<b>set_gl_ccw</b>	controller#
set_gl_cw	<i>label</i>	<b>set_gl_cw</b>	controller#
set_local	<i>label</i>	<b>set_local</b>	controller#
set_mcf	<i>label</i>	<b>set_mcf</b>	controller#,variable
set_pls_ang	<i>label</i>	<b>set_pls_ang</b>	controller#,on,off,module#
set_pls_cnt	<i>label</i>	<b>set_pls_cnt</b>	controller#,count
set_pls_mask	<i>label</i>	<b>set_pls_mask</b>	controller#,variable
set_pls_time	<i>label</i>	<b>set_pls_time</b>	controller#,time,module#

**Figure 3.24 - Programmable Limit Switch Instructions**

## Interrupts

It is often necessary for your application program to respond quickly to an external event, such as a switch closure or an operator input. The DeltaMax programming language provides two methods for responding to this type of event.

Software Interrupts provide a means for a program to respond to changes in state of any DeltaMax flag. Hardware Interrupts provide a means for an axis controller to perform a preprogrammed task immediately on receipt of an input signal.

### Software Interrupts

The Software Interrupts feature of the DeltaMax provides for automatic program response to the change in state of any DeltaMax flag (I/O, timer, motor status or user).

This feature functions by allowing the programmer to associate the change of state of a flag with a program subroutine. Whenever the specified change occurs, the DeltaMax makes a note of what it was doing, and then transfers control to the associated subroutine just as though a **gosub** instruction was performed. When the subroutine is completed, control passes back to the interrupted operation.

In the DeltaMax, Software Interrupts are checked between the execution of program instructions. Therefore, program activities such as downloading large cams from program memory to axis controller memory can hold off the recognition of software interrupts.

Software Interrupt processing provides up to 32 prioritized interrupts ranging from priority 0 (highest) to 31 (lowest). If more than one interrupt occurs at the same time, the one with the **LOWEST** interrupt number (highest priority) will be recognized first. The user may disable all or selected software interrupts during portions of the program which should not be "interrupted".

Software Interrupt processing is edge triggered -- the specified subroutine will be executed only on the leading or trailing edge of the transition, depending on the type of interrupt specified. For example, if a software interrupt is specified to occur whenever input module number 1 is ON and software interrupt processing is enabled while input module number 1 is already ON, no software interrupt will occur. The interrupt will only occur when the transition from the OFF to the ON state occurs.

## Hardware Interrupts

In some cases, it is desirable for an axis controller to respond very rapidly to an external event. For these instances, DeltaMax Controllers provide a feature called **Hardware Interrupts**.

The axis controller is directly connected to the corresponding I/O Module Controller slot. For example,

### **Controller #1 is linked to I/O-1 (flag 0)**

Hardware Interrupts can be processed much faster than conventional Input/Output handling since the Main Processor distributes the desired task to the Axis Controller before the interrupt occurs rather than waiting for the Input module to be activated, then distributing the task or instruction. Because of this, Hardware Interrupts are capable of 1 millisecond response times.

The following is a list of the tasks or instructions which can be executed when the corresponding hardware interrupt signal is detected:

<b>trap_pos</b>	<b>lock</b>
<b>over_draw</b>	<b>ratio</b>
<b>index</b>	<b>exec_profile</b>
<b>position</b>	<b>f_decel</b>

Each instruction above is used with the Hardware Interrupt feature by issuing an **enable\_hwi** instruction, followed by the instruction to be executed when the interrupt is detected.

The following example would instruct controller #1 to index 2048 bits when input module I/O-1 changes from a low to high state:

<i>label</i>	<b>enable_hwi</b>	
	<b>index</b>	<b>1,2048</b>

Execution of this pair of instructions causes the Main Processor to instruct the appropriate controller card that it should now monitor its Hardware Interrupt signal and perform the designated operation when the interrupt signal is activated. The axis controller responds by enabling its **BUSY** and **HARDWARE INTERRUPT ARMED** flags. After the controller detects the interrupt and completes the task, its **BUSY** and **HARDWARE INTERRUPT ARMED** flags will be disabled. It is the programmers responsibility to issue this pair of instructions again if it is desired to perform the task again.

The programmer can cancel an armed task with the instruction **disable\_hwi**. On receipt of the **disable\_hwi** instruction, the Controller's **BUSY** and **HARDWARE INTERRUPT ARMED** status flags will be turned off.

Only 1 task can be executed per interrupt. If more than 1 task is issued, the most recent will be used.

## Interrupt Instructions

<b>Instruction</b>	<b>Format</b>	<b>Instruction</b>	<b>Format</b>
clr_swi	<i>label</i>	<b>clr_swi</b>	interrupt#
clr_all_swi	<i>label</i>	<b>clr_all_swi</b>	
disable_swi	<i>label</i>	<b>disable_swi</b>	
disable_hwi	<i>label</i>	<b>disable_hwi</b>	controller#
enable_hwi	<i>label</i>	<b>enable_hwi</b>	
enable_swi	<i>label</i>	<b>enable_swi</b>	
f_decel	<i>label</i>	<b>f_decel</b>	controller#
get_trap_pos	<i>label</i>	<b>get_trap_pos</b>	controller#,variable
over_draw	<i>label</i>	<b>over_draw</b>	controller#,speed,limit,distance
set_swi_mask	<i>label</i>	<b>set_swi_mask</b>	variable
swi_if_off	<i>label</i>	<b>swi_if_off</b>	interrupt#,flag,sub_label
swi_if_on	<i>label</i>	<b>swi_if_on</b>	interrupt#,flag,sub_label
trap_pos	<i>label</i>	<b>trap_pos</b>	controller#

**Figure 3.25 - Software and Hardware Interrupt Instructions**

## Extended Memory Operations

The DeltaMax provides one type of extended memory - volatile RAM. Separated into two distinct areas for controller 1 and 2.

### Extended RAM

Each extended memory area has 28K bytes of volatile data memory. This memory can be used to create very high resolution electronic cam data tables or piecewise profiles.

### Extended RAM Programming

To create a data array in axis controller memory, a special form of the **dim** instruction is used:

#### SYNTAX:

```
label      dim      controller#,words
```

#### PARAMETERS:

label	Name assigned to block of memory (array).
controller#	Axis ID #.
words	Length of data memory allocated to the label. Allocated in 4 byte (32 bit) words.

Once this special form of the **dim** instruction has been executed, it is not necessary to reference this area in memory by Axis ID#. Values in these arrays are accessed using the **let\_byte** and **let** instructions in the same manner as any standard array.

#### WARNING:

Piecewise Profiles and the conventional form of the **cam\_data** instruction use the same memory from the start (location 0) of the 28K volatile RAM area. It is the responsibility of the programmer to ensure that arrays declared with the extended form of the **dim** statement do not overlap with Piecewise Profiles or conventional cams.

## Extended Memory Limitations

1. The **prep\_profile** instruction for Piecewise Profiles may not reference data stored in axis controller memory. Data for this type of profile must reside in main memory.
2. The **cam\_data** instruction can only reference data residing in the master controller or in axis controller memory which is the target of the **cam\_data** instruction.
3. Depending upon the location of the data array, the **cam\_data** instruction executes differently. If the array is in the master controller's memory, the **cam\_data** instruction transmits the array to the specified axis controller, establishes pointers to the beginning and end of the cam array, and defines both the master scale and data scale factors. If the array is in the axis controller's memory, the **cam\_data** instruction only establishes pointers to the beginning and end of the array, and the master and data scale factors. No data transfer is executed.

## Analog Input/Output

### DeltaMax

The DeltaMax has two analog inputs and one analog output channel. These channels might be used in applications like a joystick interface, controlling DC motor drives, or monitoring analog sensors.

### Capabilities of Analog Input/Output

- |                   |  |
|-------------------|--|
| <b>Data range</b> | 12 bit conversion over a range of 0 to +5 volts is provided. The data range is 0 (0 volts) to +1023 (+5 volts).  |
| <b>Offset</b>     | Any of the 3 channels may be offset. The offset value is added to the real channel value at the time of conversion. The channel offsets range from -1023 to +1023. The default value is 0. |
| <b>Slew rate</b>  | An analog “rate of change” limit may be set for each channel. This rate of change limit is "calibrated" in bits per 10 milliseconds. The default value is +1023.                           |

### Analog Controller Functional Description

Analog processing uses a 10 millisecond update cycle in which the analog input channels and analog output channel are updated.

INPUT channels are read-only. Each input channel is read, and the raw voltage signal is added to the corresponding channel offset value. The result of this addition is compared to the previous reading for that channel, and if necessary, limited by the slew rate limit currently in effect.

OUTPUT channels are updated using the same algorithm as INPUT channels. That is, the offset is added and then the rate of change limit is applied. This limited result is then output.

### Power-Up States for Analog I/O Channels

On power up, or after a **RESET** command from the MacroPro II Analyzer, the analog I/O channels are in the following state:

1. Offsets are set to zero (0).
2. Slew rate limits are set to 1023.
3. Output channel values are set to zero.

## Analog Instructions

<b>Instruction</b>	<b>Format</b>		
analog_in	<i>label</i>	<b>analog_in</b>	controller#,ch#,value
analog_out	<i>label</i>	<b>analog_out</b>	controller#,ch#,output
analog_rt	<i>label</i>	<b>analog_rt</b>	controller#,ch#,value
analog_zo	<i>label</i>	<b>analog_zo</b>	controller#,ch#,value

**Figure 3.26 - Analog Instructions**

## User Serial Ports

The DeltaMax family of controllers support a number of serial communication ports. The following is a summary of the ports available for each controller and a short description of each:

<u>PORT NUMBER</u>	<u>DESCRIPTION</u>
Port 1	RS-232C Executive serial port.
Port 2	RS-232C Executive serial port <i>or</i> User programmable RS-232 port.

Port 1 is an RS-232C serial port that only supports the DeltaMax Packet Protocol method of communication. This port is typically used by the MacroPro II Development System for the loading and testing of DeltaMax programs.

Port 2 is a user programmable port suitable for use with a variety of computer displays, hand-held terminals, strip displays, printers, data entry terminals, etc..

Both Port 1 and Port 2 default to RS-232C Executive serial port with a baud rate of 19,200 and will remain in this configuration until a **port\_set** instruction is executed. The **port\_set** instruction can only be applied to port Port 2.

## Serial Port Initialization

Before the user programmable port (Port 2) can be used, it is necessary to configure the port for proper use. The **port\_set** instruction is used for this purpose. The format of this instruction is:

*label*            **port\_set**            **port,baud,protocol**

The **port** number can only be 1. The **baud** rate can be 110, 300, 600, 1200, 2400, 4800, 9600, or 19200. The **protocol** variable is used to select the proper combination of parity, stop bits and XON/XOFF selection, according to Figure 3.39.

<u>Protocol</u>	<u>Description</u>
0	1 stop bit, no parity, XON/XOFF disabled
1	2 stop bits, no parity, XON/XOFF disabled
2	1 stop bit, odd parity, XON/XOFF disabled
3	2 stop bits, odd parity, XON/XOFF disabled
4	1 stop bit, even parity, XON/XOFF disabled
5	2 stop bits, even parity, XON/XOFF disabled
6	CUSTOM
7	RESERVED
8	1 stop bit, no parity, XON/XOFF enabled
9	2 stop bits, no parity, XON/XOFF enabled
10	1 stop bit, odd parity, XON/XOFF enabled
11	2 stop bits, odd parity, XON/XOFF enabled
12	1 stop bit, even parity, XON/XOFF enabled
13	2 stop bits, even parity, XON/XOFF enabled

**Figure 3.27 - Communication Protocol Selection**

Once a **port\_set** instruction has been executed, it remains in effect until another is issued or power is cycled to the DeltaMax.

Once a serial port has been initialized, **print**, **print\_num**, and **input** instructions may be issued.

## Important Notes Regarding Serial Ports

The following factors should be considered when using the DeltaMax serial ports.

1. Serial port instructions have been implemented so that program execution does not need to be delayed while waiting for characters to be transmitted or received. This leads to the following considerations:

- a. **Print** and **print\_num** instructions are queued up to be executed by a separate task. Several milliseconds may pass between the execution of the instruction and the actual transmission of characters. The program sequence:

```

label          let          x=10
                 print_num    4,0,x
                 let          x=25

```

could result in "25" being sent out the serial port instead of "10".

It may be necessary to use temporary variables to yield the desired result.

- b. The print queue of the operating system has room for a limited number of entries. It is possible for the user to overrun this queue by rapidly issuing print commands with no time delay between them. If your application will issue several print commands in succession, it may be necessary to implement a software delay between print commands.
- c. The **input** instruction takes precedence over the **print** and **print\_num** instructions. The program sequence:

```

NULL          text          ""          null
                 string
MSG_PROMPT    text          "Please Enter Speed: "
                 print          MSG_PROMPT
                 input        NULL,4,0,x,in_done

```

may result in the **input** instruction executing before **MSG\_PROMPT** is sent out the port. A programmed wait of approximately 30 milliseconds between the **print** and the **input** statement may be necessary to achieve the desired result.

2. There are two special cases of the **input** command:
  - a. The first parameter of the **input** instruction is the address of a text string which is sent to the serial port as a prompt. If the prompt string exists, then the current value of the variable being input is sent to the port immediately following the prompt string. If the prompt string is a null string, i.e. consists of a single null character, then no prompt is displayed, and the current value of the variable is NOT sent to the port.

- b. A special form of the **input** command is provided to handle single character input. In this form, the prompt string is a null string and the length and width parameters are zero. In this situation, the decimal value of the next character received via the serial port will be placed in the input variable.

## Serial Instructions

<b>Instruction</b>	<b>Format</b>		
if_char	<i>label</i>	<b>if_char</b>	port#,address_label
if_no_char	<i>label</i>	<b>if_no_char</b>	port#,address_label
input	<i>label</i>	<b>input</b>	textlabel,len,dec,variable,userflag
port_set	<i>label</i>	<b>port_set</b>	port#,baud,protocol
print	<i>label</i>	<b>print</b>	textlabel
print_num	<i>label</i>	<b>print_num</b>	len,dec,var
stop_input	<i>label</i>	<b>stop_input</b>	

**Figure 3.28 - Serial Port Instructions**



# MACROPRO II<sup>TM</sup>

FOR WINDOWS<sup>TM</sup>

Section 4 - DeltaMax DeviceNet



INDUSTRIAL INDEXING SYSTEMS, INC.

## SECTION 4 - DELTAMAX DEVICENET

### Table of Contents

<i>Introduction</i>	3
<i>DeltaMax Object Model</i>	4
<i>Connecting DeltaMax to DeviceNet Network</i>	5
<i>Deltamax Objects</i>	6
Flags	6
Data Memory	8
Integer	10
Float	11
<i>DeltaMax Programmable Parameter Object</i>	12
<i>I/O Connections</i>	14
Polled Connection	14
Bit Strobed Connection	14

*This page is intentionally left blank.*

## Introduction

DeviceNet is a low-cost communications link to connect industrial devices ( such as limit switches, photoelectric switches, valve manifolds, motor starters, operator interfaces, ect..) as well as control devices to a network. The Open DeviceNet Vendor Association Publishes a DeviceNet Product Catalog three or four times a year for a current product listing of DeviceNet compatible devices.

DeviceNet is a trademark of the ODVA Open DeviceNet Vendor Association, inc.

8222 Wiles Road

Suite 287

Coral Springs , FL 33067

Phone: (305)340-5412

Fax:(305)340-5413


<http://www.industry.net/ODVA>

IIS Industrial Indexing Systems Inc. is a member of ODVA. IIS maintains a Vendor ID with ODVA of 89.

IIS has given the DeltaMax the following:


Device Profile:	Generic
Product Name:	DeltaMax
Product Code:	0
Product Revision:	1

### DeltaMax Object Model




## Connecting DeltaMax to DeviceNet Network

The figure below shows the location of the DeviceNet connector on the DeltaMax.



The figure below shows the open pluggable terminal connector required for the DeviceNet Network connections.



## Deltamax Objects

### Flags

DeviceNet has limited access to DeltaMax FLAG bit map memory. FLAG memory in a DeltaMax contains vital information for the programmer developing a MacroProgram for any application. This bitmap is broken down as follows:

FLAG #	DESCRIPTION
0-15	Discrete Inputs; Application specific, user programmable, originate from an external connector.
16-23	Discrete Outputs; Application specific, user programmable, output to an external connector.
24-31	Software programmable limit switches.
32-55	DeviceNet input flags. The <b>DeviceNet</b> port may <b>read/write</b> to these flags. To be considered as inputs only by a MacroProgrammer, therefore not write-able by a MacroProgram.
56-71	DeviceNet output flags. The <b>DeviceNet</b> port may only <b>read</b> these flags. To be considered as outputs from the MacroProgram, they may be written too or read from in a MacroProgram.
72-79	Timers
80-95	Axis1 status flags; example JOGGING,BUSY,DOWN,INDEXING, ect..
96-111	Pseudo Axis status flags, similar to Axis1 status flags, however this is a software axis
112-127	Analog status flags.
128-132	DeviceNet Status flags; status flags read only. The <b>DeviceNet</b> port may only <b>read</b> these flags.
133-207	Not Used
208-255	User flags; have programmable effects in motion program.

## Flag Object Definition

Class Code: 100 (64HEX)

Instances: 1-256, one instance for each flag. Flags are zero based therefore instance 1 is for flag zero.

Instance Attributes: ( one only )

Attr. ID	Access Rule	Attr. Name	Data Type	Description
3	get/set	Value	BOOL	The logic value of the flag

The access rule for each instance is dependant on the flag# associated with it as follows:

Instance	Flag#	Access Rule
1-32	0-31	none
33-56	32-55	get/set
57-72	56-71	get
73-128	72-127	none
129-144	128-143	get
145-256	144-255	none

## Instance Definitions

- 33 thru 56) These instances are DeviceNet input flags, therefore they are read-only MacroProgram flags. A device external to the DeltaMax may set and clear these flags over DeviceNet.
- 57 thru 72) These instances are DeviceNet output flags, therefore they may be set or cleared in a MacroProgram. A device external to DeltaMax may access their attributes over DeviceNet.
- 129) CanBus Enabled Status Flag. This instance is TRUE once a canset instruction is successfully executed in a MacroProgram.
- 130) CanBus Fault Flag. This instance is TRUE if DeviceNet interface goes busOff.
- 131) Explicit Connection Exists. This instance is set while an explicit connection is present.
- 132) Polled Connection Exists. This instance is set while a polled connection is present.
- 133) Bit-Strobed Connection Exists. This instance is set while a bit-strobed connection is present.
- 134) DeviceNet Bus Power Down. This instance is set when the DeltaMax hardware detects that the DeviceNet Network power has faulted. The flag is intended for MacroProgram use.

## Data Memory

This object in the DeltaMax controller allows access to all of the MacroProgram variable memory area. It offers addressing modes that the individual Float and Integer Objects do not. It is intended to facilitate large block transfers of memory.

MacroProgram variable memory is set aside exclusively for an individual application. In total it is 16000 bytes, however it is broken into two fairly unique sections. One section holds data that is referred to in a MacroProgram of type integer, they are 32bits wide. The other section holds type floats, they are 64bits wide. The two sections have beginning address offsets of 0 and an ending offset depending on the application. The integer and float sections of data memory are contiguous, therefore the float address offset of 0 is actually address following the integer ending offset. Variable address offsets are easily obtained by the programmer in a symbol table file generated by the “MacroPro II” tool kit.

### Data Memory Object Definition

Class Code: 103 (67HEX)

Instances: 1- 2 ( 1-Integers, 2-Floats)

Instance Attributes:

Attr. ID	Access Rule	Attr. Name	Data Type	Description
1	get/set	Address Offset	UINT	Address offset used for Attr. 3 when accessing the value. Default = 0.
2	get/set	Data Length	UCHAR	Data access length 1..8 Defaults: 4 for integers instance 1 8 for floats instance 2
3	get/set	Value	DINT LINT	The data memory value. The data type can be modified with attribute 2.
4	get/set	Address Mode	UCHAR	Available for selecting an addressing mode, see table 1.1 Default = 0, address is in service data.
5	get	Unprotected Lo	UINT	Data is accessible for write above this offset. Default = 0
6	get	Unprotected Hi	UINT	Data is accessible for write below this offset. Default = ending offset, application specific.

Table 1 - Addressing Modes ( attribute 4 )

<b>Value</b>	<b>Description</b>
0	Address offset is obtained from service data.
1	Address is obtained from the address offset attribute, the attribute is not incremented after the access.
2	Address is obtained from the address offset attribute, with auto-increment, in that the address offset is incremented after the access by the “Data Length”. Once the address reaches the end offset a Vendor Specific error is returned with add code of 01 (address offset out of range).

### Data Memory Behavior

Attributes 5 and 6 are defaulted such that over DeviceNet MacroProgram variables may not be written to. If it is required that variables in a MacroProgram be written to over the Network then a **dnet\_range** instruction must be executed in the MacroProgram, see **dnet\_range** section herein.

## Integer

The Integer Object allows easy access to Integer variables for most DeviceNet devices.

This object in the DeltaMax controller allows access to only the integers of the MacroProgram variable memory area. There is one instance for each integer of the MacroProgram. Due to the nature of DeviceNet, one is able to only address up to the first 256 instances of the Integer Memory space, however if need be one can access all of integer space using the Data Memory Object.

### Integer Variable Memory Object Definition

Class Code: 101 (65HEX)

Instances: 1 thru 256

Instance Attributes:

Attr. ID	Access Rule	Attr. Name	Data Type	Description
1	get	Address Offset	UINT	Address offset of the instance.
2	get	Data Length	UCHAR	Always 4 bytes.
3	get/set	Value	DINT	Value of Integer variable instance.
4	get	Unprotected Lo	UINT	Same as Data Memory Object.
5	get	Unprotected Hi	UINT	Same as Data Memory Object.

### Integer Variable Behavior

Attributes 4 and 5 are defaulted such that over DeviceNet MacroProgram variables may not be written to. If it is required that variables in a MacroProgram be written to over the Network then a **dnet\_range** instruction must be executed in the MacroProgram, see **dnet\_range** section herein.

## Float

The Integer Object allows easy access to Integer variables for most DeviceNet devices.

This object in the DeltaMax controller allows access to only the floats of the MacroProgram variable memory area. There is one instance for each float of the MacroProgram. Due to the nature of DeviceNet, one is able to only address up to the first 256 instances of Float Memory space, however if need be one can access all of the float space using the Data Memory Object.

### Float Variable Memory Object Definition

Class Code: 102 (66HEX)

Instances: 1 thru 256

Instance Attributes:

Attr. ID	Access Rule	Attr. Name	Data Type	Description
1	get	Address Offset	UINT	Address offset of the instance.
2	get	Data Length	UCHAR	Always 8 bytes.
3	get/set	Value	LREAL	Value of Float variable instance.
4	get	Unprotected Lo	UINT	Same as Data Memory Object.
5	get	Unprotected Hi	UINT	Same as Data Memory Object.

### Float Variable Behavior

Float variables are 64bits wide, they are defined in IEEE 754 for the basic double floating-point format.

Attributes 4 and 5 are defaulted such that over DeviceNet MacroProgram variables may not be written to. If it is required that variables in a MacroProgram be written to over the Network then a **dnet\_range** instruction must be executed in the MacroProgram, see **dnet\_range** section herein.

## DeltaMax Programmable Parameter Object

The DeltaMax Parameter object is programmable via macro instructions. This allows for unique application specific requirements to be accessed over the DeviceNet network as a parameter. Tools like DeviceNet Manager by Allen-Bradley may then easily upload the parameter instances displaying their value and text description for user friendly interface to the controllers MacroProgram. DeviceNet Manager also has the capability to then generate a DeviceNet EDS File (electronic data sheet) from the information obtained from a Parameter Object Instance.

The Parameter Object Instance attributes are defined by ODVA as follows:

Attribute Name (ID)	[Expected Values, Responses] Full Parameter Instance
Undefined (00)	[Attribute_Not_Supported (x14)]
Parameter_Value (01)	Depends on Attributes 5, 6
Link_Path_Size (02)	[USINT (0..255)]
Link_Path (03)	[PATH_ID[Link_Path_Size] see Note 1 below]
Descriptor (04)	[WORD (000000000xxxxxx)]
Data_Type (05)	[USINT (1..26)]
Data_Size (06)	[USINT (1..255)]
Parameter_Name_String (07)	[SHORT_STRING with max of 16 characters]
Units_String (08)	[SHORT_STRING with max of 4 characters]
Help_String (09)	[SHORT_STRING with max of 64 characters]
Minimum_Value (10)	[Same type as Parameter_Value (01)]
Maximum_Value (11)	[Same type as Parameter_Value (01)]
Default_Value (12)	[Same type as Parameter_Value (01)]
Scaling_Multiplier (13)	[UINT (1..65535)]
Scaling_Divisor (14)	[UINT (1..65535)]
Scaling_Base (15)	[UINT (0..65535)]
Scaling_Offset (16)	[INT (-32768..32767)]
Multiplier_Link (17)	[UINT (1..65535)]
Divisor_Link (18)	[UINT (1..65535)]
Base_Link (19)	[UINT (0..65535)]
Offset_Link (20)	[UINT (0..65535)]
Decimal_Precision (21)	[USINT (0..255)]
Undefined (22..99)	[Attribute_Not_Supported]

Parameters may be programmed for a Flag, Integer, or Float Object instances. Instances of the Flag, Integer and Float Objects are just variables declared in a MacroProgram. Once the variables are declared in a motion application program then the following MacroProgram instructions may be added to the program to generate a parameter object for DeviceNet Manager Tools:

**dnet\_flag\_pm**  
**dnet\_int\_pm**  
**dnetflt\_pm**

The instructions to program a parameter object must be contained within a **begin\_cfg** and **end\_cfg** instruction block, also a **begin\_cfg** instruction in a MacroProgram must be the first executable instruction in a program. The usage of the above instructions is defined in the MacroProgram Features section of this document, also refer to the example programs.

The **dnet\_range** instruction must be executed prior to a **dnet\_int\_pm** or **dnetflt\_pm** for any parameters to be any thing but **READ ONLY**. This also effects how parameters behave within any DeviceNet managing tools.

It is recommended that a parameter object be programmed into a DeltaMax prior to enabling the DeviceNet port. the DeviceNet port is enabled once a **can\_set** instruction is executed.

## I/O Connections

The DeltaMax has two possible static I/O instances of the Connection Object, see appendix A, one Polled (Instance 2) and one Bit-Strobed (Instance 3).

### Polled Connection

The DeltaMax will consume 3 bytes in a polled command. These three bytes will set or clear flag numbers 32 thru 55, instances 33 thru 56 resp., of the Flags Object as follows.

	Bit Numbers			Bit Numbers			Bit Numbers		
	7	BYTE 1	0	7	BYTE 2	0	7	BYTE 3	0
flag#	39		32	47		40	55		48

The DeltaMax will produce 2 bytes in the polled response, the bytes will contain the present condition of flag numbers 56 thru 71, instances 57 thru 72, of the Flags Object as follows.

	Bit Numbers			Bit Numbers		
	7	BYTE 1	0	7	BYTE 2	0
flag#	63		56	71		64

### Bit Strobed Connection

The DeltaMax shall produce only from a Bit-Strobed command. The response shall contain the present state of flag numbers 56 thru 71. The Data bytes in the response are identical to the Polled connection response as follows.

	Bit Numbers			Bit Numbers		
	7	BYTE 1	0	7	BYTE 2	0
flag#	63		56	71		64

**Important Note:** A Bit-Strobed connection when allocated requires the DeltaMax processor to listen to all Group 2 DeveNet traffic on the bus. Under normal bus conditions this should not be a significant burden, however it could possibly slow MacroProgram processing under very heavy DeviceNet traffic.

# MACROPRO II<sup>TM</sup>

FOR WINDOWS<sup>TM</sup>

Section 5 - Analyzer



INDUSTRIAL INDEXING SYSTEMS, INC.

**SECTION 5 - ANALYZER****Table of Contents**

<i>Analyzer Help</i>	5
<b>Parameters Difference Message</b>	5
<b>Parameters Difference Display</b>	5
<b>Keep Drive Parameters</b>	5
<b>Overwrite Drive Parameters</b>	5
<b>Stop and Reset Controller</b>	6
<b>Analyzer Tool Bar</b>	7
<b>Message Bar</b>	7
<b>Program in PC</b>	7
<b>Equality Indicator</b>	7
<b>Program in DeltaMax</b>	7
<i>File</i>	8
<b>New Program</b>	8
<b>Program Info</b>	9
<b>Exit</b>	9
<b>Previous Programs</b>	9
<i>Actions</i>	10
<b>Stop</b>	10
<b>Reset</b>	10
<b>Send</b>	11
<b>Run w/AutoStart</b>	11
<b>Send and Run</b>	11
<b>Run Only</b>	11
<b>Test Mode</b>	11
<i>Status</i>	12
<b>DeltaMax Info</b>	12
<b>Controller Selection</b>	13
<b>DeltaMax Program Information</b>	13
<b>Status Indicators</b>	13
<b>Flag Description</b>	13

<b>DeltaMax System Status</b>	<b>13</b>
<b>DeltaMax Identification</b>	<b>13</b>
<b>Close</b>	<b>13</b>
<b>Parameters Menu Item</b>	<b>14</b>
<b>Parameters</b>	<b>14</b>
<b>Resolver Cable Length</b>	<b>15</b>
<b>Home Position Shift</b>	<b>15</b>
<b>Torque Limit % Maximum</b>	<b>15</b>
<b>Brake On at % Rated Speed</b>	<b>15</b>
<b>CCW Drive Torque</b>	<b>15</b>
<b>CCW Absorption Torque</b>	<b>15</b>
<b>Drive_Package</b>	<b>15</b>
<b>Monitor Output</b>	<b>15</b>
<b>Brake Mode</b>	<b>16</b>
<b>Send Drive Parameters</b>	<b>16</b>
<b>Cancel Drive Parameters</b>	<b>16</b>
<i>Home Position</i>	<i>17</i>
<b>Home Position Description</b>	<b>17</b>
<b>Home Position Set</b>	<b>17</b>
<i>Auto Tune</i>	<i>18</i>
<b>Drive Auto Tune</b>	<b>19</b>
<b>Rotation Amount</b>	<b>19</b>
<b>Target Response</b>	<b>19</b>
<b>Maximum Speed</b>	<b>20</b>
<b>Start Autotune</b>	<b>20</b>
<i>AJ Parameters</i>	<i>21</i>
<b>AJ Parameter Modification</b>	<b>21</b>
<b>Load Inertia Magnification</b>	<b>22</b>
<b>High Speed Response</b>	<b>22</b>
<b>Position Gain</b>	<b>22</b>
<b>Gain Reduction</b>	<b>22</b>
<b>Feed Forward Gain</b>	<b>22</b>
<b>Current Command Filter</b>	<b>22</b>
<b>Change Values</b>	<b>22</b>

Cancel	22
<i>Read/Write</i>	23
Data And Flags	23
Writing Data	24
Writing Flags	24
Continuous Read	24
Refresh Button	24
Address Number Type	24
Add Data Name/Address	25
Add Flag Name/Number	25
Block Integer	25
Block Float	26
Line Up/Down Button	26
Page Up/Down Button	26
Decimal/Hex/ASCII Values Button	26
Starting Address Button	27
General Description	27
Clear List Button	27
Delete Item	27
Read/Write List	27
Use Button	27
Quick Find Option Box	27
<i>View</i>	28
Source	28
Equate Table	29
Label Table	29
Integer Constants Table	29
Float Constants Table	29
Integer Data Table	29
Float Data Table	29
Close	29
Search	30
Search String	30
Ignore Case	30

---

<b>Wrap at End</b>	<b>30</b>
<b>OK Button</b>	<b>30</b>
<b>Cancel Button</b>	<b>30</b>
<b>Goto Line #</b>	<b>30</b>
<b>Trace</b>	<b>31</b>
<b>Trace Window</b>	<b>31</b>
<b>Helpful Hints</b>	<b>32</b>
<b>Current Trace Type</b>	<b>32</b>
<b>Before Trace Type</b>	<b>32</b>
<b>About Trace Type</b>	<b>33</b>
<b>After Trace Type</b>	<b>33</b>
<b>Stop Trace</b>	<b>33</b>
<b>Close Command Button</b>	<b>33</b>
<b>Print Command Button</b>	<b>33</b>
<b>Reset Command Button</b>	<b>33</b>
<b>Start/Stop Trace Command Button</b>	<b>34</b>
<b>Trace Line</b>	<b>34</b>
<b>Enable Trace After Line</b>	<b>34</b>
<b>Valid Label Selection Window</b>	<b>35</b>
<b>Executable Source Line Labels</b>	<b>35</b>
<b>Read Trace</b>	<b>35</b>
<b>View Last Trace</b>	<b>35</b>
<b>Window Menu Item</b>	<b>36</b>
<b>Help Menu Item</b>	<b>36</b>
<b>Help</b>	<b>36</b>

## Analyzer Help

The MacroPro II Analyzer has many different features that allow you to analyze the operation of an Industrial Indexing Systems DeltaMax.

### Parameters Difference Message




Figure 4.1 - Parameters Difference Display

### Parameters Difference Display

This area displays the status of the ".par" (user parameters) file associated with the program in the PC as compared with the ".par" file currently stored in the drive.

### Keep Drive Parameters

Selecting this button will load the parameters from the drive into the ".par" file associated with the program currently in the PC.

### Overwrite Drive Parameters

This button will write the ".par" file associated with this program into the DeltaMax. This button will only be active if the program in the controller is stopped and reset. The controller needs to be loaded and started after this command is executed.

## Stop and Reset Controller

This button is only active if the controller is not reset. Stop and Reset will cease the program running in the DeltaMax, if one is running, and reset the DeltaMax. An **f\_decel** (forced deceleration) command is sent to the axis controller and the pseudo controller.

**NOTE:** When a Stop and Reset Controller is issued, the DeltaMax program memory is cleared, all flags are cleared, and any existing program is erased. Any Input modules treated as Output modules using MacroPro II will be reset as Inputs. Any Output modules treated as PLS modules in the program will be reset as Outputs.

## Analyzer Tool Bar



Figure 4.2 - Analyzer Menu, Tool, and Status Bars

## Message Bar

This line is where the Analyzer notifies the user about the status of a current operation.

## Program in PC

This is the name of the program that is currently in the PC.

## Equality Indicator

This indicator will either be an equals sign or an unequal sign. An equals sign indicates that the program in the PC is exactly the same as the program in the DeltaMax, whereas an unequal sign indicates that there is a difference between the two programs in the PC and the DeltaMax (date and time stamps are included in the comparison).

## Program in DeltaMax

This is the name of the program that is currently loaded in the DeltaMax.

## File

To access the File feature, use the [Alt + f] key combination or select File from the Menu Item Bar.




Figure 4.3 - Analyzer File Menu

## New Program



New Program will display the standard file open dialog. The default display will show all of the “.prg” source files in the selected directory. The only files that can be loaded into the Analyzer are the “.prg” files. The other associated files will be loaded automatically as required.





Figure 4.4 - New Program Sample Screen

**NOTE:** There are a number of associated files that must be present to allow full functionality of the Analyzer. These are: ".mcx" (the file that is loaded into the DeltaMax), ".dbg" (Analyzer information file), ".par" (user parameters), and ".sym" (symbol file, equates, labels, data, & constants).

## Program Info



Program Info will display file information about the “Source” and “Executable” file that is resident in your PC. This information includes the file name, size, date and time. It is important to understand that the program loaded into your PC may or may not be the same as the program loaded into the DeltaMax.



**Figure 4.5 - Program Info Sample Screen**

**NOTE:** To view information about the program loaded into your DeltaMax, use the DeltaMax Info function.

## Exit

Exit Analyzer will close all open Analyzer windows.

## Previous Programs

This section will allow the user to select a previously used program.

## Actions

To access the Actions feature, use the [Alt +a] combination or select Actions from the Menu Item Bar.




Figure 4.6 - Analyzer Actions Menu

### Stop



Stop will cease the program running in the DeltaMax, if one is running. An **f\_decel** (forced deceleration) command is sent to the axis controller and the pseudo controller. The F5 function key will also execute this operation.

### Reset



Reset will cause a reset of the DeltaMax. The current program must be stopped before a Reset is allowed. The F6 function key will also execute this operation.

**NOTE:** When a Reset is issued, the DeltaMax program memory is cleared, all flags are cleared, and any existing program is erased. Any Input modules treated as Output modules using MacroPro II will be reset as Inputs. Any Output modules treated as PLS modules in the program will be reset as Outputs.

## Send



Send will download the current program executable file (.mcx) from the PC to the DeltaMax. A Reset must be performed prior to using the Send function. The F7 function key will also execute this operation.

## Run w/AutoStart



Run w/AutoStart will turn on the AutoStart bit in the DeltaMax's status word. The DeltaMax will test its AutoStart bit on startup and, if set, the loaded program will start automatically. If the program is stopped, setting AutoStart will start the program in the DeltaMax in addition to setting the AutoStart bit. The F8 function key will execute this operation. The only way to clear the AutoStart is to issue a Reset.

## Send and Run

Send and Run will issue the **Stop**, **Reset**, **Send**, and **Run w/AutoStart** commands to the DeltaMax. The F9 function key will execute this operation.

## Run Only

Run will start or re-start the program currently resident in the DeltaMax. If a program is not loaded, this function has no effect on the DeltaMax.

## Test Mode

This function has not been implemented at the time this manual was written.

## Status

To access the Status feature, use the [Alt + s] key combination or select Status from the Menu Item Bar.




Figure 4.7 - Analyzer Status Menu

## DeltaMax Info



DeltaMax Info will display a window showing Program Information, the DeltaMax System Status, the part number of the DeltaMax Controller, and the Status Information for the selected controller. Pressing F2 will also execute this operation.




Figure 4.8 - DeltaMax Info Sample Screen

## Controller Selection

DeltaMax Controller Status will display a window showing the status information for a single controller. This includes the flag number of the 16 associated status flags for that controller as well as a description of each flag. Active Status flags are indicated as such by a check in the corresponding check box.

## DeltaMax Program Information

This section of the window indicates the name of the program resident on the DeltaMax along with the date and time that this program was compiled or created.

## Status Indicators

The left section of the window displays the number of the Status Flag along with a check box which indicates whether or not the listed flag is active.

## Flag Description

The right section of the window lists the Description of each Status Flag. The Flag Descriptions will change depending on the type of controller selected.

## DeltaMax System Status

This section of the window lists all System Status messages, such as “Program stopped” or “Program running”.

## DeltaMax Identification

This section of the window indicates the part number and revision of the firmware (operating system) used. The firmware part numbers are shown as SFONNNNRXX. “SFO” stands for System Functional Operation, “NNNN” is a number from 0000 to 9999 and “XX” is a revision ranging from 00 to 99.

## Close

Clicking on this selection will close the DeltaMax Information window.

## Parameters Menu Item

To access the Status feature, use the [Alt + p] key combination or select Parameters from the Menu Item Bar.




Figure 4.9 - Analyzer Parameters Menu

## Parameters



Parameters will display a window showing the status of the current drive parameters and allow these values to be edited.




Figure 4.10 - Parameters Sample Screen

## Resolver Cable Length

Sets the driver resolver cable length compensation. The driver power must be cycled to register this value. The range of acceptable values is from 3 to 394 feet.

## Home Position Shift

The resolver zero can be shifted from the mechanical motor shaft position using Home Position Shift. This position can be shifted 2047 bits.

## Torque Limit % Maximum

When the torque limit is applied the motor torque is limited by the Torque Limit % Maximum. This value is the % of motor peak torque and can range from 0 to 100%. When this value is set to 0 the selections for CCW Drive Torque, CW Drive Torque, CCW Absorption Torque and CW Absorption Torque become available.

## Brake On at % Rated Speed

When Brake Mode is set up for Holding Brake (with soft deceleration), the mechanical holding brake is applied when the motor speed falls below this percentage. The deceleration is controlled at the set deceleration rate. Brake On at % Rated Speed is scaled in % of rated speed.

## CCW Drive Torque

This value limits the CCW rotation torque. The range is 0 to 100% with 100% being the Peak Torque. This parameter becomes available when the Torque Limit % Maximum is set to 0.

## CCW Absorption Torque

This value limits the CCW rotation absorption (braking) torque. The range is 0 to 100% with 100% being the Peak Torque. This parameter becomes available when the Torque Limit % Maximum is set to 0.

## Drive\_Package

The Drive Package parameter sets the internal driver parameters corresponding to the Drive Package. The driver power must be cycled to register this parameter.

## Monitor Output

The Monitor Output selects the type of signal that is sent to the external MON output pins on the driver. The signal can either be speed or torque and normal or inverted.

## **Brake Mode**

Selects the type of brake sequencing to be done when the drive is turned off. Dynamic Brake is used when no brake is installed. After the drive is turned off The Holding Brake (with soft deceleration) is applied after controlled deceleration to the speed set by the Brake On at % Rated Speed and is applied immediately in the case of a fault. Holding Brake (no soft deceleration) is applied immediately after the drive is turned off.

## **Send Drive Parameters**

Send will load the currently displayed parameters into the controller. The program must be stopped and reset before the new parameters can be written to the drive.


## **Cancel Drive Parameters**

The Cancel button will exit the Drive Parameters menu without sending the drive information to the controller.

## Home Position



Click on an item below for help on that particular selection:



**Figure 4.11 - Home Position Set Screen**

## Home Position Description

Home Position Set will display a window that will allow the user to set the absolute home position any time. The Tool Bar button will execute this operation.

## Home Position Set

Sets the absolute zero position, clears all the turns and angle. The '**Clear Rotation & Angle**' needs to be selected and the '**Set Home**' needs to be pushed for this to take effect. If '**No Effect**' is chosen nothing will happen. '**Cancel**' will cancel the operation.

## Auto Tune

Click on an item below for help on that particular selection.

*Note:* The user can start auto tuning after clearing the warning.




Figure 4.12 - Drive Auto Tune Screen

## Drive Auto Tune

The following display allows the user to auto tune the drive by entering the desired values. At the end of the auto tuning sequence, AJ2, AJ3 and AJ4 will be set automatically and the values will be displayed under 'Drive Adjustment Values'.

Click on an item below for help on that particular selection.

----- Changed -----	
From	To
Load Inertia Magnification (AJ2)	1.6
High Speed Response (AJ3)	0.9
Position Gain (AJ4)	62

Figure 4.12a - Drive Auto Tune Screen

### Rotation Amount

Sets the amount of the reciprocal rotation during the auto tuning sequence.

**Valid Range:** 1 to 300 revs

### Target Response

Sets the desired frequency response. If this value is too high, unstable operation may result.

**Valid Range:** 1 to 1000 Hz

## Maximum Speed

Sets the speed of the reciprocal rotation during the auto tune sequence.

*Valid Range:* 1 to 4000 rpm

## Start Autotune

This starts the auto tune sequence.

## AJ Parameters

Click on an item below for help on that particular selection.

*Note:* The user can modify the AJ parameters after clearing the warning.




Figure 4.13 - AJ Parameters Screen

## AJ Parameter Modification

This display allows the user to change the AJ parameters in the drive. Click on an item below for help on that particular selection.




Figure 4.13a - AJ Parameters Screen

## Load Inertia Magnification

Sets the baseline frequency response of the driver using the ratio of the load inertia/motor inertia for a rigidly coupled load. If the value is set too high, the motor and driver may become unstable and oscillate. This parameter is set automatically during auto tuning.

## High Speed Response

Sets the high frequency response of the driver. The higher the number the more responsive. If the value is set too high, the motor and driver may become unstable and oscillate. This parameter is set automatically during auto tuning.

## Position Gain

Sets the DC gain of the position control loop. The higher this value the more stiffer and faster the response. If the value is set too high, the motor and driver may become unstable and oscillate. This parameter is set automatically during auto tuning.

## Gain Reduction

Sets the amount of gain reduction at zero speed.

## Feed Forward Gain

Sets the feed forward gain in the position loop. A value of 1.0 results in 0.0 following error. Less than 1.0 will produce a lag between the actual motor position and the commanded position. A value greater than 1.0 produces a lead. The lead or lag will be proportional to speed for settings different from 1.0.

## Current Command Filter

Sets the notch frequency of a velocity loop anti-resonance filter. This filter can be used to cancel machine or servo resonance.

*Power must be turned OFF then ON for this parameter to take effect.*

## Change Values

Changes the AJ parameters to the values set by the user.

## Cancel

The Cancel button will end the current operation.

## Read/Write

To access the File feature, use the [Alt + r] key combination or select File from the Menu Item Bar.




Figure 4.14 - Analyzer Read/Write Menu

## Data And Flags



This window is used for reading individual data and/or flags from the DeltaMax and also for writing data and/or flags to the DeltaMax. Pressing F4 will also execute this operation.

**NOTE:** When reading cam information(arrays), displaying in hexadecimal format is recommended, which can be accomplished in the Block Integer section.




Figure 4.15 - Read/Write Sample Screen (Data and Flags)

## Writing Data

To write data, click on the value of the data to write. Type in the value, in decimal only, and hit the 'Enter' key to write the value. By simply typing in a new value and hitting the 'Enter' key, another write will be performed.

## Writing Flags

To change the state of a flag, double-click on the flag state. This will toggle the state of the flag. Timers and Status flags are read-only.

**NOTE:** Changing the state of an I/O flag from this window assigns that flag as an output flag and will no longer respond to an external input.

## Continuous Read

Checking this item will start reading the selected data and/or flags from the DeltaMax and the headings are colored blue and names, values, etc. are black. When this item is not checked, the "Refresh" button appears and the continuous reading effect is turned off. Also, the headings and the values are colored red. The state of this button does not effect data/flag writes, they operate as normal when continuous read is on or off.

**NOTE:** If "Data and Flags", "Block Integer", or "Block Float" are set for reading, they only read when they are the active tab.

## Refresh Button

Clicking this button will force a read of the read/write list. This button is visible only when the Continuous Read check box is not checked.

## Address Number Type

When adding an address number to the read/write list, this specifies which data type it represents.

## Add Data Name/Address

Type in (or select from the list) a data name or address to add to the read/write list. If it is an array name, put the element number in square brackets. If it is an address number, the address must be greater than or equal to zero and also divisible by 4 for integers (8 for floating point addresses). For the Data/Flags tab, the address number type can be specified by clicking on the appropriate option button in the Addr # Type frame.

## Add Flag Name/Number

Type in (or select from the list) a flag name or flag number to add to the read/write list. If it is a flag number, it must be between 0 and 255. Flag names in the list starting with an underscore (“\_”) prefix are the predefined flags.

## Block Integer



This window is used for reading blocks of integer data from the DeltaMax and also for writing integer data to the DeltaMax.

**NOTE:** When reading cam information(arrays), displaying in hexadecimal format is recommended.




Figure 4.16 - Read/Write Sample Screen (Block Integer)

## Block Float



This window is used for reading blocks of floating point data from the DeltaMax and also for writing floating point data to the DeltaMax. The Tool Bar button will execute this operation.




Figure 4.17 - Read/Write Sample Screen (Block Float)

### Line Up/Down Button

Clicking this button increments or decrements the starting address by one data address.

### Page Up/Down Button

Clicking this button increments or decrements the starting address by one block of 10 data addresses.

### Decimal/Hex/ASCII Values Button

Toggling this button displays data in either decimal, hexadecimal, or ASCII format.

## Starting Address Button

Click this button to change the starting address of the block of 10 data items. At the prompt enter a data label name or an address number. For array elements, enter the name followed by the element number enclosed in square brackets. For example, to enter a starting address of the 3rd element in the array named *Cam*; simply enter *Cam[2]* (since arrays are zero based).

## General Description

The Data & Flag List window is used to make up a list of data and flags to read/write. A maximum of 10 items can be used and may be any combination of data and/or flags. The Select Data list box is a list of variables defined in the current program (Source) and can be added to the read/write list.

Double-click on the data item to be added or select the item and then click the Add button.

## Clear List Button

All items (data and/or flags) in the read/write list will be removed.

## Delete Item

The selected data or flag will be removed from the read/write list. The selected item is that where the name, not value, is highlighted. Double-clicking the item will also delete it.

## Read/Write List

Double-clicking an item will remove it from the list. Highlighting an item here activates the delete item button.

## Use Button

Clicking this button will minimize the Data & Flags List window, show the Read/Write **Data and Flags** window and begin reading the items from the read/write list.

## Quick Find Option Box

The Quick Find Option box will allow you to quickly select a predefined group of flags. Flags range from #0 to #255.

## View

To access the File feature, use the [Alt + v] key combination or select File from the Menu Item Bar.




Figure 4.18 - Analyzer View Menu

## Source



Source will display the Source for the program currently resident in the PC. Various controls allow you to view any or all program Source lines as needed. The F11 function key will also execute this operation.




Figure 4.19 - View Sample Screen

## Equate Table

Equate Table will move the file display pointer to the section in the symbol file (.sym) for the program currently resident in the PC, where all labels that were equated (using the **equ** instruction in the program) are listed. Various controls allow you to view any or all of the symbol file (.sym) as needed.

## Label Table

Label Table will move the file display pointer to the section in the symbol file (.sym) for the program currently resident in the PC, where all program Labels are listed. Various controls allow you to view any or all of the symbol file (.sym) as needed.

## Integer Constants Table

Integer Constants Table will move the file display pointer to the section in the symbol file (.sym) for the program currently resident in the PC, where all Integer Constants used in the program are listed. Various controls allow you to view any or all of the symbol file (.sym) as needed.

## Float Constants Table

Float Constants Table will move the file display pointer to the section in the symbol file (.sym) for the program currently resident in the PC, where all Floating Point Constants used in the program are listed. Various controls allow you to view any or all of the symbol file (.sym) as needed.

## Integer Data Table

Integer Data Table will move the file display pointer to the section in the symbol file (.sym) for the program currently resident in the PC, where all program Integer Data are listed. Various controls allow you to view any or all of the symbol file (.sym) as needed.

## Float Data Table

Float Data Table will move the file display pointer to the section in the symbol file (.sym) for the program currently resident in the PC, where all program Floating Point Data are listed. Various controls allow you to view any or all of the symbol file (.sym) as needed.

## Close

Close will exit the View window.

## Search

Search allows you to find a designated text string within the file being viewed. A list of strings previously searched is maintained for easier viewing. Like most Search or find functions, the F3 key will search for the next occurrence of the entered string.




Figure 4.20 - Search Window

### Search String

Enter the String to be searched, keeping in mind the Case option selected. A list of strings previously searched is maintained for easier viewing. Use the scroll bar to search on other strings as needed.

### Ignore Case

When Ignore Case is checked, strings will be compared and the match will be made regardless of the case entered in the Search String *or* the file being searched.

### Wrap at End

Wrap at End will cause the search to continue at the beginning of a file, when an end-of-file is encountered.

### OK Button

Pressing the OK Button will cause the search for the selected/entered string to begin from the current file location.

### Cancel Button

The Cancel Button will end the search and resume viewing the file.

### Goto Line #

Goto Line # lets you position to a specific line within the file being viewed. The range of allowable lines is listed.

## Trace



The Trace feature allows you to follow the program execution without affecting the operation of the program.

To access the Trace feature, use the [Alt + t] key combination to access the Trace menu bar item.




Figure 4.21 - Trace Menu Bar

## Trace Window

The Trace feature is closely linked with the source file so that when the Trace window is opened, the Source view window is also opened. If the Source view window is already open, it may be re-sized so that the Trace and Source windows are equal in size.




Figure 4.22 - Trace Window

The Trace Feature has the ability to capture up to 112 lines of program execution. This is not to say that each time the Trace is run that you should see 112 lines. The trace type, trace events, and program will effect the number of lines displayed after a successful trace.

After a successful trace, the “Settings” window will roll-up to show the full trace listing. The trace listing shows the Trc. # (trace number) in the first column. This trace number indicates the order in which a program line was executed. A negative number indicates lines executed before the trace line. The trace line numbered zero is the line that was specified as the line to trace on. Positive numbered lines are lines that were executed after the trace line was executed. The next column in the trace listing is the source program line number (Line #). The remaining columns are the actual source text for the associated line numbers.

There are two items in the menu bar Trace pull down box that are not available in the Trace window. These are Read Trace, and View Last Trace.

## Helpful Hints

Clicking on a line in the Source window will automatically set the **Trace Line** or **Enable Trace After Line**. Repeated clicking on lines in the Source window will reset these trace events.

Highlighting a line in the Trace window will display the associated line in the Source window.

Entering any text string in the Trace Line or Enable Trace After Line entry boxes will bring up a **Valid Label Selection** window. This window will list all labels in the program that can be used as a trace parameter .

## Current Trace Type

The Current trace type will initiate the Trace process regardless of the settings for **Trace Line**, and **Enable Trace After Line**. This trace type is useful when trying to determine if the program is running and what part of the program is being executed.

## Before Trace Type

The Before trace type will allow you to see which lines are being executed before a particular program line. You must enter a **Trace Line** parameter to enable a trace of this type. The **Enable Trace After Line** is optional but will have an effect on the number of trace lines that might be displayed. The maximum number of lines that could be displayed before the “trace line” would be 112, with the trace line being Trc. # 0.

## About Trace Type

The About trace type will allow you to see which lines are being executed before and after a specified program line. You must enter a **Trace Line** parameter to enable a trace of this type. The **Enable Trace After Line** is optional but will have an effect on the number of trace lines that might be displayed before the actual trace line. The maximum number of lines that could be displayed before the “trace line” would be 57 (negative Trc. #'s), with the trace line being Trc. # 0. The maximum number of trace lines that would be displayed after the trace line would be 55 (positive Trc. #'s).

## After Trace Type

The After trace type will allow you to see which lines are being executed after a particular program line. You must enter a **Trace Line** parameter to enable a trace of this type. The **Enable Trace After Line** is optional. Your program will have an effect on the number of trace lines that might be displayed. The maximum number of lines that could be displayed after the “trace line” would be 112, with the trace line being Trc. # 0.

## Stop Trace

This menu item will stop the currently active trace.

## Close Command Button

The Close command button will stop any active trace events, then close the trace window.

## Print Command Button

The Print command button will allow you to print the contents of the trace listing to your MS Windows print driver. This print uses the default settings that were last set with the Microsoft Windows Print Manager. It is recommended that you select a fixed space font (such as Courier), to give you the proper column alignment on the print out.

## Reset Command Button

The Reset command button will stop any active trace and reset the **Trace Line** and **Enable Trace After Line** parameters.

## Start/Stop Trace Command Button

The Start/Stop trace command button will initiate the trace process based on the settings listed in the “Settings” window, or stop an active trace. When a trace is active the “Trace Active” message panel will flash next to the Start/Stop trace command button, as shown the following figure.




Figure 4.23 - “Trace Active” Panel (next to Start/Stop Command Button)

## Trace Line

### Purpose:

The Trace Line entry specifies what is the focal point of the trace process. This entry identifies the line that triggers a trace in the DeltaMax. This parameter is required when using the **Before**, **About** and **After** trace types.

### Entry method:

The Trace Line entry box accepts either a source line number or an **Executable Source Line Labels**. Checks are made on the validity of those entries. To enter a line number you can enter the number manually in the box or you can click on a line in the Source window. When you click on a line in the Source window the associated line number will be automatically entered into the entry box. To enter a label you must enter the alpha string into the box manually. If an invalid label was entered a **Valid Label Selection Window** will be displayed to allow you to change your label selection.

## Enable Trace After Line

### Purpose:

The Enable Trace After Line entry specifies the DeltaMax when to enable tracing. Only AFTER this line has been executed, will the DeltaMax start to look for the **Trace Line**.

### Entry method:

The Trace Line entry box accepts either a source line number or an **Executable Source Line Label**. Checks are made on the validity of those entries. To enter a line number you can enter the number manually in the box or you can click on a line in the Source window. When you click on a line in the Source window the associated line number will be automatically entered into the entry box. To enter a label you must enter the alpha string into the box manually. If an invalid label was entered a **Valid Label Selection Window** will be displayed to allow you to change your label selection.

## Valid Label Selection Window

The following figure shows the Valid Label Selection window that would be displayed if an invalid label entry was entered into the **Trace Line** and **Enable Trace After Line** entry boxes. Valid labels are **Executable Source Line Labels**.

### Entry method:

You can type in a label that is shown on the list and then click on Accept. You can also double click on the label of choice.




Figure 4.24 - Valid Label Selection Window

## Executable Source Line Labels

This is a label that is tied to a line in the program that will be executed when the program runs. Labels for equates or data are not considered executable labels.

## Read Trace

This menu item is not available on the Trace window.

In some cases a trace might not complete as expected. In the event this happens, but you still want to see what is currently in the DeltaMax's trace memory, select Read Trace. This feature will stop the active trace then access the current state of the trace memory in the DeltaMax. For this feature the trace "Settings" are ignored.

## View Last Trace

This menu item is not available on the Trace window.

This feature will open the Trace window if not already open and display the last trace results.

## Window Menu Item

To access the Window feature, use the [Alt + w] key combination or select Window from the Menu Item Bar. The windows that are currently open and which one is active will be displayed here. A selection to cascade the windows or to select which window is currently active can be made.




Figure 4.25 - Window Menu

## Help Menu Item

To access the Help feature, use the [Alt + h] key combination or select Help from the Menu Item Bar. From this menu a selection to the desired help section can be made.




Figure 4.26 - Help Menu

## Help



Help gives you access to the Help facility for the Analyzer. The F1 function key will execute this operation. Help for the window that is currently active in the analyzer will be displayed.

# MACROPRO II<sup>TM</sup>

FOR WINDOWS<sup>TM</sup>

Section 6 - Instruction Reference  
& Examples



INDUSTRIAL INDEXING SYSTEMS, INC.

## SECTION 6 - INSTRUCTION REFERENCE

## Table of Contents (Instructions)

<b>Instruction</b>	<b>Page</b>
<i>Type Allowed</i>	7
<i>analog_in</i>	8
<i>analog_out</i>	9
<i>analog_rt</i>	10
<i>analog_zo</i>	11
<i>begin_cam</i>	12
<i>begin_cfg</i>	13
<i>begin_data</i>	14
<i>blk_io_in</i>	15
<i>blk_io_out</i>	16
<i>calc_cam_sum</i>	17
<i>calc_unit_cam</i>	18
<i>cam</i>	19
<i>cam_data</i>	20
<i>can_set</i>	22
<i>case</i>	23
<i>clr_all_swi</i>	24
<i>clr_bit</i>	25
<i>clr_dnet</i>	26
<i>clr_flag</i>	27
<i>clr_local</i>	28
<i>clr_pls</i>	29
<i>clr_swi</i>	30
<i>clr_sys_error</i>	30
<i>data</i>	32
<i>data_scale</i>	33
<i>declare</i>	34
<i>default</i>	35
<i>delta_comp</i>	36

<i>digi_comp</i>	37
<i>dim</i>	38
<i>disable_hwi</i>	39
<i>disable_swi</i>	40
<i>dnet_flag_pm</i>	41
<i>dnetflt_pm</i>	42
<i>dnet_int_pm</i>	43
<i>dnet_p_code</i>	44
<i>dnet_range</i>	45
<i>drive_off</i>	46
<i>drive_on</i>	47
<i>enable_hwi</i>	48
<i>enable_swi</i>	50
<i>end_cam</i>	51
<i>end_cfg</i>	52
<i>end_data</i>	53
<i>end_select</i>	54
<i>equ</i>	55
<i>exec_profile</i>	56
<i>exit_select</i>	57
<i>float</i>	58
<i>float_dim</i>	59
<i>f_decel</i>	60
<i>get_act_spd</i>	61
<i>get_angle</i>	62
<i>get_cam_cnt</i>	63
<i>get_cam_end</i>	64
<i>get_cam_ptr</i>	65
<i>get_cam_strt</i>	66
<i>get_cam_sum</i>	67
<i>get_com</i>	68
<i>get_fol_err</i>	69
<i>get_for_ang</i>	70

<i>get_for_spd</i>	71
<i>get_map</i>	72
<i>get_map_stat</i>	73
<i>get_mcf</i>	74
<i>get_mcf_stat</i>	75
<i>get_ms_time</i>	76
<i>get_pls_ang</i>	77
<i>get_pls_mask</i>	78
<i>get_pls_out</i>	79
<i>get_pos</i>	80
<i>get_pstat</i>	81
<i>get_time</i>	82
<i>get_trap_pos</i>	83
<i>gosub</i>	84
<i>goto</i>	85
<i>if</i>	86
<i>if_bit_clr</i>	87
<i>if_bit_set</i>	88
<i>if_char</i>	89
<i>if_dnet_off</i>	90
<i>if_dnet_on</i>	91
<i>if_flag_off</i>	92
<i>if_flag_on</i>	93
<i>if_io_off</i>	94
<i>if_io_on</i>	95
<i>if_no_char</i>	96
<i>if_stat_on</i>	97
<i>if_stat_off</i>	98
<i>if_tmr_off</i>	99
<i>if_tmr_on</i>	100
<i>incr_com</i>	101
<i>index</i>	102
<i>input</i>	103

<i>integer</i>	104
<i>jog_ccw</i>	105
<i>jog_cw</i>	106
<i>l_track_spd</i>	107
<i>let</i>	108
<i>let_byte</i>	110
<i>lock</i>	111
<i>master_scale</i>	116
<i>mod_index</i>	117
<i>mod_position</i>	119
<i>no_op</i>	121
<i>offset_master</i>	122
<i>over_draw</i>	123
<i>port_set</i>	125
<i>position</i>	127
<i>prep_profile</i>	128
<i>preset</i>	129
<i>print</i>	130
<i>print_num</i>	131
<i>ratio</i>	132
<i>read_offset</i>	133
<i>restart_at</i>	134
<i>return_sub</i>	135
<i>select</i>	136
<i>set_ac_dc</i>	137
<i>set_bit</i>	138
<i>set_cam_ptr</i>	139
<i>set_dnet</i>	140
<i>set_flag</i>	141
<i>set_gl_ccw</i>	142
<i>set_gl_cw</i>	143
<i>set_local</i>	144
<i>set_map</i>	145

---

<i>set_mcf</i>	146
<i>set_ms_tmr</i>	147
<i>set_offset</i>	148
<i>set_ovd_mode</i>	149
<i>set_pls_ang</i>	150
<i>set_pls_cnt</i>	151
<i>set_pls_mask</i>	152
<i>set_speed</i>	153
<i>set_swi_mask</i>	154
<i>set_tmr</i>	155
<i>set_trig_cam</i>	156
<i>set_trig_pw</i>	157
<i>stop_input</i>	158
<i>swi_if_off</i>	159
<i>swi_if_on</i>	160
<i>switch_cam</i>	161
<i>sys_fault</i>	164
<i>sys_return</i>	165
<i>text</i>	166
<i>track_spd</i>	167
<i>trap_pos</i>	168
<i>turn_off</i>	169
<i>turn_on</i>	170
<i>unlock</i>	171
<i>vel_ccw</i>	172
<i>vel_cw</i>	173

## Table of Contents (Examples)

<b>Example</b>	<b>Page</b>
<i>Analog Functions</i>	174
<i>CAMS with switch_cam</i>	177
<i>Clock Simulation</i>	185
<i>DeviceNet without Parameter Object</i>	188
<i>DeviceNet with Parameter Object</i>	191
<i>Home Sequence</i>	194
<i>Index with over_draw</i>	201
<i>Programmable Limit Switch Functions</i>	206
<i>Piecewise Profile</i>	212
<i>Ratio Lock</i>	218
<i>CAMS with calc_unit_cam</i>	223
<i>I/O Functions</i>	229
<i>Offset Methods</i>	233
<i>Clear Software Interrupts</i>	240
<i>Operator Interface</i>	244
<i>Floating Point Numbers</i>	253

**Type Allowed**

<b><u>Abbreviation</u></b>	<b><u>Definition</u></b>
A	Address Label
FC	Float Constant
FE	Float Equate
FV	Float Variable
IC	Integer Constant
IE	Integer Equate
IV	Integer Variable
T	Text

**analog\_in****SYNTAX:**

*label* analog\_in controller#,channel#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	Analog controller number	3	IE, IC
channel#	Input channel number	1 to 2.	IE, IC
value	A value containing the analog reading from the specified input channel number	-1023 to +2046	IV

**DESCRIPTION:**

Perform a read from the specified channel of the analog controller. The data is placed in 'value' after it is modified based on the channel's current slew rate limit and offset parameters. The modified data will have a range of -1024 to +2046 which is equivalent to 0 VDC to +5 VDC when the offset is 0.

The value read may be delayed up to 11 milliseconds due to access time through the update loop.

**RETURNS:**

Returns the current reading of the specified analog input channel plus any currently set offset value and limited by current slew rate setting.

**analog\_out****SYNTAX:**

*label* analog\_out controller#,channel#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	3	IE, IC
channel#	Channel to be used.	3	IE, IC
value	Value to output.	0 to 1023	IE, IC, IV

**DESCRIPTION:**

Modify the output value by the specified channel's current slew rate limit and offset parameters and then write to the specified channel. The specified channel update may be delayed for as long as 11 milliseconds due to the access time of the control loop.

Executing the **f\_decel** macro instruction will slew the output channel to 0 volts.

The modified output data will have a range from 0 to +1023 which is equivalent to 0 VDC to +5 VDC. If an added offset would modify an **analog\_out** outside, the output range is ignored.

Outputs are initialized to 0.0 volts on power-up. The analog output channel will slew to 0.0 volts when the program is stopped by the Analyzer.

**RETURNS:**

None.

**analog\_rt****SYNTAX:**

*label* analog\_rt controller#,channel#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	3	IE, IC
channel#	Channel to be used.	1 to 3	IE, IC
value	The slew rate limit.	0 to 1023	IE, IC, IV

**DESCRIPTION:**

Sets the specified channel slew rate limit in bits per 10 milliseconds. The slew rate value limits the rate at which a particular channel (input or output) can change. A slew rate of 1 is equivalent to a rate of change of 4.88 mV per 10 milliseconds.

**RETURNS:**

None.

**analog\_zo****SYNTAX:**

*label* analog\_zo controller#,channel#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	3	IE, IC
channel#	Channel to be used.	1 to 3	IE, IC
value	Offset value.	-1023 to +1023	IE, IC, IV

**DESCRIPTION:**

Sets the specified channel offset value in 4.88 millivolts per bit. Offset value is cleared on power-up. The analog output channel will slew to 0.0 volts when the program is stopped by the Analyzer. Zero offset values are cleared on power-up.

**RETURNS:**

None.

## **begin\_cam**

### **SYNTAX:**

*label* begin\_cam

### **PARAMETERS:**

None.

### **DESCRIPTION:**

Signals the start of a cam data area which will contain 8 bit (1 byte) values which represent incremental cam data. Each **begin\_cam** instruction must have a corresponding **end\_cam** instruction.

This instruction requires a 'label'.

### EXAMPLE

cam_array	begin_cam	
	cam	1,2,3,4,5
	cam	6,6,6,6,6
	cam	5,4,3,2,1
	end_cam	

### **RETURNS:**

None.

**begin\_cfg****SYNTAX:**

*label* begin\_cfg

**PARAMETERS:**

None

**DESCRIPTION:**

This is a directive to the MacroPro II™ Compiler.

The directive informs the compiler and eventually the Deltamax Operating System, that the following commands up to the end\_cfg directive, are to be executed immediately following a program download to the DeltaMax.

**RETURNS:**

None.

**begin\_data****SYNTAX:**

*label* begin\_data

**PARAMETERS:**

None.

**DESCRIPTION:**

Signals the beginning of a data area which will contain 32-bit (4 byte) values.

This instruction requires a 'label'.

**EXAMPLE**

profile	begin_data	
	data	100,200,15*4096
	data	0,200,40*4096
	end_data	

**RETURNS:**

None.

**blk\_io\_in****SYNTAX:**

*label* blk\_io\_in                    input\_flag#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
input_flag#	Starting flag number to read. Must be a multiple of 8.	0 or 8	IE, IC
value	Value of I/O flags to be read.		IV

**DESCRIPTION:**

The first eight bits in 'value' are used to store the state of the I/O modules, starting with 'input\_flag#'.

EXAMPLE

If 'value' = 3, the first two inputs are ON.

If 'value' = 255, all eight input modules are ON.

**RETURNS:**

A four byte value with the LS byte representing the ON and OFF states of the eight I/O read.  
(Bit ON, I/O is ON)

**blk\_io\_out****SYNTAX:**

*label* blk\_io\_out                    output\_flag#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
output_flag#	Starting flag number to modify.	16	IE, IC
value	Value of I/O flags to set.		IE, IC, IV

**DESCRIPTION:**

The first eight bits in 'value' are used to set or clear the eight outputs.

EXAMPLE

If 'value' = 3, the first two output modules will be turned ON.

If 'value' = 255, all eight output modules will be turned ON.

**RETURNS:**

None.

**calc\_cam\_sum****SYNTAX:**

*label* calc\_cam\_sum controller#,starting element,ending element

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id #	1	IE, IC
starting element	Element # relative to axis memory zero.		IE, IC, IV
ending element	Element # relative to axis memory zero.		IE, IC, IV

**DESCRIPTION:**

Sums the values of cam elements in axis controller memory starting with 'starting element' and including 'ending element'. The starting and ending element numbers are relative to axis controller memory location zero.

The axis status flag **CALCULATION IN PROGRESS** will be ON until calculations are complete.

The calculated sum can be retrieved using the **get\_cam\_sum** instruction.

**RETURNS:**

None.

**calc\_unit\_cam****SYNTAX:**

*label* calc\_unit\_cam controller#,distance, # of elements, starting element

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
distance	Total distance of the cam in bits.		IE, IC, IV
# of elements	Number of elements which make up the cam.		IE, IC, IV
starting element	The first element of the cam. This element is relative to axis memory location zero.		IE, IC,IV

**DESCRIPTION:**

Allows the user to define the shape of a cam and to have the axis controller calculate the cam data array. A table of co-efficients must first be transmitted, using the 'let' instruction, into the axis controller memory block, beginning at byte address 27,000. This table must be 130 elements in length.

The 'calc\_unit\_cam' instruction will then provide the total cam distance, the number of elements in the cam and the starting element for the cam (relative to axis memory location zero).

**RETURNS:**

None.

**cam****SYNTAX:**

*label* cam value,value,etc.

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>
value	Incremental cam value.	-127 to +127

**DESCRIPTION:**

Specifies one-byte incremental values for an electronic cam.

Expressions are allowed. More than one cam value may be contained in a **cam** statement. By placing the **end\_cam** statement at the end of the cam table, a cam table terminator (128) is automatically generated.

EXAMPLE

```
cam_array  begin_cam
           cam      1,2,3,4,5,6,7,8,9,10
           cam      10,10,10,10,10,10,10
           cam      10,9,8,7,6,5,4,3,2,1
           end_cam
```

**RETURNS:**

None.

**cam\_data****SYNTAX:**

*label* cam\_data controller#,data\_label,master\_scale,data\_scale

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
data_label	Program label of the cam data.		T
master_scale	Number of times to right shift the master position as it is received by the controller.	0 to 12	IE, IC
	<u>Master Scale Factor</u>	<u>Cam array advances every</u>	
	12	1 full turn	
	11	1/2 turn	
	10	1/4 turn	
	9	1/8 turn	
	8	1/16 turn	
	7	1/32 turn	
	6	1/64 turn	
	5	1/128 turn	
	4	1/256 turn	
	3	1/512 turn	
	2	1/1024 turn	
	1	1/2048 turn	
	0	1/4096 turn	
data_scale	Number of times to left shift each data element.	0 to 7	IE, IC

**DESCRIPTION:**

The **cam\_data** instruction provides the controller with its' master scale, data scale and cam data array location.

When 'data\_label' is dimensioned to reside within program memory, this instruction will also transfer the data array associated with 'data\_label' to the controller.

When 'data\_label' is dimensioned to reside directly on the volatile memory of the axis controller, no transfer of data will occur. Data can be transferred to the controller memory using the **let** or **let\_byte** instructions before and/or after the **cam\_data** instruction has been issued. This instruction then serves as a pointer to that data array. More than 1 data array can be dimensioned for the controller.

**RETURNS:**

None.

**can\_set****SYNTAX**

*label* can\_set arg1,arg2,arg3

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
arg1	DeviceNet ID	0 to 63, -1	IV, IC
arg2	DeviceNet Baudrate in kbaud	125,250,500, -1	IV, IC
arg3	Protocol setting	2	IV, IC

**DESCRIPTION:**

Configures the DeviceNet MacID and Baudrate.

If arg1 and/or arg2 are set to -1 then that DeviceNet parameter may be set over the DeviceNet network. The DeltaMax may then be configured by a software tool such as DeviceNet Manager by Allen-Bradley. Once the parameter is configured it is stored in Nonvolatile memory so that it is remembered by the controller from one powerup to the next.

The DeviceNet ID and Baudrate may be set back to the default values of 63 and 125Kbaud respectively, by RESETTING the DeltaMax thru the MACROPRO\_II Analyzer then cycling power to the unit.

A can\_set executed after a CanBus fault flag (flag# 129) will attempt to clear the fault and bus-off condition so that communications may continue.

**RETURNS:**

None.

**case****SYNTAX**

*label* case num

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
num	An integer value.	-32768 to 32767	IC

**DESCRIPTION:**

Used with the **select** instruction to designate a branch address. Each **case** value must be unique.

EXAMPLE

```

select      num
  case 1
  .
  .
  exit_select

  case 2
  .
  .
  exit_select

  default
  .
  .
  exit_select

end_select

```

**RETURNS:**

None.

## **clr\_all\_swi**

### **SYNTAX:**

*label* clr\_all\_swi

### **PARAMETERS:**

None.

### **DESCRIPTION:**

Disables and clears all 32 (0 through 31) software interrupts.

### **RETURNS:**

None.

**clr\_bit****SYNTAX:**

*label* clr\_bit                      bit#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
bit#	Number of the bit within the 4-byte value to be cleared to off (logic 0).	0 to 31	IE, IC, IV
value	The 4-byte area in memory affected by this instruction.		IV

**DESCRIPTION:**

The specified bit will be cleared (logic 0). If that bit has been previously cleared, it will remain cleared. If that bit was previously set (logic 1), it will now be cleared.

This instruction has no effect on the remaining bits of this 4-byte value.

This instruction will be ignored if 'bit#' is outside the range of 0 to 31.

**RETURNS:**

None.

**clr\_dnet****SYNTAX:**

*label* clr\_dnet                      flag#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
flag#	DeviceNet flag number to be cleared.	56 to 71	IE, IC

**DESCRIPTION:**

Allows setting of a DeviceNet flag from 56-71, sets the value of the flag boolean level false or zero.

**RETURNS:**

None.

**clr\_flag****SYNTAX:**

*label* clr\_flag user\_flag#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
user_flag#	Number of the user flag to be cleared.	208 to 255	IE, IC

**DESCRIPTION:**

Clears the specified user flag.

**RETURNS:**

None.

**clr\_local****SYNTAX:**

*label* clr\_local controller#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id #	1 or 2	IE, IC

**DESCRIPTION:**

Clears the current local zero position and causes the specified axis controller to use the current global zero as the absolute zero position.

**RETURNS:**

None.

**clr\_pls****SYNTAX:**

*label* clr\_pls controller#,module#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	2	IE, IC
module#	PLS output module.	16 to 23	IE, IC

**DESCRIPTION:**

Clears the specified PLS module and allows that module to be used as a normal output. After this instruction is issued the PLS must be redefined to use as an PLS module again.

**RETURNS:**

None.

**clr\_swi****SYNTAX:**

*label* clr\_swi                      interrupt#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
interrupt#	Interrupt number.	0 to 31	IE, IC

**DESCRIPTION:**

Clears a previously defined software interrupt.

**RETURNS:**

None.

**clr\_sys\_error****SYNTAX:**

*label*                      clr\_sys\_error                      flag#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
flag#	dedicated system error flag	144 to 159	IE, IC

**DESCRIPTION:**

The DeltaMax controller will verify that data used with a program instruction is valid at run time. When it is determined that an attempt to use invalid data has been made, a dedicated flag will be enabled. That flag is known as a system error flag.

This flag is set in order for the program to monitor and detect a problem with data used by a certain instruction. The program could monitor the state of this flag through the use of the **if\_flag\_on** or **if\_flag\_off** instructions or through the use of the software interrupts.

The system error flag will remain enabled until one of three events occur:

- 1 - a controller RESET has been executed
- 2 - the controller power has been cycled from off to on
- 3 - the flag is cleared within the program

The program instruction **clr\_sys\_error** will clear the system error flag.

**RETURNS:**

None.

**data****SYNTAX:**

*label* data value,value,etc.

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>
value	32-bit constant	-2,147,483,648 to +2,147,483,647

**DESCRIPTION:**

Specifies 32-bit values. More than 1 value may be contained in a 'data' statement.

EXAMPLE

profile	begin_data	
	data	100,200,4096
	data	0,200,4096
	end_data	

**RETURNS:**

None.

**data\_scale****SYNTAX:**

*label*                      data\_scale                      controller#,dscale

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id #	1	IE, IC
dscale	cam related master scale	0 to 7	IE, IC, IV

**DESCRIPTION:**

The **cam\_data** instruction provides cam setup information to the controller. This includes the location of the data which defines the cam, the master scale factor and the data scale factor.

Due to the amount of information it provides, the **cam\_data** instruction is a relatively lengthy instruction to execute, compared to most instructions. The **data\_scale** instruction can be used when the only information to be changed regarding cam processing is the data scale factor.

The data scale factor is used to scale the distance per cam element.

A data scale factor of '0' indicates that the contents of each cam element would be scaled by a factor of  $2^0$  (which is 1). A data scale factor of '7' indicates that the contents of each cam element would be scaled by a factor of  $2^7$  (which is 128).

For example, the total distance defined by a cam is 8000 bits. Using a data scale of '1', the total distance moved by this same cam would be 16,000 bits, since each cam element is scaled by  $2^1$  (which is 2).

The **data\_scale** instruction can be used to initiate a new data scale factor (cam element execution rate) without the need to pass additional information to the controller in the form of the **cam\_data** instruction.

**RETURNS:**

None.

**declare****SYNTAX:**

*label* declare *mode*

**PARAMETERS:**

<u>Name</u>	<u>Description</u>
mode	This entry can be only ON or OFF.

**DESCRIPTION:**

This is a directive to the MacroPro II™ Compiler.

If 'mode' is ON, the Compiler will expect that all values, text strings, equates etc. will be declared by the programmer. They will not be automatically created by the Compiler.

If 'mode' is OFF, the Compiler will automatically create data space for those values used but not declared.

The Compiler will assume that 'mode' is OFF if this instruction is not included in the program.

**RETURNS:**

None.

**default****SYNTAX:**

*label* default

**PARAMETERS:**

None.

**DESCRIPTION:**

Used with the **select** instruction to designate a group of statements which are executed if none of the **case** statements produce a match.

**EXAMPLE**

```
select  x
      case  1
        .
        .
        exit_select

      case  2
        .
        .
        exit_select

      default
        exit_select

end_select
```

**RETURNS:**

None.

**delta\_comp****SYNTAX:**

*label* delta\_comp controller#,AJ2,AJ3,AJ4,AJ7,AJ8,AJ9

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE,IC
AJ2	load iniertia magnification	0.0 to 100	IE,IC,IV,FE,FC,FV
AJ3	high speed response	0.1 to 20.0	IE,IC,IV,FE,FC,FV
AJ4	position gain	1 to 200	IE,IC,IV,FE,FC,FV
AJ7	gain reduction while stopped	0 to 10000	IE,IC,IV,FE,FC,FV
AJ8	feed forward gain	0.0 to 2.0	IE,IC,IV,FE,FC,FV
AJ9	current command filter	100 to 20000	IE,IC,IV,FE,FC,FV

**DESCRIPTION:**

Sets digital compensation values at the Delta Drive. When executed, the values are transmitted to the Delta Drive and are effective immediately. When AJ9 (current command filter) is changed, power must be cycled to the Delta Drive for this parameter to take effect.

The defaults for the AJ Parameters are as follows:

<u>Name</u>	<u>Default</u>
AJ2	1.0
AJ3	1.0
AJ4	30
AJ7	0
AJ8	1.0
AJ9	6000

The subsequent execution of a *delta\_comp* instruction in the program will cause the AJ Parameters to be set as needed for your application.

**RETURNS:**

None.

**digi\_comp****SYNTAX:**

*label* digi\_comp controller #,gain,value,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
gain	Used to adjust the size of the allowed following error window.	2 to 32768	IE, IC, IV
value	not used	0	IE, IC
value	not used	0	IE, IC

**DESCRIPTION:**

The default following error window for DeltaMax systems is +/-2048 bits. This corresponds to the default 'gain' of 16.

Changing the 'gain' value will effect the size of the following error window. For example:

- a 'gain' of 32 will result in a following error window of +/-1024 bits.
- a 'gain' of 8 will result in a following error window of +/-4096 bits.

The parameters 'value' are unused.

**RETURNS:**

None.



**disable\_hwi****SYNTAX:**

*label* disable\_hwi controller#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC

**DESCRIPTION:**

Terminates scanning of the hardware interrupt signal in the axis controller. Also clears the appropriate **HARDWARE INTERRUPT ARMED** status in the controller.

**RETURNS:**

None.

**disable\_swi****SYNTAX:**

*label* disable\_swi

**PARAMETERS:**

None.

**DESCRIPTION:**

Disables software interrupt processing. Previously defined system interrupts will not be cleared, merely disabled.

**RETURNS:**

None.

**dnet\_flag\_pm****SYNTAX:**

*label* dnet\_flag\_pm                      dnet\_flag,text\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
dnet_flag	DeviceNet I/O flag number	32 to 71	IC
text_label	Label of a text string	16 characters maximum	T

**DESCRIPTION:**

This instruction must reside in a program between a begin\_cfg and end\_cfg instruction at the top of a macroprogram.

Assigns a parameter to the DeviceNet programmable Parameter Object of the controller. The parameter assigned is the instance of the Flag Object associated with the dnet\_flag argument of the instruction. During instruction execution the MacroProgram variable shall be given the default value of the instruction.

Instances of the Parameter Object are arranged in the order of which they are assigned in a program. No more than 16 assignments may be made in a program, in that there can only be 16 instances of the Parameter Object. That includes assignments from instructions **dnet\_intg\_pm** and **dnetflt\_pm**.

**RETURNS:**

None.

**dnet\_flt\_pm****SYNTAX:**

*label* dnet\_flt\_pm value,text\_label,min,max,default

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
value	The declared integer value to use for a DeviceNet parameter.		IF
text_label	Label of a text string to describe the parameter.	16 characters maximum	T
min	Minimum intended value for the assigned parameter.	IEE754 double floating-point	FC
max	Maximum intended value for the assigned parameter.	IEE754 double floating-point	FC
default	Default value for the assigned parameter.	IEE754 double floating-point	FC

**DESCRIPTION:**

This instruction must reside in a program between a begin\_cfg and end\_cfg instruction at the top of a macroprogram.

Assigns a parameter to the DeviceNet programmable Parameter Object of the controller. The parameter assigned is the instance of the Float Object associated with the float value argument of the instruction. During instruction execution the MacroProgram variable shall be given the default value of the instruction.

Instances of the Parameter Object are arranged in the order of which they are assigned in a program. No more than 16 assignments may be made in a program, in that their can only be 16 instances of the Parameter Object. That includes assignments from instructions **dnet\_flag\_pm** and **dnet\_intg\_pm**.

*IMPORTANT:* The **dnet\_range** instruction should be executed prior to this instruction, so that the parameter may be written to over the DeviceNet port if desired. Otherwise the parameter shall have a READ ONLY attribute.

**RETURNS:**

None.

**dnet\_int\_pm****SYNTAX:**

*label* dnet\_int\_pm value,text\_label,min,max,default

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
value	The declared integer value to use for a DeviceNet parameter.		IV
text_label	Label of a text string to describe the parameter.	16 characters maximum	T
min	Minimum intended value for the assigned parameter.	-2147483647 to 2147483647	IC
max	Maximum intended value for the assigned parameter.	-2147483647 to 2147483647	IC
default	Default value for the assigned parameter.	-2147483647 to 2147483647	IC

**DESCRIPTION:**

This instruction must reside in a program between a begin\_cfg and end\_cfg instruction at the top of a macroprogram.

Assigns a parameter to the DeviceNet programmable Parameter Object of the controller, see IB-19B005. The parameter assigned is the instance of the Integer Object associated with the integer value argument of the instruction. During instruction execution the MacroProgram variable shall be given the default value of the instruction.

Instances of the Parameter Object are arranged in the order of which they are assigned in a program. No more than 16 assignments may be made in a program, in that their can only be 16 instances of the Parameter Object. That includes assignments from instructions **dnet\_flag\_pm** and **dnet\_ftl\_pm**.

**IMPORTANT:** The **dnet\_range** instruction should be executed prior to this instruction, so that the parameter may be written to over the DeviceNet port if desired. Otherwise the parameter shall have a READ ONLY attribute.

**RETURNS:**

None.

**dnet\_p\_code****SYNTAX**

*label* dnet\_p\_code            product\_code,text\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
product_code	DeviceNet product code number in the Deltamax Identity Object.	1024 to 1279	IC
text_label	Label of a text string to describe the deltamax application program.		T

**DESCRIPTION:**

This instruction must reside in a program between a begin\_cfg and end\_cfg instruction at the top of a macroprogram.

Assigns a “DeviceNet Product Code” in the Identity Object of the controller. It also will change the “DeviceNet Product Type” in the Identity Object of the controller from 0Hex to 300Hex, so that the Product Type changes from “Generic” to “vendor\_specific”.

The instruction is intended for giving different controllers on the same DeviceNet network unique identities. This is especially helpful when the controllers have different programs and application parameters to accomplish different task in a system having one DeviceNet Network.

**RETURNS:**

None.

**dnet\_range****SYNTAX**

*label* dnet\_range argument\_1, argument\_2

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
argument_1	lower boundary	any variable label within the macroprogram	
argument_2	upper boundary	variable label in a sequentially higher order in memory than argument_1	

**DESCRIPTION:**

Allows the maroprogrammer to set limits on what variables in the macroprogram may be written to by the DeviceNet port.

*IMPORTANT:* The **dnet\_range** instruction should be executed prior to the parameter object programming instructions **dnetflt\_pm** and **dnetint\_pm**, so that the parameter may be written to over the DeviceNet port if desired.

**RETURNS:**

None.

**drive\_off****SYNTAX:**

*label* drive\_off controller#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller ID #	1	IE, IC

**DESCRIPTION:**

Resets all motor fault conditions and puts the axis controller into a passive position sensing mode.  
Turns the servo amplifier off and disables the following error check.

**RETURNS:**

None.

**drive\_on****SYNTAX:**

*label* drive\_on controller#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC

**DESCRIPTION:**

Reset all motor fault conditions and turns on the servo amplifier. The controller must be enabled at least once prior to executing any motion instructions. The controller initializes to 'reset mode' on power-up.

**RETURNS:**

None.

**enable\_hwi****SYNTAX:**

*label* enable\_hwi

**PARAMETERS:**

The instruction immediately following **enable\_hwi** will be used.

**DESCRIPTION:**

This instruction, when used with supported 'hardware interrupt' instructions, will enable scanning at the specified motion controller for the 'hardware interrupt' signal to be activated.

When the 'hardware interrupt' signal is detected, the specified instruction will immediately be executed. The MacroPro II™ Compiler will associate the instruction that follows 'enable\_hwi' as the instruction to be executed.

The following instructions are currently supported:

enable\_hwi  
over\_draw      controller id#,speed,limit,distance

enable\_hwi  
trap\_pos      controller id#

enable\_hwi  
ratio      controller id#,ratio

enable\_hwi  
lock      controller id#,lock type

enable\_hwi  
position      controller id#,abs\_position

enable\_hwi  
index      controller id#,distance

enable\_hwi  
exec\_profile      controller id#

enable\_hwi  
f\_decel      controller id#

The **HARDWARE INTERRUPT ARMED** status in the controller will be on after this instruction has been executed.

**RETURNS:**

None.

## **enable\_swi**

### **SYNTAX:**

*label* enable\_swi

### **PARAMETERS:**

None.

### **DESCRIPTION:**

Enables software interrupt processing.

### **RETURNS:**

None.

**end\_cam****SYNTAX:**

*label* end\_cam

**PARAMETERS:**

None.

**DESCRIPTION:**

Signals the end of a data area containing incremental cam data. Each **begin\_cam** instruction must have a corresponding **end\_cam** instruction.

Automatically places an end of cam value (80 hex) at the end of the cam array.

**EXAMPLE**

```
cam_array    begin_cam
              cam        1,2,3,4,5
              cam        6,6,6,6,6
              cam        5,4,3,2,1
              end_cam
```

**RETURNS:**

None.

**end\_cfg****SYNTAX:**

*label* end\_cfg

**PARAMETERS:**

None

**DESCRIPTION:**

This is a directive to the MacroPro II™ Compiler.

The directive informs the compiler and eventually the Deltamax Operating System, to stop executing configuration commands.

**RETURNS:**

None.

**end\_data****SYNTAX:**

*label* end\_data

**PARAMETERS:**

None.

**DESCRIPTION:**

Signals the end of a data array area. Each **begin\_data** instruction must have a corresponding **end\_data** instruction.

**EXAMPLE**

profile	begin_data	
	data	100,200,4096
	data	0,200,4096
	end_data	

**RETURNS:**

None.

**end\_select****SYNTAX:**

*label* end\_select

**PARAMETERS:**

None.

**DESCRIPTION:**

Used to end a group of **select/case** statements. Each **select** statement must have a corresponding **end\_select** statement.

**RETURNS:**

None.

**equ****SYNTAX:**

*label* equ constant

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Type Allowed</u>
constant	An integer or floating point number or expression.	IE, IC, FE, FC

**DESCRIPTION:**

The **equ** instruction assigns a symbol to a number or mathematic expression.

The MacroPro II™ Compiler replaces each occurrence of 'label' with the assigned number.

This instruction requires a 'label'.

**RETURNS:**

None.

**exec\_profile****SYNTAX:**

*label* exec\_profile controller#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	Controller id#	1 or 2	IE, IC

**DESCRIPTION:**

Executes a previously defined piece-wise profile. While the profile is executing, the **get\_pstat** instruction may be used to determine the profile segment currently running.

This instruction sets the controller status flags **BUSY** and **INDEXING**. These flags remain set until a **f\_decel** instruction causes the motor to reach zero speed or the profile is completed.

This instruction will be ignored if no valid data has been transmitted to the controller via the **prep\_profile** instruction.

This instruction will be ignored if the controller has not received a **drive\_on** instruction, or if the controller is busy executing a motion instruction. If the instruction cannot be executed, the axis status flag **COMMAND INVALID IN THIS STATE** will be set. This flag will automatically be cleared by the controller at the next communication between the main processor and the axis controller.

**RETURNS:**

None.

## exit\_select

### SYNTAX:

*label* exit\_select

### PARAMETERS:

None.

### DESCRIPTION:

Used to end a group of statements being executed within a particular **case** statement. Causes program control to transfer to the statement following the **end\_select** statement. Each **case** statement must have a corresponding **exit\_select** statement.

### EXAMPLE

```
select
    case      1
    .
    exit_select
    case      2
    .
    exit_select
    default
    .
    exit_select
end_select
```

### RETURNS:

None.

**float****SYNTAX:**

*label* float

**PARAMETERS:**

None.

**DESCRIPTION:**

This statement assigns a 64 bit storage location, or value, to the name 'label'. The storage location will be initialized to zero when the program is loaded into the Controller.

This instruction requires a 'label'.

**RETURNS:**

None.

**float\_dim****SYNTAX:**

*label* float\_dim size

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
size	Number of 64-bit storage locations to reserve.	1 to 2000	IE, IC

**DESCRIPTION:**

This statement allocates the indicated number of storage locations to the name 'label'.

This instruction requires a 'label'.

**RETURNS:**

None.

## **f\_decel**

### **SYNTAX:**

*label* f\_decel controller#

### **PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC

### **DESCRIPTION:**

The specified controller will be commanded to stop its motion at the last set accel/decel rate. If its motion is currently stopped, **f\_decel** has no effect.

The controller status flag **FORCED DECEL IN PROGRESS** is set by this instruction. It remains set until the controller's motion reaches zero speed.

A mode zero unlock will occur if the controller is currently in a master/slave lock.

A **f\_decel** instruction is automatically sent to all controllers whenever a **sys\_fault** or a **sys\_return** instruction is executed.

### **RETURNS:**

None.

**get\_act\_spd****SYNTAX:**

*label* get\_act\_spd controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC
value	Current motion controller speed in RPM.(4096 bits per revolution are assumed)		IV

**DESCRIPTION:**

Returns the actual speed at the motor shaft of the specified motion controller (in RPM) into 'value'.

**RETURNS:**

Actual axis speed.

**get\_angle****SYNTAX:**

*label* get\_angle controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller ID #	1	IE, IC
value	The current angle of the master axis driving the controller in master/slave lock.		IV

**DESCRIPTION:**

Returns the current angle of the master axis driving the axis controller in master/slave lock.

**RETURNS:**

Master angle

**get\_cam\_cnt****SYNTAX:**

*label* get\_cam\_cnt controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
value	The returned cam counter.		IV

**DESCRIPTION:**

Returns the number of executions of the currently executing cam. The cam counter is incremented when the cam pointer rolls over from last element to first element, and is decremented each time the cam pointer rolls over from first element to last element.

**RETURNS:**

The number of times this cam has been executed.

**get\_cam\_end****SYNTAX:**

*label* get\_cam\_end controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
value	The last element in the current cam.		IV

**DESCRIPTION:**

Returns the ending location of the cam currently being executed, relative to the axis memory location zero.

**RETURNS:**

Returns the element number of the last value in the current cam.

**get\_cam\_ptr****SYNTAX:**

*label* get\_cam\_ptr controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
value	The cam element currently being referenced.		IV

**DESCRIPTION:**

Stores the current cam array element relative to the beginning of the cam into 'value'..

**RETURNS:**

The number of the current cam array element.

**get\_cam\_strt****SYNTAX:**

*label* get\_cam\_strt controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
value	The first element in the current cam.		IV

**DESCRIPTION:**

Retrieves the starting location of the cam currently executed, relative to axis controller memory location zero.

**RETURNS:**

The first element of the current cam relative to axis controller memory zero.

**get\_cam\_sum****SYNTAX:**

*label* get\_cam\_sum controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
value	Returned sum of cam elements.		IV

**DESCRIPTION:**

Returns the result of the last **calc\_cam\_sum** instruction in 'value'. This instruction may be executed after the instruction **calc\_cam\_sum** has been executed, and the axis status flag **CALCULATION IN PROGRESS** has gone from ON to OFF.

**RETURNS:**

The signal value equal to the sum of the elements as specified by the '**calc\_cam\_sum**' instruction.

**get\_com****SYNTAX:**

*label* get\_com controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC
value	Returned position.		IV

**DESCRIPTION:**

Gets the absolute commanded motor position of the specified axis controller and places this position in 'value'. Position is a signed 32-bit number.

**RETURNS:**

Axis controllers commanded position.

**get\_fol\_err****SYNTAX:**

*label* get\_fol\_err controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
value	The current following error angle.		IV

**DESCRIPTION:**

Returns the current following error angle. This value is the difference between the current commanded position and the current actual position and is represented as a signed value with a normal range of  $\pm 4095$ . Altering the digital gain to less than 16 may result in a value which exceeds normal range. CCW will return negative values, and CW motion will return positive values.

**RETURNS:**

Returns the difference between the current axis controller commanded and actual positions.

**get\_for\_ang****SYNTAX:**

*label* get\_for\_ang controller#,channel#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	2	IE, IC
channel#	The fiber optic channel#.	1	IE, IC
value	The current fiber optic angle.		IV

**DESCRIPTION:**

Returns the current fiber optic angle for the specified channel.

**RETURNS:**

Fiber optic angle. This value is a signed 32-bit number with the range -2,147,483,648 to +2,147,483,647.

**get\_for\_spd****SYNTAX:**

*label* get\_for\_spd controller#,channel#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	2	IE, IC
channel#	The fiber optic channel#.	1	IE, IC
value	The current speed in RPM.		IV

**DESCRIPTION:**

Returns the current speed in RPM from the device connected to the fiber optic channel. This speed is based on 4096 bits per motor revolution at this device.

**RETURNS:**

Speed of the device connected to the fiber optic channel. This value is a signed 16-bit number with the range -32768 to +32767.

**get\_map****SYNTAX:**

*label* get\_map                    value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Type Allowed</u>
value	The currently defined master angle bus configuration.	IV

**DESCRIPTION:**

Queries the current definition of the master angle bus communication configuration defined by the last **set\_map** instruction.

**RETURNS:**

Returns the current master angle bus configuration. 'Value' may be interpreted as seen in Figure 3.21.

**get\_map\_stat****SYNTAX:**

*label* get\_map\_stat            value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Type Allowed</u>
value	The current master angle bus status.	IV

**DESCRIPTION:**

MAP is an acronym for Master Angle Passing.

**RETURNS:**

Status of last **set\_map** instruction executed.

<u>Status</u>	<u>Description</u>
0	Valid 'map' value.
1	More than 1 talker on Bus 'A'.
2	More than 1 talker on Bus 'B'.
3	Axis controller is receiving from Bus 'A' and 'B'.
4	Illegal talkers and/or listeners on Bus 'A'.
5	Illegal talkers and/or listeners on Bus 'B'.

**get\_mcf****SYNTAX:**

*label* get\_mcf controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	2	IE, IC
value	The currently defined Multi Function Controller configuration.		IV

**DESCRIPTION:**

MCF is an acronym for Multi Function Controller.

**RETURNS:**

Returns the current configuration of the Multi Function Controller, as defined by the last valid **set\_mcf** instruction.

This 4-byte value is used as shown in Figure 3.22.

**get\_mcf\_stat****SYNTAX:**

*label* get\_mcf\_stat            *value*

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	2	IE, IC
value	The current multi function controller status.		IV

**DESCRIPTION:**

MCF is an acronym for Multi Function Controller.

**RETURNS:**

Status of last **set\_mcf** instruction executed.

<u>Status</u>	<u>Description</u>
0	Valid 'mcf' value.
1	Too many 'sources' for PLS.
2	Too many 'sources' on Bus 'A'.
3	Too many 'sources' on Bus 'B'.

**get\_ms\_time****SYNTAX:**

*label*            get\_ms\_time            value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
value	Returned time	0 to 2,147,483,648	IV

**DESCRIPTION:**

Return the current system time in 'value'. The 'value' is an unsigned 32-bit data value. The resolution of the timer is 1 millisecond.

For example, a 'value' of 10000 would indicate that 10000 milliseconds (10 seconds) has elapsed from the moment the controller was powered up.

The system time will be reset to 0 during system power up.

**RETURNS:**

Current system time from power up.

**get\_pls\_ang****SYNTAX:**

*label*            get\_pls\_ang                            controller#,pls\_angle

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id #	2	IE, IC
pls_angle	Angle used to drive the PLS modules.	0 to 8,388,607	IV

**DESCRIPTION:**

The **get\_pls\_ang** instruction returns the current angle used by the PLS function to determine the state of all defined PLS modules (ON or OFF).

This value will always be a number within the range specified by the **set\_pls\_cnt** instruction. If a **set\_pls\_cnt** instruction was not previously executed, the default range is 4096.

For example, the following **set\_pls\_cnt** instruction defines a PLS range of 40000 bits:

*label*                    **set\_pls\_cnt**                    **2,40000**

Any subsequent **get\_pls\_ang** instruction will return a PLS angle between 0 and 39999.

**RETURNS:**

A PLS angle within the range established by the **set\_pls\_cnt** instruction.

**get\_pls\_mask****SYNTAX:**

*label* get\_pls\_mask controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	2	IE, IC
value	The currently defined PLS mask value.		IV

**DESCRIPTION:**

PLS is an acronym for Programmable Limit Switch.

Returns the currently defined PLS mask value into 'value', as defined by the last **set\_pls\_mask** instruction.

Only the high order 2 bytes are used.

**EXAMPLE:**

If bit 16 of 'value' is set, PLS #16 is enabled and if bit 31 of 'value' is set, PLS #31 is enabled. Bits 0 to 15 are unused.

**RETURNS:**

The currently defined pls mask.

**get\_pls\_out****SYNTAX:**

*label* get\_pls\_out controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	2	IE, IC
value	The current state of the PLS output modules.		IV

**DESCRIPTION:**

PLS is an acronym for Programmable Limit Switch.

Returns the current state of the PLS output modules into 'value'. A bit on (logic 1) indicates that the associated module is ON. A bit off (logic 0) indicates that the associated output is OFF.

Only the high order 2 bytes are used.

Bits 16 to 23 are the hardware PLS flags.

Bits 24 to 31 are the internal PLS flags.

**RETURNS:**

Current state of PLS outputs.

**get\_pos****SYNTAX:**

*label* get\_pos controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC
value	returned position.		IV

**DESCRIPTION:**

Gets the absolute actual motor position of the specified controller and places this position in 'value'. The position is a signed 32-bit value.

**RETURNS:**

The current actual motor position.

**get\_pstat****SYNTAX:**

*label* get\_pstat controller#,status

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC
status	Returned status.		IV

**DESCRIPTION:**

Returns the calculation or running status of a Piecewise Profile.

- A. After a profile calculation has been performed, **get\_pstat** is used to check the results of the calculations. If there were no errors, 'status' is zero. If any part of the calculations failed, then **get\_pstat** will return a calculation error code and the number of the profile segment that caused the error as follows:

Least significant byte: profile segment number in error  
 Next significant byte: error code (see below)

- B. While a profile is executing, **get\_pstat** returns the number of the profile segment that is being executed.

**RETURNS:**

Error Codes:

<u>Code</u>	<u>Meaning</u>
1	Attempt to change profile direction.
3	Insufficient distance for specified speed and/or acceleration.

The following example represents a 'status' where the profile segment number in error is 10 and the error code for that segment is 3:

status: 778 (decimal) status: 0000 030A (hexadecimal)

**get\_time****SYNTAX:**

*label* get\_time                    value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Type Allowed</u>
value	Returned time.	IV

**DESCRIPTION:**

Return the current system time in 'value'. The 'value' is an unsigned 32-bit data value. The resolution of the timer is 5 milliseconds.

The timer will reset to 0 during system power up.

**RETURNS:**

Current system time from power-up.

**get\_trap\_pos****SYNTAX:**

*label* get\_trap\_pos controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
value	Returned position.	(-524288*4096) to (+524288*4096)-1	IV

**DESCRIPTION:**

Returns the actual motor position of the controller (saved by executing the last **trap\_pos** instruction) into 'value'.

**RETURNS:**

Returns last trapped position.

**gobsub****SYNTAX:**

*label* gobsub                      subroutine\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Type Allowed</u>
subroutine_label	Program label of the subroutine.	A

**DESCRIPTION:**

Branches to the specified address. When a **return\_sub** instruction is executed the program branches to the instruction following the **gobsub** instruction.

The Delta Max provides 20 levels of subroutine nesting. The **STACK OVERFLOW** status flag will be set if more than 20 levels are used.

**RETURNS:**

None.

**goto****SYNTAX:**

*label* goto address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Type Allowed</u>
address_label	Label where execution will continue.	A

**DESCRIPTION:**

Branches to the specified address label.

**RETURNS:**

None.

**if****SYNTAX:**

*label* if compare1 operator compare2,address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Type Allowed</u>														
compare1	Value to be compared.	IE, IC, IV, FE, FC, FV														
operator	Type of comparison to be performed.															
	<table border="1"> <thead> <tr> <th><u>Operator</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>=</td> <td>Equal to</td> </tr> <tr> <td>&lt;&gt;</td> <td>Not equal to</td> </tr> <tr> <td>&gt;</td> <td>Greater than</td> </tr> <tr> <td>&lt;</td> <td>Less than</td> </tr> <tr> <td>&gt;=</td> <td>Greater than or equal to</td> </tr> <tr> <td>&lt;=</td> <td>Less than or equal to</td> </tr> </tbody> </table>	<u>Operator</u>	<u>Description</u>	=	Equal to	<>	Not equal to	>	Greater than	<	Less than	>=	Greater than or equal to	<=	Less than or equal to	
<u>Operator</u>	<u>Description</u>															
=	Equal to															
<>	Not equal to															
>	Greater than															
<	Less than															
>=	Greater than or equal to															
<=	Less than or equal to															
compare2	Value to be compared.	IE, IC, IV, FE, FC, FV														
address_label	Branch address if comparison is true.	A														

**DESCRIPTION:**

Performs arithmetic comparison and causes branching to the specified address if the comparison is true.

If the comparison is false, no branching occurs and execution continues with the next instruction.

**RETURNS:**

None.

**if\_bit\_clr****SYNTAX:**

*label* if\_bit\_clr bit#,value,address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
bit#	Bit number of the 4-byte value to be tested.	0 to 31	IE, IC, IV
value	The 4-byte value to be tested.		IE, IC, IV
address_label	Branch address.		A

**DESCRIPTION:**

Branch to the specified address if the specified bit is off (logic 0).

If the bit tested is on (logic 1), no branching occurs and execution continues with the next instruction.

This instruction will be ignored if 'bit#' is outside the range of 0 to 31.

**RETURNS:**

None.

**if\_bit\_set****SYNTAX:**

*label* if\_bit\_set bit#,value,address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
bit#	Bit number of the 4-byte value to be tested.	0 to 31	IE, IC, IV
value	The 4-byte value to be tested.		IE, IC, IV
address_label	Branch address.		A

**DESCRIPTION:**

Branch to the specified address if the specified bit is on (logic 1).

If the bit tested is off (logic 0), no branching occurs and execution continues with the next instruction.

This instruction will be ignored if 'bit#' is outside the range of 0 to 31.

**RETURNS:**

None.

**if\_char****SYNTAX:**

*label* if\_char port#,address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
port#	Communications port number.	2	IE, IC
address_label	Branch address.		A

**DESCRIPTION:**

Branches to the specified address if characters are sensed at the specified port.

If no characters are sensed, execution continues with the next instruction.

**RETURNS:**

None.

**if\_dnet\_off****SYNTAX:**

*label* if\_dnet\_off flag#,address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
flag#	DeviceNet flag number to be tested.	32 to 71	IE, IC
address_label	instruction label within macroprogram.		

**DESCRIPTION:**

Allows condition checks on the DeviceNet flags 32-71, if the flag is off the branch is executed.

**RETURNS:**

None.

**if\_dnet\_on****SYNTAX:**

*label* if\_dnet\_on flag#,address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
flag#	DeviceNet flag number to be tested.	32 to 71	IE, IC
address_label	instruction label within macroprogram.		

**DESCRIPTION:**

Allows condition checks on the DeviceNet flags 32-71, if the flag is on the branch is executed.

**RETURNS:**

None.

**if\_flag\_off****SYNTAX:**

*label* if\_flag\_off                    user\_flag#,address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
user_flag#	Flag number to test.	208 to 255	IE, IC
address_label	Branch address.		A

**DESCRIPTION:**

Branch to the specified address if the specified user flag is off.

If the user flag is on, no branching occurs and execution continues with the next instruction.

**RETURNS:**

None.

**if\_flag\_on****SYNTAX:**

*label* if\_flag\_on user\_flag#,address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
user_flag#	Flag number to test.	208 to 255	IE, IC
address_label	Branch address.		A

**DESCRIPTION:**

Branch to the specified address if the specified user flag is on.

If the user flag is not on, no branching occurs and execution continues with the next instruction.

**RETURNS:**

None.

**if\_io\_off****SYNTAX:**

*label* if\_io\_off I/O flag#,address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
I/O flag#	Input or Output module number.	0 to 23	IE, IC
address_label	Branch address.		A

**DESCRIPTION:**

Branches to the specified address if the specified I/O flag is off.

If the I/O flag is on, branching does not occur and execution continues with the next instruction.

**RETURNS:**

None.

**if\_io\_on****SYNTAX:**

*label* if\_io\_on I/O flag#,address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
I/O flag#	Input or Output module number.	0 to 23	IE, IC
address_label	Branch address.		A

**DESCRIPTION:**

Branches to the specified address if the specified I/O flag is on.

If the I/O flag is off, branching does not occur and execution continues with the next instruction.

**RETURNS:**

None.

**if\_no\_char****SYNTAX:**

*label* if\_no\_char                    port#,address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
port#	Communications port number.	2	IE, IC
address_label	Branch address.		A

**DESCRIPTION:**

Branches to the specified address if no characters are sensed at the specified port.

If characters are sensed, execution continues with the next instruction.

**RETURNS:**

None.

**if\_stat\_on****SYNTAX:**

*label* if\_stat\_on status\_flag #,address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
status_flag#	Controller status flag.	80 to 127	IE, IC
address_label	Branch address.		A

**DESCRIPTION:**

Branches to the specified address label if the controller status flag indicated is on.

If the controller status flag is off, branching does not occur and execution continues with the next instruction.

**RETURNS:**

None.

**if\_stat\_off****SYNTAX:**

*label* if\_stat\_off                    status\_flag #,address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
status_flag#	Controller status flag.	80 to 127	IE, IC
address_label	Branch address.		A

**DESCRIPTION:**

Branches to the specified address label if the controller status flag indicated is off.

If the controller status flag is on, branching does not occur and execution continues with the next instruction.

**RETURNS:**

None.

**if\_tmr\_off****SYNTAX:**

*label* if\_tmr\_off timer\_flag#,address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
timer_flag#	Timer flag number.	72 to 79	IE, IC
address_label	Branch address.		A

**DESCRIPTION:**

Branches to the specified address if the timer flag indicated is off.

If the timer flag is on, branching does not occur and execution continues with the next instruction.

**RETURNS:**

None.

**if\_tmr\_on****SYNTAX:**

*label* if\_tmr\_on timer\_flag#,address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
timer_flag#	Timer flag number.	72 to 79	IE, IC
address_label	Branch address.		A

**DESCRIPTION:**

Branches to the specified address if the timer flag indicated is on.

If the timer flag is off, branching does not occur and execution continues with the next instruction.

**RETURNS:**

None.

**incr\_com****SYNTAX:**

*label* incr\_com controller#,bits,interrupts

**PARAMETERS:**

<b>Name</b>	<b>Description</b>	<b>Range</b>	<b>Type Allowed</b>
controller#	controller id#	1 or 2	IE, IC
bits	The incremental value, in bits, to be added to the commanded position.		IE, IC, IV
interrupts	The number of motor interrupts to move the distance specified in 'bits'. Motor interrupts occur every 1 ms.		IE, IC, IV

**DESCRIPTION:**

This instruction calculates the number of bits to be added to the commanded position, each motor interrupt, as a result of the calculations 'bits/motor interrupts'. Resulting accel/decel rates are not limited. 'bits' may be signed for direction.

**RETURNS:**

None.

**index****SYNTAX:**

*label* index controller#,distance

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC
distance	Incremental number of bits to move.	(-524288*4096) to (+524288*4096)-1	IE, IC, IV

**DESCRIPTION:**

Commands the specified controller to index the motor the distance given. The speed of the move is determined by the previously set accel/decel rate and speed.

The resolution is 4096 bits per turn. To index 1 turn, distance would be 4096.

The axis controller status flags **MOTOR BUSY** and **INDEXING** will be set (ON) while the motor is indexing.

This instruction will be ignored if the controller has not received a **drive\_on** instruction or if the controller is busy executing a motion instruction. If the instruction cannot be executed, the axis status flag **COMMAND INVALID IN THIS STATE** will be set. This flag will automatically be cleared by the controller at the next communication between the main processor and the axis controller.

**RETURNS:**

None.

**input****SYNTAX:**

*label* input label,length,decimals,value,user\_flag

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
label	ASCII string (prompt) to be displayed		T
length	Maximum length of input value.	0 to 12	IE, IC
decimals	Decimal places in the input value.	0 to 6	IE, IC
value	The value entered.		IV
user_flag	Flag indicating input is complete.	208 to 255	IE, IC

**DESCRIPTION:**

Prepares and reads numeric (only) information from the selected port. The port is selected by using the **port\_set** instruction.

Input string 'length' determines the number of characters accepted during input. The number of characters includes the sign and decimal point (if applicable) as well as the number of characters.

'Decimal places' indicates the number of values to the right of the decimal point.

Input 'value' is the destination address of the numeric input.

The **port\_set** instruction must be executed prior to invoking the **input** instruction.

The characters allowed while entering strings with length exceeding 1 character are +.-1234567890.

If the value being entered has an actual character length greater than the specified input string 'length', the excess characters are ignored. Actual string lengths less than the input string length are permitted and are justified accordingly.

**EXAMPLE**

**If** 2.2 is entered  
**and** decimals = 1  
**then** value =  $2.2 * (10 \wedge 1) = 2.2 * 10 = 22$

**RETURNS:**

The return 'value' contains the numeric conversion of the ASCII string entered at the terminal. This number value is value \* (10 ^ decimals).

**integer****SYNTAX:**

*label* integer

**PARAMETERS:**

None.

**DESCRIPTION:**

This statement assigns a 32 bit storage location, or value, to the name 'label'. The storage location will be initialized to zero when the program is loaded into the Controller.

This instruction requires a 'label'.

**RETURNS:**

None.

**jog\_ccw****SYNTAX:**

*label* jog\_ccw controller#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC

**DESCRIPTION:**

Commands the specified controller to turn the motor shaft in a counter-clockwise direction using the last set accel/decel rate and speed. Motion will continue until an **f\_decel** instruction is executed.

This instruction sets the controller status flags **BUSY** and **JOGGING**. These flags remain set until an **f\_decel** instruction causes the motor to reach zero speed.

This instruction will be ignored if the controller has not received a **drive\_on** instruction, or if the controller is busy executing a motion instruction. If the instruction cannot be executed, the axis status flag **COMMAND INVALID IN THIS STATE** will be set. This flag will be cleared by a **f\_decel** command or a **drive\_off** command.

**RETURNS:**

None.

## jog\_cw

### SYNTAX:

*label* jog\_cw controller#

### PARAMETERS:

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC

### DESCRIPTION:

Commands the specified controller to turn the motor shaft in a clockwise direction using the last set accel/decel rate and speed. Motion will continue until an **f\_decel** instruction is executed.

This instruction sets the controller status flags **BUSY** and **JOGGING**. These flags remain set until an **f\_decel** instruction causes the motor to reach zero speed.

This instruction will be ignored if the controller has not received a **drive\_on** instruction, or if the controller is busy executing a motion instruction. If the instruction cannot be executed, the axis status flag **COMMAND INVALID IN THIS STATE** will be set. This flag will be cleared by a **f\_decel** command or a **drive\_off** command.

### RETURNS:

None.

## I\_track\_spd

### SYNTAX:

*label* I\_track\_spd controller#,speed

### PARAMETERS:

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC
speed	Resulting Speed: -128 to +127 RPM	-32768 to +32767	IE, IC, IV

### DESCRIPTION:

The specified controller tracks (changes to) the speed indicated divided by 256.

The speed may be changed at any time.

This instruction sets the controller status flags **BUSY** and **JOGGING**. These flags remain set until a **f\_decel** instruction causes the motor to reach zero speed.

This instruction will be ignored if the controller has not received a **drive\_on** instruction, or if the controller is busy executing a motion instruction. If the instruction cannot be executed, the axis status flag **COMMAND INVALID IN THIS STATE** will be set. This flag will automatically be cleared by the controller at the next communication between the main processor and the axis processor.

### RETURNS:

None.

**let****SYNTAX:**

*label* let value=operand1 opcode operand2

*label* let value=function(operand1)

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Type Allowed</u>																										
value	Resulting value.	IV, FV																										
operand1	Value or constant.	IE, IC, IV, FE, FC, FV																										
opcode	Operation to be performed.																											
	<table border="0"> <thead> <tr> <th><u>opcode</u></th> <th><u>operation</u></th> </tr> </thead> <tbody> <tr> <td>+</td> <td>addition</td> </tr> <tr> <td>-</td> <td>subtraction</td> </tr> <tr> <td>*</td> <td>multiplication</td> </tr> <tr> <td>/</td> <td>division</td> </tr> <tr> <td>&amp;</td> <td>bitwise and</td> </tr> <tr> <td> </td> <td>bitwise or</td> </tr> <tr> <td>^</td> <td>bitwise exclusive or</td> </tr> <tr> <td>[ ]</td> <td>array indexing</td> </tr> <tr> <td>&gt;&gt;</td> <td>shift right</td> </tr> <tr> <td>&lt;&lt;</td> <td>shift left</td> </tr> <tr> <td>}}</td> <td>rotate right</td> </tr> <tr> <td>{{</td> <td>rotate left</td> </tr> </tbody> </table>	<u>opcode</u>	<u>operation</u>	+	addition	-	subtraction	*	multiplication	/	division	&	bitwise and		bitwise or	^	bitwise exclusive or	[ ]	array indexing	>>	shift right	<<	shift left	}}	rotate right	{{	rotate left	
<u>opcode</u>	<u>operation</u>																											
+	addition																											
-	subtraction																											
*	multiplication																											
/	division																											
&	bitwise and																											
	bitwise or																											
^	bitwise exclusive or																											
[ ]	array indexing																											
>>	shift right																											
<<	shift left																											
}}	rotate right																											
{{	rotate left																											
operand2	Value or constant.	IE, IC, IV, FE, FC, FV																										
function	Allowable function type.																											
	<table border="0"> <thead> <tr> <th><u>function</u></th> <th><u>operation</u></th> </tr> </thead> <tbody> <tr> <td>sqr</td> <td>square root of operand 1</td> </tr> <tr> <td>abs</td> <td>absolute value of operand 1</td> </tr> <tr> <td>neg</td> <td>negate operand 1</td> </tr> </tbody> </table>	<u>function</u>	<u>operation</u>	sqr	square root of operand 1	abs	absolute value of operand 1	neg	negate operand 1																			
<u>function</u>	<u>operation</u>																											
sqr	square root of operand 1																											
abs	absolute value of operand 1																											
neg	negate operand 1																											

**DESCRIPTION:**

The only arithmetic operation allowed, using arrays, is a simple assign. Operations such as add, subtract, multiply etc. are not allowed.

The **let** instruction can be used to transfer data (in 4-byte blocks) between program data memory and the volatile memory of an axis controller. The following example will dimension a 100

element array called 'test\_array' on controller# 1. The value 1234 will be placed in element 19 (array subscripts are zero based) of this array.

#### EXAMPLE 1

```
test_array    dim    1,100
              .
              .
              .
              let    test_array[18]=1234
```

The **let** instruction can be used to transfer data (in 4-byte blocks) from the volatile memory of an axis controller to program data memory. The following example will dimension a 100 element array called 'test\_array' on controller# 1. The current value of element 3 (array subscripts are zero based) will be placed into value 'x'.

#### EXAMPLE 2

```
test_array    dim    1,100
              .
              .
              .
              let    x=test_array[2]
```

#### **RETURNS:**

None.

**let\_byte****SYNTAX:**

*label* let\_byte destination=source

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Type Allowed</u>
destination	Value or cam table element.	IE, IC, IV
source	Value or cam table element.	IE, IC, IV

**DESCRIPTION:**

Typically used to store and retrieve cam elements, one byte at a time. The only arithmetic operation allowed using the **let\_byte** instruction is a simple assign.

Can also be used to pack or split 32 bits to 8 bits or 8 bits to 32 bits.

The **let\_byte** instruction can be used to transfer data (in 1-byte blocks) from program data memory to the volatile memory of an axis controller. The following example will dimension a 100 element (400 byte) array called 'test\_array' on controller# 1. The value 117 will be placed in byte 19 (array subscripts are zero based) of this array.

EXAMPLE 1

```
test_array    dim        1,100
              .
              .
              .
              let_byte    test_array[18]=117
```

The **let\_byte** instruction can be used to transfer data (in 1-byte blocks) from the volatile memory of the axis controller to program data memory. The following example will dimension a 100 element (400 byte) array called 'test\_array' on controller# 1. The current value of byte 3 (array subscripts are zero based) will be placed into value 'x'.

EXAMPLE 2

```
test_array    dim        1,100
              .
              .
              .
              let_byte    x=test_array[2]
```

**RETURNS:**

None.

**lock****SYNTAX:**

*label* lock controller#,lock#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
lock #	Lock method (see explanations below)		IE, IC

**NOTE:**

Lock modes 0, 5, 8 and 9 (described below) may be used in conjunction with the switch cam feature. See the **switch\_cam** instruction for additional information and examples on the use of the combined features.

**DESCRIPTIONS:**

Locks the specified controller onto the master position vector as defined by the master angle configuration.

<u>Lock #</u>	<u>Lock Method</u>
0	cam lock

The DeltaMax controllers provide a mode of operation that effectively emulates mechanical cams. In the electronic cam mode, the slave axis follows a digital cam based on the master angle from one of the master angle buses. Electronic cams are tables of incremental motor moves. Each incremental value occupies one byte of memory and has an allowable range of -127 to +127. The slave controller uses the current master position to determine the proper index into the electronic cam array. As the index moves through the cam table, the incremental distances are added together to form the proper slave axis position. Linear interpolation is performed between elements in the cam array.

When lock method 0 is executed, the cam executes at the first element in the array. When the end of the cam table is reached, the process begins again at the beginning of the table. This process is bi-directional, with the cam moving to increasing positive number elements with clockwise master rotation and decreasing number elements with counterclockwise rotation.

Further information about cam lock can be found by reviewing the following instructions; cam\_data, set\_cam\_ptr, get\_cam\_ptr, switch\_cam, get\_cam\_strt, get\_cam\_end, get\_cam\_sum, calc\_unit\_cam, begin\_cam, end\_cam.

<u>Lock #</u>	<u>Lock Method</u>
1	simple lock with accel/decel limits

Lock method 1 provides the electronic equivalent of a gearbox. The electronic gearbox or ratio is driven by the master angle from one of the master angle buses. The master angle is processed by the previously specified **ratio** instruction and an offset is added, resulting in an effective master used to drive the slave command position.

When lock method 1 is executed, the axis controller calculates the instantaneous offset between the master angle processed by the ratio and the slave command position. Once the offset is calculated, master slave lock is accomplished. Once per millisecond thereafter, the slave axis position is updated based on the new master position. The slave motion is limited by the previously set accel/decel rate (see **set\_ac\_dc**) and is limited to a speed of 5800 RPM. The limiting of the slave acceleration can be an advantage in systems that have rough or rapidly changing master speeds. The limited acceleration on the slave dampens the slave motor and smooths out the operation.

The **ratio** instruction can be executed while in lock method 1. When the **ratio** instruction is executed, the slave controller switches to simply slewing at the **set\_ac\_dc** rate until the slave reaches the new slave speed. When the speed is matched, a new offset is calculated and lock is resumed. It is important to note that after a **ratio** instruction is executed, a new offset is used. The axis status flag **JOGGING** is on while the slave motor is changing from one speed to another. This flag goes off when the ratio lock equation starts executing. The acceleration rate may be changed during the slew from one speed to another caused by a ratio change. A **set\_ac\_dc** executed prior to the **ratio** instruction will cause the slew acceleration rate to change.

The result of executing a **lock** command may vary, depending on the value used in the **ratio** command and the command sequence. This can best be illustrated using the following examples:

#### EXAMPLE 1

```
label      ratio      slave,ratio_value
.
.
.
lock      slave,1
```

At the moment the **lock** is executed:

- a) the slave axis will calculate an internal master/slave "offset", by comparing the master angle with the slave position
- b) the slave axis will accelerate at the rate set using the last **set\_ac\_dc** command
- c) the slave axis will "make up" the distance lost during the acceleration time, by running at a faster rate for that same period of time (the slave axis would appear to momentarily "overshoot" the requested ratio)
- d) the slave axis will run at the requested ratio while maintaining the internal master/slave "offset"

Subsequent changes in 'ratio\_value' will not result in the slave axis "making up" any lost distance while adjusting to a new ratio.

EXAMPLE 2

In this example, the **ratio** command is executed twice. The result of locking the slave axis will be different than that of EXAMPLE 1.

```
label      ratio      slave,0
          .
          .
          .
          lock      slave,1
          .
          .
          ratio      slave,ratio_value
```

At the moment the **lock** is executed:

- a) the slave axis will calculate an internal master/slave "offset", but since the ratio is initially set to zero, no motion occurs

At the moment the second **ratio** instruction is executed:

- a) the slave axis will accelerate at the rate set using the last **set\_ac\_dc** command
- b) the slave axis will run to the requested ratio while maintaining the internal master/slave "offset" (the slave axis will NOT attempt to "make up" any lost distance while adjusting to the new ratio)

<u>Lock #</u>	<u>Lock Method</u>
2	velocity lock

In velocity lock, the slave axis tracks the master velocity with accel/decel limit.

<u>Lock #</u>	<u>Lock Method</u>
3	piecewise profile lock

In piecewise profile lock, the slave axis will execute the piecewise profile in memory when the master angle (modulo 4096) crosses the specified angle from either direction (CW or CCW). This master angle is specified by the instruction **set\_trig\_pw**. The instruction **prep\_profile** must be executed before the **lock** instruction.

<u>Lock #</u>	<u>Lock Method</u>
4	simple lock without accel/decel limits

Lock method 4 is identical to lock method 1. The only difference is that the slave axis is not limited by the specified slave acceleration rate. This means that during lock, the slave is commanded directly by the effective master position. Note: Any perturbations or roughness in the master will be passed onto the slave with no accel/decel rate limiting.

The **ratio** instruction can be executed during lock method 4. When a new ratio is executed, the slave controller breaks lock, slews to new lock speed at the specified acceleration rate and relocks using the above equation. The **JOGGING** status flag is on during the slew period. Note that after the slew period a new offset is calculated. The acceleration rate may be changed during slew executing a **set\_ac\_dc** instruction prior to the ratio instruction.

<u>Lock #</u>	<u>Lock Method</u>
5	cam lock

Lock method 5 is identical to lock method 0 except that the user has the option of positioning the cam pointer to a position other than the beginning of the cam. This is accomplished by executing the **set\_cam\_ptr** instruction. Execution of the cam will begin at the position in the cam data table at the cam pointer.

<u>Lock #</u>	<u>Lock Method</u>
6	keyway lock

Lock method 6 allows the user to align the absolute position of the slave with the absolute position of the master. The ratio in Lock Method 6 is fixed at 1:1 and may not be changed. The slave controller acceleration rate is limited by the previously executed **set\_ac\_dc** instruction. The slave top speed is also limited to 5800 RPM.

When the lock instruction is executed, the slave controller executes the following equation every 1 millisecond:

$$\text{master angle} = \text{slave command position}$$

This equation is executed modulo 1 turn (4096 bits) of the master. This means that when the **lock** instruction is executed, the slave will move, at the acceleration rate specified, in the shortest direction to bring the master and slave absolute angles into alignment. Note that Lock Method 6 can cause movement when lock is executed even if the master is at rest.

The slave accel and speed are limited. Hunting can occur if the master rate of change is greater than the specified slave acceleration rate. The rule of thumb of having the slave acceleration rate at least 5 times the expected master rate of change is applicable. The limited acceleration rate can be used to smooth a master with fast perturbations (roughness).

<u>Lock #</u>	<u>Lock Method</u>
7	undefined

<u>Lock #</u>	<u>Lock Method</u>
8	lock cam at specified master angle

In lock type 8, the slave axis will begin executing its cam when the master axis crosses the specified angle (modulo 4096) from either direction (CW or CCW). This angle is specified using the instruction **set\_trig\_cam**. It is possible to start execution of the cam from any point in the cam by using the instruction **set\_cam\_ptr**. The axis status flag **SWITCH CAM PENDING** will be set until the master crosses the specified lock angle and execution of the cam begins.

<u>Lock #</u>	<u>Lock Method</u>
9	lock cam at specified master angle for 1 cycle only

Lock type 9 is identical to lock type 8 except that execution of the cam will automatically terminate at a rollover in the cam.

**RETURNS:**

None.

**master\_scale****SYNTAX:**

*label*            master\_scale            controller#,mscale

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id #	1	IE, IC
mscale	cam related master scale	0 to 12	IE, IC, IV

**DESCRIPTION:**

The **cam\_data** instruction provides cam setup information to the controller. This includes the location of the data which defines the cam, the master scale factor and the data scale factor.

Due to the amount of information it provides, the **cam\_data** instruction is a relatively lengthy instruction to execute, compared to most instructions. The **master\_scale** instruction can be used when the only information to be changed regarding cam processing is the master scale.

The master scale factor determines the rate at which cam elements are executed relative to the change in master position.

<u>Master Scale Factor</u>	<u>Cam Array Advances Every</u>
12	4096 master bits
11	2048 master bits
10	1024 master bits
9	512 master bits
8	256 master bits
7	128 master bits
6	64 master bits
5	32 master bits
4	16 master bits
3	8 master bits
2	4 master bits
1	2 master bits
0	1 master bits

The **master\_scale** instruction can be used to initiate a new master scale factor (cam element execution rate) without the need to pass additional information to the controller in the form of the **cam\_data** instruction.

**RETURNS:**

None.

**mod\_index****SYNTAX:**

*label*                    mod\_index                    controller#,speed,rate,distance,degree

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id #	1 or 2	IE, IC
speed	Desired speed in RPM.	1 to 5800 RPM	IE, IC, IV
rate	Desired accel/decel rate in revs/sec/sec.	1 to 1600	IE, IC, IV
distance	Incremental number of bits to move.	(-524288*4096) to(+524288*4096)-1	IE, IC, IV
degree	The relative amount of motion modification.	0 to 9	IE, IC, IV

**DESCRIPTION:**

The **mod\_index** instruction commands the controller to index (incremental motion) the motor the specified distance as defined by the speed, rate and degree provided.

The **mod\_index** instruction is similar to the **index** instruction. There are, however, two key differences:

- 1 - The **mod\_index** instruction requires the speed, rate and distance parameters. The **index** instruction requires only the distance parameter. The speed and rate parameters must be preset using the **set\_speed** and **set\_ac\_dc** instructions.
- 2 - The **mod\_index** instruction will initiate a modified sine shape motion that is determined by the degree parameter. The **index** instruction will initiate a normal trapezoidal shape motion with no modification.

A degree entry of '0' indicates no motion modification. The larger the degree entry, the greater the modification to the motion shape.

Resolution is 4096 bits per turn. To index 1 turn, distance would be 4096.

The axis controller status flags MOTOR BUSY and INDEXING will be set (ON) while the motor is indexing.

This instruction will be ignored if the controller has not received a **drive\_on** instruction or if the controller is busy executing a motion instruction. If the instruction cannot be executed, the axis

status flag COMMAND INVALID IN THIS STATE will be set. This flag will automatically be cleared by the next axis controller instruction is executed.

**RETURNS:**

None.

## mod\_position

### SYNTAX:

*label*                    mod\_position                    controller#,speed,rate,abs\_position,degree

### PARAMETERS:

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id #	1 or 2	IE, IC
speed	Desired speed in RPM.	1 to 5800 RPM	IE, IC, IV
rate	Desired accel/decel rate in revs/sec/sec.	1 to 1600	IE, IC, IV
abs_position	The absolute position relative to position zero.	(-524288*4096) to(+524288*4096)-1	IE, IC, IV
degree	The relative amount of motion modification.	0 to 9	IE, IC, IV

### DESCRIPTION:

The **mod\_position** instruction commands the controller to position the motor to the specified **abs\_position** as defined by the speed, rate and degree provided.

The **mod\_position** instruction is similar to the **position** instruction. There are, however, two key differences:

- 1 - The **mod\_position** instruction requires the speed, rate and distance parameters. The **position** instruction requires only the **abs\_position** parameter. The speed and rate parameters must be preset using the **set\_speed** and **set\_ac\_dc** instructions.
- 2 - The **mod\_position** instruction will initiate a modified sine shape motion that is determined by the degree parameter. The **position** instruction will initiate a normal trapezoidal shape motion with no modification.

A degree entry of '0' indicates no motion modification. The larger the degree entry, the greater the modification to the motion shape.

Resolution is 4096 bits per turn. To index 1 turn, distance would be 4096.

The axis controller status flags MOTOR BUSY and INDEXING will be set (ON) while the motor is positioning.

This instruction will be ignored if the controller has not received a **drive\_on** instruction or if the controller is busy executing a motion instruction. If the instruction cannot be executed, the axis

status flag COMMAND INVALID IN THIS STATE will be set. This flag will automatically be cleared by the next axis controller instruction is executed.

**RETURNS:**

None.

**no\_op**

**SYNTAX:**

*label* no\_op

**PARAMETERS:**

None.

**DESCRIPTION:**

Performs a 'no operation' instruction. Commonly used to provide a short time delay.

**RETURNS:**

None.

**offset\_master****SYNTAX:**

*label* offset\_master controller#,offset

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller#	1 or 2	IE, IC
offset	Offset to be added to the master position. This value is a signed 32-bit number.		IE, IC, IV

**DESCRIPTION:**

This command instructs the operating system to add the specified offset value (in bits) to the actual transducer angle of the specified master controller before it is placed on the master angle bus. The offset is an absolute value added to the master angle and is unaffected. Only the data being placed on the master angle bus is affected.

**RETURNS:**

None.

**over\_draw****SYNTAX:**

*label* over\_draw controller#,speed,limit,distance

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
speed	Desired speed to start overdraw in RPM. Must not exceed speed of associated index or position instruction.		IE,IC,IV
limit	Desired limit in bits. Represents maximum travel allowed if hardware interrupt does NOT occur.		IE, IC, IV
distance	Distance to travel AFTER the hardware interrupt occurs.		IE, IC, IV

**NOTE:**

This instruction can only be used in conjunction with hardware interrupts.

**DESCRIPTION:**

This instruction is typically used in feed to sensor types of applications. Information provided by the **over\_draw** instruction modifies an **index** or **position** instruction. As the **index** or **position** instruction nears completion, motor speed will begin to decrease according to the set accel/decel rate. When the motor speed reaches the value specified in the **over\_draw** instruction, deceleration will cease. The motor will run at constant speed until one of two conditions are met:

1. The distance specified in 'limit' is reached. Should this occur, the motor will decelerate to a stop.
2. The Controller's associated input module turns on. Should this occur, the position of the motor shaft is immediately noted. The motor will stop 'distance' bits from the point the input module turns on.

It should be noted that the motor shaft position is trapped immediately by the controller's hardware. However, it may be as long as 1 millisecond before the trapped position is serviced. For this reason, the 'distance' value should allow at least enough distance for deceleration **plus** the distance the motor shaft would turn in 1 millisecond at the 'speed' specified in the **over\_draw** instruction.

The controller will set the axis status flag **OVERDRAW FAIL** if in the index or position move, the over\_draw speed was not reached.

EXAMPLE

```

busy_1      equ      94      busy flag
hwi_armed_1 equ      91      interrupt armed flag
.
drive_on.   1
set_speed   1,400    400 rpm
set_ac_dc   1,100    100 rev/sec2

! sensor only active during overdraw section of the profile
set_ovd_mode 1,1
.
.
.
profile
enable_hwi
over_draw    1,100,4096,2000

! wait for index to finish. If interrupt still armed, sensor not tripped
index        1,81920

loop         if_stat_on    1,busy_1,loop
            if_stat_on    1,hwi_armed_1,od_fail
.
            (normal processing)
.
od_fail
            (handle case where sensor not seen)

```

**RETURNS:**

None.

**port\_set****SYNTAX:**

*label* port\_set port#,baud,protocol

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
port#	Port number.	2	IE, IC
baud	Data transmission rates are listed below, use any one of the following: 110, 300, 600, 1200, 2400, 4800, 9600 or 19200.		IE, IC
protocol	Communications characteristics are listed below.		IE, IC

<u>protocol</u>	<u>Description</u>
0	1 stop bit, no parity, XON/XOFF disabled
1	2 stop bits, no parity, XON/XOFF disabled
2	1 stop bit, even parity, XON/XOFF disabled
3	2 stop bits, even parity, XON/XOFF disabled
4	1 stop bit, odd parity, XON/XOFF disabled
5	2 stop bits, odd parity, XON/XOFF disabled
6	RESERVED
7	RESERVED
8	1 stop bit, no parity, XON/XOFF enabled
9	2 stop bits, no parity, XON/XOFF enabled
10	1 stop bit, even parity, XON/XOFF enabled
11	2 stop bits, even parity, XON/XOFF enabled
12	1 stop bit, odd parity, XON/XOFF enabled
13	2 stop bits, odd parity, XON/XOFF enabled

If no parity, then data word is 8 bits. If even or odd parity, then data word is 7 bits.

**DESCRIPTION:**

Open and initialize the specified communications port.

The **port\_set** instruction may be executed at any time.

Port number 2 is the RS-232C port on the Delta Max.

**RETURNS:**

None.

**position****SYNTAX:**

*label* position controller#,abs\_position

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC
abs_position	The absolute position relative to position zero.	(-524288*4096) to (+524288*4096) -1 bits	IE, IC, IV

**DESCRIPTION:**

Move the controller to the specified position, relative to zero. The speed of the move is determined by the previously set accel/decel rate and speed.

The Delta Max has a resolution of 4096 bits per turn. To position to turn 1, 'abs\_position' would be 4096.

**RETURNS:**

None.

**prep\_profile****SYNTAX:**

*label* prep\_profile controller#,data\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC
data_label	Label of the data for the profile.		T

**DESCRIPTION:**

Transmits the desired Piecewise Profile data to the specified controller and prepares the data for execution. While the motion controller is performing its' calculations, the **CALCULATING PIECEWISE PROFILE** controller status flag will be on. When profile calculations or execution have been completed, this controller status flag will be turned off. After calculations are completed, the **get\_pstat** instruction may be used to determine whether calculations completed successfully.

**RETURNS:**

None.

**preset****SYNTAX:**

*label* preset controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	2	IE, IC
value	offset value		IE, IC, IV

**DESCRIPTION:**

Adds the offset value in bits to the master angle used to drive the PLS.

**RETURNS:**

None.

**print****SYNTAX:**

*label* print *text\_label*

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Type Allowed</u>
text_label	Label of a text string.	T

**DESCRIPTION:**

Print the ASCII character string to the port declared in the previous **port\_set** instruction.

The execution of a **port\_set** instruction must precede the execution of the **print** instruction.

The output to the port is buffered, that is, the speed characteristics of the port do not affect the execution of the Delta Max.

**RETURNS:**

None.

**print\_num****SYNTAX:**

*label* print\_num length,decimals,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
length	Number of character places of 'value' parameter.	1 to 16	IE, IC, IV
decimals	Number of decimal places of 'value' parameter.	0 to 6	IE, IC, IV
value	Numeric value to be converted to ASCII characters and displayed according to the length and decimal parameters.		IE, IC, IV

**DESCRIPTION:**

Print the output value to the port declared in the previous **port\_set** instruction.

The format of the printed number is defined by 'length' which declares the maximum number of character positions allowed to represent the numeric value and by 'decimals' which declares the number of numeric positions to the right of the decimal point.

If the specified length is less than the actual length of the value to be printed, a string of asterisks (\*) will be printed instead. If the specified length is greater than the actual length of the value to be printed, the number will be right justified accordingly.

The execution of a **port\_set** instruction must precede the execution of the **print\_num** instruction.

The output to the port is buffered, that is the speed characteristics of the port do not affect the execution of the Delta Max.

**RETURNS:**

None.

**ratio****SYNTAX:**

*label* ratio controller#,ratio

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
ratio	Desired electronic ratio (in bits).	-32768 to +32767	IE, IC, IV

**DESCRIPTION:**

Scale the master/slave position vector being passed by the 'ratio' value for the specified controller.

Combined with the **lock** instruction (simple lock method), an electronic 'gear box' with a value ratio may be emulated.

'ratio' is in bits (i.e. 4096 would give a ratio of 1:1).

**RETURNS:**

None.

## read\_offset

### SYNTAX:

*label* read\_offset controller#,value

### PARAMETERS:

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
value	Offset value in bits.		IV

### DESCRIPTION:

Returns the current offset as defined by the **set\_offset** instruction.

### RETURNS:

The current offset is returned in the designated 'value'.

**restart\_at****SYNTAX:**

*label* restart\_at address\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Type Allowed</u>
address_label	Branch address.	A

**DESCRIPTION:**

Clear all **gosub** return addresses and branch to the specified 'address label'.

**RETURNS:**

None.

**return\_sub****SYNTAX:**

*label* return\_sub

**PARAMETERS:**

None.

**DESCRIPTION:**

Return from a subroutine invoked by a **gosub** instruction.

The Delta Max provides 20 levels of subroutine nesting. The program status **STACK OVERFLOW** will occur if more than 20 levels are used.

If a **return\_sub** instruction is encountered without a corresponding **gosub**, a program status of **STACK UNDERFLOW** may occur.

**RETURNS:**

None.



**set\_ac\_dc****SYNTAX:**

*label* set\_ac\_dc controller#,rate

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC
rate	Desired accel/decel rate in revs/sec/sec.	1 to 1600	IE, IC, IV

**DESCRIPTION:**

Set the accel/decel rate for the specified controller. All motions for this controller (except cam, ratios and piecewise profiles) will be determined by this rate.

The rate is scaled in revs/sec/sec for all motions (except **vel\_cw** and **vel\_ccw** instructions) for which the rate scale is (revs/sec/sec) / 256.

The default accel/decel rate is 1 revs/sec/sec. This is also the lowest allowable accel/decel rate. The highest allowable rate is 1600 revs/sec/sec.

**RETURNS:**

None.

**set\_bit****SYNTAX:**

*label* set\_bit                      bit#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
bit#	Number of the bit within the 4-byte value to be set to on (logic 1).	0 to 31	IE, IC, IV
value	The 4-byte area in memory affected by this instruction.		IV

**DESCRIPTION:**

The specified bit will be set to on (logic 1). If that bit has been previously set, it will remain set. If that bit was previously cleared (logic 0), it will now be set to on.

This instruction has no effect on the remaining bits of this 4-byte value.

This instruction will be ignored if 'bit#' is outside the range of 0 to 31.

**RETURNS:**

None.

**set\_cam\_ptr****SYNTAX:**

*label* set\_cam\_ptr controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
value	The new start position within the cam table.	0 to (cam table length -1)	IE, IC, IV

**DESCRIPTION:**

Repositions the 'start of cam' pointer in the current cam table array for the controller. This instruction must be used in conjunction with **lock** types 5, 8 and 9 in order to execute the cam from within the table, rather than the start of the table.

**RETURNS:**

None.

**set\_dnet****SYNTAX:**

*label* set\_dnet                      flag#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
flag#	DeviceNet flag number to be set.	56 to 71	IE, IC

**DESCRIPTION:**

Allows setting of a Devicenet flag from 56-71, sets the value of the flag boolean level true or one.

**RETURNS:**

None.

**set\_flag****SYNTAX:**

*label* set\_flag user\_flag#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
user_flag#	Number of the user flag.	208 to 255	IE, IC

**DESCRIPTION:**

Sets the specified user flag.

**RETURNS:**

None.

**set\_gl\_ccw****SYNTAX:**

*label* set\_gl\_ccw controller#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC

**DESCRIPTION:**

Set the absolute 0.0 position to the nearest position transducer zero in the counter-clockwise direction. The current local 0.0 will be cleared.

This instruction may be executed while the motor is in motion. If it is performed while the motor is stopped, no motion will occur.

This instruction is often used in conjunction with a zero revolution switch to establish an absolute zero or home position on multi-turn systems.

**RETURNS:**

None.

**set\_gl\_cw****SYNTAX:**

*label* set\_gl\_cw controller#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC

**DESCRIPTION:**

Set the absolute 0.0 position to the nearest position transducer zero in the clockwise direction. The current local 0.0 will be cleared.

This instruction may be executed while the motor is in motion. If it is performed while the motor is stopped, no motion will occur.

This instruction is often used in conjunction with a zero revolution switch to establish an absolute zero or home position on multi-turn systems.

**RETURNS:**

None.

## set\_local

### SYNTAX:

*label* set\_local controller#

### PARAMETERS:

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC

### DESCRIPTION:

Set the present motor position as the absolute 0.0 position. Will override the **set\_gl\_ccw** and **set\_gl\_cw** instructions, however, the global 0.0 position is not changed.

Used to establish a 'floating' home position.

### RETURNS:

None.

## set\_map

### SYNTAX:

*label* set\_map value

### PARAMETERS:

<u>Name</u>	<u>Description</u>	<u>Type Allowed</u>
value	The desired map value.	IE, IC, IV

### DESCRIPTION:

'map' is an acronym for Master Angle Passing.

The **set\_map** instruction defines the master angle configuration within a system unit. The proper value of 'value' can be determined from Figure 3.21.

Only 1 transmitter per bus can be defined. Improper bus configurations will cause the **get\_map\_stat** instruction to return a non-zero value.

### RETURNS:

None.

**set\_mcf****SYNTAX:**

*label* set\_mcf controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	2	IE, IC
value	Multi Function Controller configuration value.		IE, IC, IV

**DESCRIPTION:**

This instruction is used to configure the multi-function controller on the DeltaMax, which is controller #2. This controls the Pseudo Axis, Master Angle Bus Network, Fiber Optic Network and Programmable Limit Switch (PLS) functions.

**RETURNS:**

None.

**set\_ms\_tmr****SYNTAX:**

*label*                    set\_ms\_tmr                    timer\_flag#,time

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
timer_flag#	Timer flag number	72 to 79	IE, IC
time	Time to set.	1 to 65535	IE, IC, IV

**DESCRIPTION:**

Activates or enables 'timer flag#' for a time in milliseconds equal to 'time'.

The specified 'timer flag#' remains set until 'time' has expired.

**RETURNS:**

None.

**set\_offset****SYNTAX:**

*label* set\_offset controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
value	Desired offset in bits	-32768 to +32767	IE, IC, IV

**DESCRIPTION:**

Offsets all positions by the specified value in bits.

This instruction will cause the motor to move the distance specified by 'value' within the next motor interrupt.

**RETURNS:**

None.

**set\_ovd\_mode****SYNTAX:**

*label* set\_ovd\_mode controller#,mode

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
mode	Selects the section of the motion profile where the overdraw sensor is active.	0 or 1	IE, IC

**DESCRIPTION:**

Selects the section of the motion profile where the overdraw sensor is active.

Mode 0 - the sensor is active through the entire profile.

Mode 1 - the sensor is only active during the overdraw section of the profile.

In mode 0, when the sensor is activated during the index part of the profile, the index will be treated as a regular index with no search speed section executed.

**RETURNS:**

None.

**set\_pls\_ang****SYNTAX:**

*label* set\_pls\_ang controller#,on\_angle,off\_angle,module#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	2	IE, IC
on_angle	Turn ON module# at this angle in bits.	0 to 4095 bits (representing 360 degrees)	IE, IC, IV
off_angle	Turn OFF module# at this angle in bits.	0 to 4095 bits (representing 360 degrees)	IE, IC, IV
module#	Desired output module.	16 to 31	IE, IC, IV

**DESCRIPTION:**

PLS is an acronym for Programmable Limit Switch.

This instruction defines the action that will occur on the designated PLS output unit.

'Module#' 16 to 23 are mapped to the PLS output modules. 'Module#' 24 to 31 are mapped internally to flags.

Each time a **set\_pls\_ang** instruction is issued, the axis controller executes a sorting algorithm and will activate its' **CALCULATION IN PROGRESS** flag. The program must verify that this flag is no longer active before executing subsequent **set\_pls\_ang** instructions.

The 'rollover point' is the master cycle length in bits. The default 'rollover point' is 4096. That is, the cycle is defined as a value between 0 and 4095. Based on this 4096 bit cycle, a PLS module will be turned ON when it crosses into the ON range and will be turned OFF when it crosses into the OFF range, based on the master source angle.

**NOTE:** A PLS module must be enabled using the **set\_pls\_mask** instruction before it can be used.

**RETURNS:**

None.

**set\_pls\_cnt****SYNTAX:**

*label*            set\_pls\_cnt            controller#,pls\_count

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id #	2	IE, IC
pls_count	The PLS cycle count.	4 to 8,388,607	IE, IC, IV

**DESCRIPTION:**

The **set\_pls\_cnt** instruction defines the cycle count for the PLS function. This also determines the range of allowable entries for the ON ANGLE and OFF ANGLE parameters used in the **set\_pls\_ang** instruction.

For example, the following **set\_pls\_cnt** instruction is executed:

*label*            **set\_pls\_cnt**            **2,16000**

This would establish a PLS cycle of 16000 bits which will range between 0 and 15999. Once the PLS angle 15999 is passed, the cycle rolls over and begins again at 0.

A subsequent **set\_pls\_ang** instruction must then define their ON ANGLE and OFF ANGLE parameters within the range of 0 to 15999, otherwise, an ILLEGAL ARGUMENT will be detected and flag # 144 will be turned ON.

**RETURNS:**

None.

**set\_pls\_mask****SYNTAX:**

*label* set\_pls\_mask controller#,value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	2	IE, IC
value	The currently defined PLS mask value.		IE, IC, IV

**DESCRIPTION:**

PLS is an acronym for Programmable Limit Switch.

Defines the PLS mask value used to enable/disable pls functioning of the pls outputs. The 2 high order bytes of 'value' represent the 16 associated output modules/flags.

Those bits set in 'value' will be masked with the currently defined PLS state to determine which PLS modules will continue to be affected.

The the instruction **set\_pls\_mask** is used to control the activity of the output modules without clearing and/or redefining the output modules using the **set\_pls\_ang** instruction.

**EXAMPLE:**

Setting bit 16 of 'value' enables PLS #16 and setting bit 31 of value enables PLS #31. Bits 0 to 15 are unused.

**RETURNS:**

None.

**set\_speed****SYNTAX:**

*label* set\_speed controller#,speed

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC
speed	Desired speed in RPM.	1 to 5800 RPM	IE, IC, IV

**DESCRIPTION:**

Set the speed of the specified controller to 'speed'. If no set\_speed command is issued the controller will use 1 RPM.

**RETURNS:**

None.

**set\_swi\_mask****SYNTAX:**

*label* set\_swi\_mask          value

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Type Allowed</u>
value	The software interrupt mask value.	IE, IC, IV

**DESCRIPTION:**

Determines which of the 32 software interrupts are active. A value of 1 in the corresponding bit of the mask 'value' enables the software interrupt.

**RETURNS:**

None.

**set\_tmr****SYNTAX:**

*label* set\_tmr timer\_flag#,time

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
timer_flag#	Timer flag number.	72 to 79	IE, IC
time	Time to set.		IE, IC, IV

**DESCRIPTION:**

Activates or enables a timer for a time = 'time'. Time is given in .01 second intervals.

The specified flag remains set until 'time' has expired.

**RETURNS:**

None.

**set\_trig\_cam****SYNTAX:**

*label* set\_trig\_cam controller#,master\_angle

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
master_angle	Angle of the master controller which initiates a trigger.	0 to +4095	IE, IC, IV

**DESCRIPTION:**

Sets the trigger point for lock methods 8 & 9 (see **lock**). When the master controller angle crosses the trigger angle from either direction, the slave axis begins executing the cam at the specified cam pointer. (The cam pointer will be set to zero if no **set\_cam\_ptr** instruction has been executed prior to the lock).

**NOTE:**

A **set\_trig\_cam** instruction will override a previous **set\_trig\_cam** instruction that has not already been implemented.

**RETURNS:**

None.

**set\_trig\_pw****SYNTAX:**

*label* set\_trig\_pw controller#,master\_angle

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
master_angle	Angle of the master controller which initiates a trigger.	0 to +4095	IE, IC, IV

**DESCRIPTION:**

Sets the trigger point for lock method 3 (see **lock**). When the master controller angle equals the angle position, a Piecewise Profile is executed.

**RETURNS:**

None.

**stop\_input****SYNTAX**

*label* stop\_input

**PARAMETERS:**

None.

**DESCRIPTION:**

Terminates all active **input** instructions and clears the input buffer area of all characters.

**RETURNS:**

None.

**swi\_if\_off****SYNTAX:**

*label* swi\_if\_off interrupt#,flag,subroutine\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
interrupt#	Interrupt number.	0 to 31	IE, IC
flag	Flag to trigger the interrupt.	0 to 255	IE, IC
subroutine_label	Subroutine branch address.		A

**DESCRIPTION:**

Sets up an event which will trigger when 'flag' changes from on to off.

**RETURNS:**

None.

**swi\_if\_on****SYNTAX:**

*label* swi\_if\_on interrupt#,flag,subroutine\_label

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
interrupt#	Interrupt number.	0 to 31	IE, IC
flag	Flag to trigger the interrupt.	0 to 255	IE, IC
subroutine_label	Subroutine branch address.		A

**DESCRIPTION:**

Sets up an event which will trigger when 'flag' changes from off to on.

**RETURNS:**

None.

**switch\_cam****SYNTAX:**

*label* switch\_cam controller#,start element,# of elements

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
start element	Element relative to axis card memory array element zero		IE, IC, IV
# of elements	Number of cam elements		IE, IC, IV

**NOTES:**

- 1) The **lock** instruction will only be executed when the **BUSY** flag is off, otherwise, it will be ignored.
- 2) A **switch\_cam** instruction will override a previous **switch\_cam** instruction that has not been already implemented.

**DESCRIPTION:**

The **SWITCH CAM** instruction allows the programmer to switch from executing one cam to another. The programmer specifies the starting element relative to element 0 in the axis controller's 28K array and the number of elements to be executed.

The manner in which the **SWITCH CAM** instruction works, is dependent on a number of parameters:

- 1) the **lock** type being used
- 2) the order in which the **switch\_cam** and **lock** instructions are executed
- 3) the current state of the axis controller, as defined by its axis status flags

When a cam is being executed and a **switch\_cam** instruction is issued, the **LOCK PENDING** status flag is set until the cam "rolls" from the last to the first or the first to the last cam element. When the "roll" occurs, the **LOCK PENDING** flag is cleared, the **MASTER/SLAVE** lock is set and the new cam begins execution.

Execution of an **unlock** command will clear the **LOCK PENDING** axis status flag, if currently set.

**EXAMPLE 1:**

When using the **switch\_cam** instruction with lock mode 0 or 5 (assume the axis is not busy and a **cam\_data** instruction has been executed).

DELTA MAX COMMAND    RESULT

switch_cam	a) sets the start/end of cam pointers b) no affect on axis status flags
lock	a) turn on <b>MASTER/SLAVE LOCK</b> and <b>BUSY</b> flags

In this example, the switch takes place immediately (affecting the cam pointers) and the actual lock will occur at the moment the **lock** command is issued.

EXAMPLE 2:

When using the **switch\_cam** instruction with lock mode 0 or 5 (assume the axis is not busy and a **cam\_data** instruction has been executed).

DELTA MAX COMMAND    RESULT

lock	a) turn on <b>MASTER/SLAVE LOCK</b> and <b>BUSY</b> flags
switch_cam	a) sets the start/end of cam pointers for the next cam to be executed b) turns on the <b>LOCK PENDING</b> flag

In this example, a lock takes place immediately. The **switch\_cam** instruction will set up the cam pointers to be used for the next cam, that is, the cam to be executed upon completion of the current cam.

EXAMPLE 3:

When using the **switch\_cam** instruction with lock mode 8 or 9 (assume the axis is not busy and a **cam\_data** instruction has been executed).

DELTA MAX COMMAND    RESULT

set_trig_cam	a) sets the lock trigger angle
switch_cam	a) sets the start/end of cam pointers b) no affect on axis status flags
lock	a) turn on <b>LOCK PENDING</b> and <b>BUSY</b> flags

In this example, the switch takes place immediately (affecting the cam pointers) and the actual lock will occur at the moment the master angle has crossed the defined trigger angle. Once the lock takes place, the **LOCK PENDING** flag is turned off and the **MASTER/SLAVE LOCK** flag is turned on.

EXAMPLE 4:

When using the **switch\_cam** instruction with lock mode 8 or 9 (assume the axis is not busy and a **cam\_data** instruction has been executed).

<u>DELTA MAX COMMAND</u>	<u>RESULT</u>
set_trig_cam	a) sets the lock trigger angle
lock	a) turn on <b>LOCK PENDING</b> and <b>BUSY</b> flags
switch_cam	if the <b>LOCK PENDING</b> flag is on, then <ul style="list-style-type: none"> <li>a) sets the start/end of cam pointers</li> <li>b) no affect on axis status flags</li> <li>c) the actual lock occurs at the trigger angle</li> </ul> if the <b>MASTER/SLAVE LOCK</b> flag is on, then <ul style="list-style-type: none"> <li>a) turns on the <b>LOCK PENDING</b> flag</li> <li>b) the switch occurs upon completion of the current cam</li> </ul>

In this example, if the **LOCK PENDING** flag is on at the moment the switch is executed, the result of the switch is that the cam start/end pointers will be realigned and the lock will still occur when the master angle crosses the trigger angle.

In this example, if the **LOCK PENDING** flag is off at the moment the switch is executed (the master angle has already crossed the trigger angle), the current cam will be completed and then the switch will occur.

**RETURNS:**

None.

**sys\_fault****SYNTAX:**

*label* sys\_fault

**PARAMETERS:**

None.

**DESCRIPTION:**

Stop execution of the program and set the system fault bit in the DeltaMax status word.

An **f\_decel** instruction is executed for all controllers.

**RETURNS:**

None.

**sys\_return****SYNTAX:**

*label* sys\_return

**PARAMETERS:**

None.

**DESCRIPTION:**

Stop execution of the program and set the system return bit in the DeltaMax status word.

An **f\_decel** instruction is executed for all controllers.

**RETURNS:**

None.

**text****SYNTAX:**

label text "ASCII string"

**PARAMETERS:**

<u>Name</u>	<u>Description</u>
string	ASCII string (enclosed in quotes).

**DESCRIPTION:**

Defines a string of characters for use with the **print** and **input** instructions.

Control and special keyboard characters which cannot be typed may be used by entering the decimal equivalent of the ASCII character(s) enclosed in '<' and '>'.

This instruction requires a 'label'.

**RETURNS:**

None.

**track\_spd****SYNTAX:**

*label* track\_spd controller#,speed

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC
speed	Desired speed.	-5800 to +5800 RPM	IE, IC, IV

**DESCRIPTION:**

The specified controller tracks (changes to) the speed indicated. All speed changes occur at the previously set accel/decel rate. The speed may be changed at any time.

This instruction sets the controller status flags **BUSY** and **JOGGING**. These flags remain set until a **f\_decel** instruction causes the motor to reach zero speed.

This instruction will be ignored if the controller has not received a **drive\_on** instruction, or if the controller is busy executing a motion instruction. If the instruction cannot be executed, the axis status flag **COMMAND INVALID IN THIS STATE** will be set. This flag will automatically be cleared by the controller at the next communication between the main processor and the axis controller. This occurs automatically every 100 milliseconds even if no program instruction directs communication to occur.

**RETURNS:**

None.

**trap\_pos****SYNTAX:**

*label* trap\_pos controller#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC

**DESCRIPTION:**

When the hardware interrupt signal on the controller is detected, the current position will be saved immediately.

This position can be retrieved later using the **get\_trap\_pos** instruction.

EXAMPLE

```
hwi_armed_1 equ 91 ! interrupt armed flag
.
.
enable_hwi
trap_pos 1
```

! wait for indication that position has been trapped

```
loop
if_stat_on hwi_armed_1,loop
get_trap_pos 1,pos
.
```

**RETURNS:**

None.

**turn\_off****SYNTAX:**

*label* turn\_off I/O flag#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
I/O flag#	Output module number.	16 to 23	IE, IC

**DESCRIPTION:**

Causes the specified I/O flag to be turned off.

The **turn\_off** instruction cannot be used for output flag positions equipped with input modules.

**RETURNS:**

None.

**turn\_on****SYNTAX:**

*label* turn\_on I/O flag#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
I/O flag#	Output module number.	16 to 23	IE, IC

**DESCRIPTION:**

Causes the specified I/O flag to be turned on.

The **turn\_on** instruction cannot be used for output flag positions equipped with input modules.

**RETURNS:**

None.

**unlock****SYNTAX:**

*label* unlock controller#,mode#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1	IE, IC
mode#	unlock method	0 or 1	IE, IC

**DESCRIPTION:**

Terminate the master/slave or CAM lock.

Using 'mode' 0, the controller will decelerate to zero speed at the previously set accel/decel rate.

Using 'mode' 1, the controller will unlock from the master, but will continue to run at the last commanded speed. It will not decelerate until it is commanded to do so using the **f\_decel** instruction.

**RETURNS:**

None

**vel\_ccw****SYNTAX:**

*label* vel\_ccw controller#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC

**DESCRIPTION:**

The specified controller accelerates and runs in a counter-clockwise direction at the previously set accel/decel rate and speed. The current accel/decel rate is divided by 256 before acceleration begins.

Accel/decel rate and speed may be modified while executing the **vel\_ccw** instruction.

This instruction sets the controller status flags **BUSY** and **JOGGING**. These flags remain set until a **f\_decel** instruction causes the motor to reach zero speed.

This instruction will be ignored if the controller has not received a **drive\_on** instruction, or if the controller is busy executing a motion instruction. If the instruction cannot be executed, the axis status flag **COMMAND INVALID IN THIS STATE** will be set. This flag will automatically be cleared by the controller at the next communication between the main processor and the axis controller. This occurs automatically every 100 milliseconds even if no program instruction directs communication to occur.

**RETURNS:**

None.

**vel\_cw****SYNTAX:**

*label* vel\_cw controller#

**PARAMETERS:**

<u>Name</u>	<u>Description</u>	<u>Range</u>	<u>Type Allowed</u>
controller#	controller id#	1 or 2	IE, IC

**DESCRIPTION:**

The specified controller accelerates and runs in a clockwise direction at the previously set accel/decel rate and speed. The current accel/decel rate is divided by 256 before acceleration begins.

Accel/decel rate and speed may be modified while executing the **vel\_cw** instruction.

This instruction sets the controller status flags **BUSY** and **JOGGING**. These flags remain set until a **f\_decel** instruction causes the motor to reach zero speed.

This instruction will be ignored if the controller has not received a **drive\_on** instruction, or if the controller is busy executing a motion instruction. If the instruction cannot be executed, the axis status flag **COMMAND INVALID IN THIS STATE** will be set. This flag will automatically be cleared by the controller at the next communication between the main processor and the axis controller. This occurs automatically every 100 milliseconds even if no program instruction directs communication to occur.

**RETURNS:**

None.

## Analog Functions

```

!-----
! TITLE:      Analog Functions
!
! DATE:       12/8/97
!
! DESCRIPTION: This program outputs an analog signal which changes in
!              amplitude from 0 Vdc to +5 Vdc and does so cyclically.
!              The output is verified by hardwiring it to an input and
!              monitoring that input.
!
!              Hardware is wired in the following manner:
!              ch1 = ch 3
!
! EQUIPMENT:  DeltaMax
!
! COMMANDS:   analog_in      analog_out      analog_rt
!             analog_zo      clr_sys_error
!
! The above commands are commonly used in many programs.  This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program.  While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.  An illegal
! argument has been purposefully set in the following example so as to
! make use of the 'clr_sys_error' instruction.
!-----

!-----
!
! Declare constants and variables
!-----

!
! Axis related constants
!
ANALOG      equ      3      ! Analog controller card
CHANNEL_IN  equ      1      ! Analog input channel.
CHANNEL_OUT equ      3      ! Analog output channel.

!
! I/O and Flags
!
SYS_OK      equ      16     ! System okay (output)
TIMER       equ      72     ! Timer to create time
!           delays.
ERROR       equ      144    ! Flag used when system error
!           is executed.

```

```

!
! Variable definitions
!
rate            integer      ! The slew rate used for the analog
!                               channels.
change         integer      ! The incremental change for the analog
!                               output.
alog_out       integer      ! Defines the value in bits of the analog
!                               output.
alog_in        integer      ! Defines the value in bits of the analog
!                               input.
diff           integer      ! Stores the difference between two
!                               variables.
time           integer      ! The time used to create a delay.

!-----
!
! Initialize variables
!
!-----

Defaults       let          rate=1023
                let          change=256
                let          alog_out=0
                let          time=20

!-----
!
! Setup a software interrupt when a system error occurs, a flag is set
! when an error (illigal argument) occurs.
!
!-----
                swi_if_on    0,ERROR,Clr_err ! go to subroutine 'Clr_err'
                                ! when an error occurs
                enable_swi

!-----
!
! Program Setup
! Define the analog zero and slew rates for the channels.
!
!-----

Setup          analog_zo    ANALOG,CHANNEL_IN,0
                gosub      Delay
                analog_rt   ANALOG,CHANNEL_IN,rate
                analog_rt   ANALOG,CHANNEL_OUT,rate
                gosub      Delay

!-----
!
! Main body of the program.
! Adjust the analog output by an incremental amount.
! Wait for the output to settle.
! Measure the analog input and compare the values.

```

```

! If out of range then stop system, otherwise continue in Loop.      -
!                                                                    -
!-----
Main          turn_on          SYS_OK
Loop          let              alog_out=alog_out+change
              if              alog_out<=1024,Adjust_Out  ! '=' creates an
                                                ! illegal argument
              let              alog_out=0
Adjust_Out    analog_out      ANALOG,CHANNEL_OUT,alog_out
              gosub           Delay
              analog_in      ANALOG,CHANNEL_IN,alog_in
              let            diff=alog_out-alog_in
              let            diff=abs(diff)
              if             diff<50,Loop
              turn_off       SYS_OK
              sys_fault

!-----
!                                                                    -
! Subroutine used to create a time delay.                             -
! Wait until the timer times out.                                    -
!                                                                    -
!-----
Delay         set_tmr          TIMER,time
Wait_Time    if_tmr_on        TIMER,Wait_Time
              return_sub

!-----
!                                                                    -
! Subroutine used to clear an illegal argument.A timer is used so that -
! the error is displayed on the seven segment display,for approx. 2secs.-
!                                                                    -
!-----
Clr_err      set_tmr          73,200
Wait_Time1   if_tmr_on        73,Wait_Time1
              clr_sys_error   ERROR

Wait_Time2   set_tmr          73,200
              if_tmr_on        73,Wait_Time2
              enable_swi
              return_sub

```

## CAMS with switch\_cam

```

!-----
! TITLE:          CAMS with switch_cam
!
! DATE:           12/3/97
!
! DESCRIPTION:    This program uses two distinct CAMs to illustrate
!                 the use of a 'switch_cam' and other associated cam
!                 functions.  Software interrupts are used to demonstrate
!                 the ability to change cams on the fly, as well as
!                 the ability to reposition and lock a cam at a
!                 different point.
!
! EQUIPMENT:      DeltaMax
!
! COMMANDS:       begin_cam          cam          cam_data
!                 clr_flag          end_cam      f_decel
!                 get_cam_cnt       get_cam_end  get_cam_ptr
!                 get_cam_strt     get_map     get_map_stat
!                 get_mcf          get_mcf_stat if_flag_off
!                 if_flag_on       if_io_off   if_stat_on
!                 lock             restart_at   set_cam_ptr
!                 set_flag         set_map     set_mcf
!                 switch_cam       sys_fault   sys_return
!                 turn_off         turn_on     unlock
!
! The above commands are commonly used in many programs.  This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program.  While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.
!-----

```

```

                declare          on

```

```

!-----
!
! Declare constants and variables
!-----

```

```

!
! Axis related constants
!

```

```

PEN          equ          1
PSEUDO       equ          2

BUSY         equ          78          ! busy flag offset
DOWN        equ          77          ! down flag offset
PEN_BUSY     equ          (PEN*16)+BUSY  ! busy flag - PEN
PSEUDO_BUSY equ          (PSEUDO*16)+BUSY ! busy flag - PSEUDO
PEN_DOWN     equ          (PEN*16)+DOWN   ! down flag - PEN
PEN_SWITCH   equ          81          ! lock pending - PEN

```

```

UNLK_MODE_0    equ          0          ! unlock mode 0

LK_MODE_0     equ          0          ! lock at start of cam
LK_MODE_5     equ          5          ! lock within the cam
MS            equ          6          ! 64 master bits/cam element
DS            equ          0          ! cam el = cam el * 2^0
PSEUDO_MABA   equ          10         ! PSEUDO sends data to
! MABA
MABA_TALKER   equ          30         ! PSEUDO is talker on MABA

MABA_LISTEN   equ          23         ! PEN is listener on MABA
END_CAM       equ          128        ! Value for end of cam

!
! I/O and Flags
!

SWITCH_RQST   equ          0          ! Request to switch cam (input)
REPEAT        equ          1          ! Repeat section of cam
! (input)
RESET         equ          6          ! Reset a PEN fault (input)
SYS_OK        equ          16         ! System okay (output)

TIMER         equ          72         ! Timer for fixed delay.

IN_CAM_FWD    equ          254        ! Flag to indicate current
! cam.
SWITCH        equ          255        ! Flag to indicate a switch
! request.

!
! Variable definitions
!

speed         integer       ! Defines the speed of the PSEUDO.
length        integer       ! Determines the length of the cam.

start         integer       ! Starting location of cam.
cam_start     integer       ! Return variable for cam starting
! location.
cam_end       integer       ! Return variable for cam ending
! location.
number_el     integer       ! Number of cam elements.
count         integer       ! Return variable for number of cam
! cycles.
pointer       integer       ! Return variable for the cam pointer.

new_pointer   integer       ! The variable used to reposition the
! cam pointer.
last_el       integer       ! Defines the location of the last
! cam element.
temp          integer       ! Used as a temporary storage variable.
ctr           integer       ! Used as a loop counter.
ctr2          integer       ! Used as a loop counter.
time          integer       ! Determines the delay time for a

```

```

!
! timer.
time2      integer    ! Determines the delay time for a
! timer.
map        integer    ! Used to configure the MASTER/SLAVE on
! the MAB.
map_back   integer    ! Return variable for the current 'map'
! setup.
map_stat   integer    ! map_stat = 0 if map OK, <> 0 if error.
mcf        integer    ! Used to configure the PSEUDO.

mcf_stat   integer    ! mcf_stat = 0 if map OK, <> 0 if error.
mcf_back   integer    ! Return variable for the current 'mcf'
! setup.
!
!
! Cam tables and data arrays
!

pen_cams    dim        PEN,200

forward_cam begin_cam
cam         64,64,64,64,64,64,64,64
cam         64,64,64,64,64,64,64,64
cam         64,64,64,64,64,64,64,64

cam         64,64,64,64,64,64,64,64
cam         64,64,64,64,64,64,64,64
cam         64,64,64,64,64,64,64,64
cam         64,64,64,64,64,64,64,64
cam         64,64,64,64,64,64,64,64
cam         64,64,64,64,64,64,64,64
cam         64,64,64,64,64,64,64,64
cam         64,64,64,64,64,64,64,64
cam         64,64,64,64,64,64,64,64

cam         64,64,64,64,64,64,64,64
cam         64,64,64,64,64,64,64,64
cam         64,64,64,64,64,64,64,64
cam         64,64,64,64,64,64,64,64
cam         -32,-32,-32,-32,-32,-32,-32,-32
cam         -32,-32,-32,-32,-32,-32,-32,-32
cam         -32,-32,-32,-32,-32,-32,-32,-32
cam         -32,-32,-32,-32,-32,-32,-32,-32
cam         -32,-32,-32,-32,-32,-32,-32,-32

cam         -32,-32,-32,-32,-32,-32,-32,-32
cam         -32,-32,-32,-32,-32,-32,-32,-32
cam         -32,-32,-32,-32,-32,-32,-32,-32
cam         0,0,0,0,0,0,0,0
cam         0,0,0,0,0,0,0,0
cam         0,0,0,0,0,0,0,0
cam         0,0,0,0,0,0,0,0
cam         0,0,0,0,0,0,0,0
end_cam

reverse_cam begin_cam
cam         -32,-32,-32,-32,-32,-32,-32,-32

```

```

cam      -32, -32, -32, -32, -32, -32, -32, -32
cam      -32, -32, -32, -32, -32, -32, -32, -32
cam      -32, -32, -32, -32, -32, -32, -32, -32
cam      -32, -32, -32, -32, -32, -32, -32, -32
cam      -32, -32, -32, -32, -32, -32, -32, -32
cam      -32, -32, -32, -32, -32, -32, -32, -32
cam      -32, -32, -32, -32, -32, -32, -32, -32
cam      -32, -32, -32, -32, -32, -32, -32, -32

cam      -32, -32, -32, -32, -32, -32, -32, -32
cam      -32, -32, -32, -32, -32, -32, -32, -32
cam      -32, -32, -32, -32, -32, -32, -32, -32
cam      -32, -32, -32, -32, -32, -32, -32, -32
cam      -32, -32, -32, -32, -32, -32, -32, -32
cam      -32, -32, -32, -32, -32, -32, -32, -32
cam      -32, -32, -32, -32, -32, -32, -32, -32
cam      64, 64, 64, 64, 64, 64, 64, 64

cam      64, 64, 64, 64, 64, 64, 64, 64
cam      64, 64, 64, 64, 64, 64, 64, 64
cam      64, 64, 64, 64, 64, 64, 64, 64
cam      64, 64, 64, 64, 64, 64, 64, 64
cam      64, 64, 64, 64, 64, 64, 64, 64
cam      64, 64, 64, 64, 64, 64, 64, 64
cam      0, 0, 0, 0, 0, 0, 0, 0
cam      0, 0, 0, 0, 0, 0, 0, 0

cam      0, 0, 0, 0, 0, 0, 0, 0
cam      0, 0, 0, 0, 0, 0, 0, 0
end_cam

```

```

!-----
!
! Initialize variables
!
!-----

```

```

Defaults      let      speed=100
               let      time=1
               let      time2=50

```

```

!-----
!
! Program Setup
! Define axis motion parameters.
! Configure map.

! Load cam tables into pen_cams array.
! Define software interrupts.
!
!-----

```

```

Setup      set_ac_dc      PSEUDO,100

```

```

        set_ac_dc      PEN,400

        gosub          Set_Config
        gosub          Load_Cams

        swi_if_on     0,PEN_DOWN,Fault

        swi_if_on     1,SWITCH_RQST,Make_Switch
        swi_if_on     2,REPEAT,Reposition_Cam
        enable_swi

!-----
!
! Main body of program
! Enable PEN.
! Start motion.

! Check conditons for a 'switch_cam'.
! If switch is not correct then stop system.
! Get information about current cam.
! Remain in Loop, waiting for software interrupts.
!
!-----
Main      turn_on      SYS_OK

          drive_on     PEN

          lock         PEN,LK_MODE_0
          track_spd    PSEUDO,speed

Loop      if_flag_off  SWITCH,Continue
          if_stat_on   PEN_SWITCH,Continue
          get_cam_strt PEN,cam_start
          get_cam_end  PEN,cam_end
          let          number_el=cam_end-cam_start
          let          number_el=number_el+1
          if           number_el<>length, System_Halt
          clr_flag     SWITCH

Continue  get_cam_ptr   PEN,pointer
          get_cam_cnt  PEN,count
          set_tmr      TIMER,time

Delay     if_tmr_on    TIMER,Delay
          goto         Loop

!-----
!
! Software Interrupt Routine indicating a request to switch cams.
! Test for current cam and switch to alternate cam.

! Set the flag that indicates a cam switch has occurred.
! Enable the software interrupts and return.
!
!-----

```

```

Make_Switch      if_flag_on      IN_CAM_FWD,Switch_Reverse
                 set_flag        IN_CAM_FWD
                 let              start=0
                 let              length=208

                 switch_cam      PEN,start,length
                 goto             Exit_Switch

Switch_Reverse   no_op
                 clr_flag        IN_CAM_FWD
                 let              start=208
                 let              length=208
                 switch_cam      PEN,start,length

Exit_Switch      set_flag        SWITCH
                 enable_swi
                 return_sub

!-----
!
! Software Interrupt Routine used to repeat a section of the current cam.-
! Stop the PEN.
! Wait for a short period of time.
! Reposition the cam pointer then start again.
! Enable the software interrupts and return.
!-----

Reposition_Cam  no_op
                 unlock          PEN,UNLK_MODE_0
Wait_Busy       if_stat_on      PEN_BUSY,Wait_Busy

                 set_tmr        TIMER,time2
Wait_Time       if_tmr_on      TIMER,Wait_Time

                 let            new_pointer=128
                 if             pointer<128,Cont_Repos
                 let            new_pointer=0

Cont_Repos      set_cam_ptr     PEN,new_pointer
                 lock           PEN,LK_MODE_5
                 enable_swi

                 return_sub

!-----
!
! Software Interrupt Routine used for a PEN fault condition.
! Turn off the System Ok output.
! Check to see that all motion has stopped.
! Wait for reset input, then restart at Main.
!-----

```

```

Fault      no_op
           turn_off      SYS_OK
           f_decel       PEN
           f_decel       PSEUDO
Wait_Busy1 if_stat_on      PEN_DOWN,Wait_Busy2
           if_stat_on      PSEUDO_BUSY,Wait_Busy1

Wait_Busy2 if_stat_on      PSEUDO_BUSY,Wait_Busy2

Start_Over if_io_off      RESET,Start_Over

           drive_off      PEN
           enable_swi
           restart_at     Main

```

```

!-----
!
! Subroutine used when an incorrect switch occurs.
! Turn off the System Ok output.
! Check to see that all motion has stopped.

! Disable PEN drive, and indicate a system fault on the System Status.
!
!-----

```

```

System_Halt no_op
            turn_off      SYS_OK
            f_decel       PEN
            f_decel       PSEUDO
Wait_Busy3  if_stat_on      PEN_BUSY,Wait_Busy3
            if_stat_on      PSEUDO_BUSY,Wait_Busy3

            drive_off      PEN

            sys_fault

```

```

!-----
!
! Subroutine to configure the MAB map and the MCF map.
! Set the appropriate bits, and check the results.
!
!-----

```

```

Set_Config let      map=0
           set_map   map
           set_bit   MABA_TALKER,map
           set_bit   MABA_LISTEN,map
           set_map   map
           get_map   map_back
           get_map_stat map_stat

           if      map_stat<>0,Config_Fail
           if      map<>map_back,Config_Fail

```

```

Config_Pseudo  let          mcf=0
                set_mcf     PSEUDO,mcf

                set_bit     PSEUDO_MABA,mcf
                set_mcf     PSEUDO,mcf
                get_mcf     PSEUDO,mcf_back
                get_mcf_stat PSEUDO,mcf_stat

                if          mcf_stat<>0,Config_Fail
                if          mcf<>mcf_back,Config_Fail

Exit_Config    return_sub

Config_Fail    sys_return

!-----
!
! Subroutine to load cams into pen_cams array.          -
! Load each cam consecutively into the array.         -
! The last element in the array needs to indicate the end of the cam. -
! Execute a cam_data command to load the axis with the cam information.-
! Immediately switch to a subset of the array which will be the      -
! equivalent of the forward_cam table.                  -
!-----

Load_Cams      no_op
                let          ctr=0
                let          length=208
                let          last_el=length
Load_Forward   let_byte    temp=forward_cam[ctr]
                let_byte    pen_cams[ctr]=temp
                let          ctr=ctr+1
                if          ctr<last_el,Load_Forward

Load_Reverse   let          ctr2=0
                let_byte    temp=reverse_cam[ctr2]
                let_byte    pen_cams[ctr]=temp

                let          ctr=ctr+1
                let          ctr2=ctr2+1
                if          ctr2<last_el,Load_Reverse
                let_byte    pen_cams[ctr]=END_CAM

                cam_data    PEN,pen_cams,MS,DS
                let          start=0
                let          length=208
                switch_cam  PEN,start,length
                set_flag    IN_CAM_FWD

                return_sub

```

## Clock Simulation

```

!-----
! TITLE:      Clock Simulation
!
! DATE:       12/4/97
!
! DESCRIPTION: This program functions as a fictitious time clock
!              operating on either military or civilian time.  The
!              program is used to illustrate many of the arithmetic
!              functions of the controller.
!
! EQUIPMENT:  DeltaMax
!
! COMMANDS:  clr_bit          declare          equ
!            gosub           goto            if
!            if_bit_clr      if_bit_set       if_tmr_on
!            integer         let             no_op
!            return_sub      set_bit         set_tmr
!
! The above commands are commonly used in many programs.  This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program.  While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.
!-----
                declare          on
!-----
!
! Declare constants and variables
!-----
TYPE          equ          0          ! Bit used to indicate
!                                     clock type
! TYPE=1 for Military; TYPE=0 for Civilian
TIMER        equ          72         ! Timer used for delays
clock        integer
!                                     ! The variable used for
!                                     clock type
second       integer          ! Counter indicates # of
!                                     seconds
minute       integer          ! Counter indicates # of
!                                     minutes
hour         integer          ! Counter indicates # of
!                                     hours
ticks        integer          ! # of 10 msec clock ticks
!-----
!
! Initialize variables
!-----

```

```

Defaults      let          second=0
              let          minute=0

! Using a 20 msec clock for demonstration purposes.

              let          ticks=2

!-----
!
! Program Setup
! Check the type of clock previously used and toggle the bit.
! The clock type alternates each time the program is restarted by
! cycling power to the DeltaMax.
! The program starts on a Military type clock whenever a reset command
! is issued from the Analyzer.
!-----

Setup         no_op
Set_Clk_Type  if_bit_set      TYPE,clock,Set_Civilian

Set_Military  set_bit        TYPE,clock
              goto          Main

Set_Civilian  clr_bit        TYPE,clock
              let          hour=12

!-----
!
! Main body of program.
! The clock counters are incremented appropriately.
! The hour is incremented based on the bit 'TYPE'.
!-----

Main         no_op

Start_Clk     no_op
Time_Seconds gosub          One_Second
              let          second=second+1

if           second<60,Time_Seconds
              let          second=0

Time_Minutes let          minute=minute+1
              if          minute<60,Time_Seconds
              let          minute=0

Time_Hours    no_op
Military_Type if_bit_clr    TYPE,clock,Civilian_Type
              let          hour=hour+1
              if          hour<24,Time_Seconds
              let          hour=0
              goto          Time_Seconds

Civilian_Type let          hour=hour+1
              if          hour<13,Time_Seconds
              let          hour=1
              goto          Time_Seconds

```

```
!-----  
!  
! Subroutine used to delay a specified amount of time.      -  
!   For demonstration purposes timer will be 20 msec.      -  
!  
!-----
```

```
One_Second      set_tmr          TIMER,ticks  
Wait_Sec        if_tmr_on       TIMER,Wait_Sec  
  
                return_sub
```

## DeviceNet without Parameter Object

```

!-----
! TITLE:          DeviceNet without Parameter Object
!
! DESCRIPTION:    This program runs a simple 'track_spd' to test a DeviceNet
!                connection. The CAN bus is configured for DeviceNet via the
!                'can_set' at address 1. It is intended that the user may stop
!                and start the motor over DeviceNet with DeviceNet input 1.
!                Once started the motor speed may be changed over DeviceNet by
!                writting to the spd variable in the program. The example EDS
!                file in the appendix is written to match this program.
!
! EQUIPMENT:     DeltaMax
!
! COMMANDS:      can_set          clr_dnet
!                dnet_range      if_dnet_on
!                if_dnet_off     set_dnet
!
! The above commands are commonly used in many programs.  This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program.  While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.
!-----

                declare          on

DNET            equ              2

MOTOR          equ              1
BUSY           equ              78
DOWN           equ              77
OFF            equ              67
MOTOR_OFF      equ              (MOTOR*16)+OFF
MOTOR_BUSY     equ              (MOTOR*16)+BUSY
MOTOR_DOWN     equ              (MOTOR*16)+DOWN

DNET_ENABLE    equ              128      !equate for the DeviceNet enabled flag
DNET_FAULT     equ              129      !equate for the DeviceNet fault flag
DNET_INPUT1    equ              32       !equate for DeviceNet input 1 for do
                                         trackspd
DNET_OUTPUT1   equ              56       !equate for DeviceNet output 1 for
MOTOR_BUSY

!***** variables to have write access over DeviceNet
spd            integer
acdc           integer
multplr        integer
divisor        float

!**** delta_comp variables
lim            integer
pg             integer
ffwd           integer

```

```

!**** motor axis variables
com          integer
pos          integer

!**** can_set variables
canid        integer
canbaud      integer
canarb       integer

!**** application variables
angle        integer
div_angle    float
mult_angle   integer
can_faults   integer

!*****DEVICENET INITIALIZATION*****
begin_cfg
dnet_range   spd,divisor
end_cfg
!*****PROGRAM VARIABLE INITIALIZATIONS*****
let          spd=100
let          acdc=200
let          divisor=1
let          multplr=1
let          canid=-1
let          canbaud=-1
let          canarb=DNET

wait_dneten  can_set      canid,canbaud,canarb
if_stat_off  128,wait_dneten      ! verify devicenet enabled

!*****MOTOR AXIS INITIALIZATION*****
drive_on     MOTOR
set_speed    MOTOR,spd
set_ac_dc    MOTOR,acdc

!*****SOFTWARE INTERRUPT INITIALIZATIONS*****
swi_if_on    0,DNET_FAULT,CanFaulted
enable_swi

!*****MAIN PROGRAM Loop*****
Main         if_dnet_on    DNET_INPUT1,run_trackspd
            if_dnet_off   DNET_INPUT1,run_fdecel

run_trackspd gosub          DoTrackSpeed
            goto          calcs
run_fdecel   gosub          ForceDecel

calcs        get_com       MOTOR,com
            get_pos       MOTOR,pos

pos          let          angle=pos&4095          ! get present angle from
            let          div_angle=angle/divisor  ! divide angle

```

```

        let          mult_angle=angle*multplr      ! multiple angle

        if_stat_on   MOTOR_BUSY,set_out1
        clr_dnet     DNET_OUTPUT1
        goto         Main
set_out1  set_dnet   DNET_OUTPUT1
        goto         Main

```

```

!*****
!*****SUBROUTINES*****
!*****

```

```

!**** Force Decel Subr.*****
ForceDecel  if_stat_off  MOTOR_BUSY,skipfdecel
            f_decel     MOTOR
skipfdecel  return_sub

```

```

!**** Track Speed Subr.*****
DoTrackSpeed
            if_stat_off  MOTOR_OFF,gotrack
            drive_on     MOTOR

gotrack     set_ac_dc    1,acdc
            track_spd    MOTOR,spd

            return_sub

```

```

!*****
!*****INTERRUPT ROUTINES*****
!*****

```

```

!**** CanBus faulted
!**** Description: Tries to clear bus_off condition due to a
!                   possible DeviceNet Network error, for a
!                   limited number of times.
CanFaulted  disable_swi
            let          can_faults=can_faults+1
            if          can_faults>10,skipcanset
            can_set     canid,canbaud,canarb
skipcanset  enable_swi
            return_sub

```

## DeviceNet with Parameter Object

```

!-----
! TITLE:          DeviceNet with Parameter Object
!
! DESCRIPTION:    This program runs a simple 'track_spd' to test a DeviceNet
!                connection. A DeviceNet Parameter Object is programmed at the
!                beginning of the program. It is intended that a DeviceNet
!                Manager Utility program may automatically create an EDS file
!                from this example program running in a DeltaMax. A Parameter
!                Object in a DeviceNet device is readable by such Utility
!                programs as Allen Bradley's DeviceNet Manager™.
!
! EQUIPMENT:     DeltaMax
!
! COMMANDS:      begin_cfg          dnet_flag_pm
!                dnet_flt_pm       dnet_int_pm
!                dnet_p_code       end_cfg
!
! The above commands are commonly used in many programs. This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program. While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.
!-----

```

```

                declare          on
DNET            equ             2
MOTOR          equ             1
BUSY           equ             78
DOWN           equ             77
OFF            equ             67
DRV1_OFF      equ             83
MOTOR_OFF     equ             (MOTOR*16)+OFF
MOTOR_BUSY    equ             (MOTOR*16)+BUSY
MOTOR_DOWN    equ             (MOTOR*16)+DOWN
DNET_ENABLE   equ             128          !equate for the DeviceNet enabled flag
DNET_FAULT    equ             129          !equate for the DeviceNet fault flag
DNET_INPUT1   equ             32          !equate for DeviceNet input 1 for do
                trackspd
DNET_INPUT2   equ             33          !equate for DNet Input 2 to turn drive
off
DNET_OUTPUT1  equ             56          !equate for DeviceNet output 1 for
MOTOR_BUSY
RUN_BIT       equ             255
! variables to have write access over DeviceNet
spd           integer
acdc          integer
time         integer
multplr      float
divisor      float

```

```

! motor axis variables
com          integer
pos          integer
time_strt   integer
get_tm      integer
tmp_tm      integer

run_text     text          "run input"
div_text     text          "float divisor"
spd_text     text          "speed in rpm"
acdc_text    text          "accel"
time_text    text          "runtime (msec)"
ID_text      text          "Dnet Eamle"
DrvOff_text  text          "MonetaryDriveOff"

!*****DEVICENET PARAMETER INITIALIZATION*****

                begin_cfg                !this is the first executable
                                                instr.
devicenet      dnet_p_code      10,ID_text      !define devicenet product code
                dnet_range      spd,divisor     !define read/write memory for

                dnet_int_pm      time,time_text,10,100,10
                dnet_flt_pm      divisor,div_text,1.0,100.0,10.5
                dnet_int_pm      spd,spd_text,10,1000,100
                dnet_int_pm      acdc,acdc_text,10,100,50
                dnet_flag_pm     DNET_INPUT1,run_text
                dnet_flag_pm     DNET_INPUT2,DrvOff_text
                can_set          -1,125,2
                end_cfg

!*****DEFINE SWI (s)*****
                swi_if_on        0,DNET_INPUT1,TurnDriveOn
                swi_if_off       2,DNET_INPUT1,Stop
                swi_if_on        1,DNET_INPUT2,TurnDriveOff

                enable_swi

!*****PROGRAM VARIABLE INITIALIZATIONS*****
                let              multplr=1
                get_time         time_strt

!*****PROGRAM START*****
                drive_on        1

wait_dneten    if_stat_off      128,wait_dneten    ! verify devicenet enabled

loop           get_time         get_tm
                let              tmp_tm = get_tm - time_strt
                let              tmp_tm = tmp_tm * 5
                if_flag_on       RUN_BIT,Trackspeed
                let              time = 0
                goto             loop

```

```
Trackspeed      let          time = tmp_tm
                 set_ac_dc    1,acdc
                 track_spd    1,spd
                 goto         loop

done            goto         done

!*****SWI: TurnDriveOn*****
TurnDriveOn     if_stat_off   DRV1_OFF,skip_drvon
                 drive_on     1
skip_drvon      get_time      time_strt
                 set_flag     RUN_BIT
                 enable_swi
                 return_sub

Stop           f_decel        1
                 clr_flag     RUN_BIT
                 enable_swi
                 return_sub

TurnDriveOff    drive_off     1
                 clr_flag     RUN_BIT
                 enable_swi
                 return_sub
```

## Home Sequence

```

!-----
! TITLE:          Home Sequence
!
! DATE:           12/5/97
!
! DESCRIPTION:    This program illustrates a homing sequence for a resolver
!                 based system.  After the homing sequence has been
!                 initiated, the operator can execute either an index
!                 or a positional move.
!
! EQUIPMENT:      DeltaMax
!
! COMMANDS:       disable_swi          index          jog_ccw
!                 jog_cw              mod_index      mod_position
!                 position            set_ac_dc      set_gl_ccw
!                 set_gl_cw          set_speed     set_swi_mask
!
! The above commands are commonly used in many programs.  This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program.  While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.
!-----

                declare          on

!-----
!
! Declare constants and variables
!-----

!
! Axis related constants
!
XFR              equ          1          ! Transfer axis
BUSY             equ          78         ! busy flag offset
DOWN            equ          77         ! down flag offset
XFR_BUSY        equ          (XFR*16)+BUSY ! busy flag - Transfer
XFR_DOWN        equ          (XFR*16)+DOWN ! down flag - Transfer

!
! I/O and Flags
!
INIT            equ          0          ! Initialize axis (input)
INDEX           equ          1          ! Start index (input)

POSITION        equ          2          ! Position to zero (input)
MOD_IDX         equ          3          ! Start modified index (input)
MOD_POS         equ          4          ! Start modified position (input)

```

```

DIR                equ            5            ! ON=CCW; OFF=CW (input)
ZREV               equ            6            ! Zero rev switch (input)
RESET             equ            7            ! Reset Fault (input)
SYS_OK            equ            16           ! System okay (output)

TIMER             equ            72           ! Timer used for delays

INIT_CMPT         equ            255         ! Flag for initialization
!               complete

!
! Motion related constants
!

INIT_SPD          equ            200         ! Initialize jog speed
INIT_ACDC         equ            200         ! Initialize accel/decel
!               rate
IDX_SPD           equ            800         ! Index speed
IDX_ACDC          equ            300         ! Index accel/decel rate
POS_SPD           equ            300         ! Position speed
POS_ACDC          equ            200         ! Position accel/decel rate
IDX_DIST          equ            40960       ! Index distance = 10 turns
IDX_DIST1        equ            20480       ! Index distance = 5 turns
HOME              equ            0           ! Absolute home
POS1              equ            -20480      ! position to -5 turns
DEG               equ            4           ! degree for modified profiles

!
! Variable definitions
!

time              integer          ! Determines the delay time for a timer.
swi_mask          integer          ! Determines the active software
!               interrupts.

!-----
!
! Initialize variables
!-----

Defaults          let              time=100
                  let              swi_mask=63

!-----
!
! Program Setup
! Define software interrupts.
!-----

Setup             swi_if_on         0,INIT,Home_Xfr
                  swi_if_on         1,INDEX,Index_Xfr
                  swi_if_on         2,POSITION,Position_Xfr
                  swi_if_on         3,MOD_IDX,Mod_Idx_Xfr
                  swi_if_on         4,MOD_POS,Mod_Pos_Xfr
                  swi_if_on         5,XFR_DOWN,Fault

                  enable_swi

```

```

!-----
!
! Main body of program.
! Enable XFR.
! Remain in Loop, waiting for software interrupts.
!-----

Main          clr_flag          INIT_CMPT
              turn_on          SYS_OK
              drive_on         XFR
              delta_comp       XFR,1.0,1.0,30,0,1.0,6000

Loop          goto             Loop

!-----
!
! Software Interrupt Routine to Home XFR axis.
! Setup software interrupt mask to only allow XFR_DOWN to be active.
! Define XFR motion parameters.
! Test to determine direction of home sequence.
! Test ZREV switch for current state.
! If on the switch, must jog off switch to start.
! Jog toward the ZREV switch and monitor the state of the IO.
! When ZREV turns on, stop and set a global zero according to the
! HOME direction.
! Position the XFR to HOME.
! Set the flag INIT_CMPT.
! Enable software interrupts and return.
!-----

Home_Xfr      let              swi_mask=32
              set_swi_mask    swi_mask
              enable_swi

              set_speed       XFR,INIT_SPD
              set_ac_dc       XFR,INIT_ACDC
              if_io_on        DIR,Find_Home_Ccw

Find_Home_Cw  if_io_off       ZREV,Off_Switch_Cw
              jog_ccw        XFR

On_Switch_Cw  if_stat_on      XFR_DOWN,Fault
              if_io_on       ZREV,On_Switch_Cw
              f_decel        XFR
              gosub          Wait_Stop

Off_Switch_Cw jog_ccw        XFR
              if_stat_on     XFR_DOWN,Fault
              if_io_off      ZREV,Off_Switch_Cw
              set_gl_ccw     XFR
              f_decel        XFR
              gosub          Wait_Stop
              goto           Xfr_At_Home

```

```

Find_Home_Ccw  if_io_off      ZREV,Off_Switch_Ccw
                jog_cw        XFR

On_Switch_Ccw  if_stat_on      XFR_DOWN,Fault
                if_io_on      ZREV,On_Switch_Ccw
                f_decel       XFR
                gosub         Wait_Stop

Off_Switch_Ccw jog_ccw        XFR

                if_stat_on      XFR_DOWN,Fault
                if_io_off      ZREV,Off_Switch_Ccw
                set_gl_ccw     XFR
                f_decel       XFR
                gosub         Wait_Stop

Xfr_At_Home    position       XFR,HOME
                gosub         Wait_Stop

Exit_Home_Xfr  set_flag        INIT_CMPT
                disable_swi
                let           swi_mask=63
                set_swi_mask  swi_mask
                enable_swi
                return_sub

```

```

!-----
!
! Software Interrupt Routine to Index the XFR 10 turns.
! Setup software interrupt mask to only allow XFR_DOWN to be active.
! Check to see that INIT_CMPT has been set.
!   If not skip index.
! Define axis motion parameters.
! Index XFR 10 turns.
! Wait for index to complete.
! Enable software interrupts
!
!-----

```

```

Index_Xfr      let           swi_mask=32
                set_swi_mask  swi_mask
                enable_swi

                if_flag_off    INIT_CMPT,Exit_Index
                set_speed      XFR,IDX_SPD
                set_ac_dc      XFR,IDX_ACDC
                index          XFR,IDX_DIST
                gosub         Wait_Stop

Exit_Index     disable_swi
                let           swi_mask=63
                set_swi_mask  swi_mask
                enable_swi
                return_sub

```

```

!-----
!
! Software Interrupt Routine to Position XFR to HOME.
! Setup software interrupt mask to only allow XFR_DOWN to be active.
! Check to see that INIT_CMPT has been set.
!   If not skip position.
! Define axis motion parameters.
! Position XFR to HOME.
! Wait for index to complete.
! Enable software interrupts
!-----

```

```

Position_Xfr   let           swi_mask=32
               set_swi_mask  swi_mask
               enable_swi

               if_flag_off    INIT_CMPT,Exit_Position
               set_speed      XFR,POS_SPD
               set_ac_dc      XFR,POS_ACDC

               position       XFR,HOME
               gosub          Wait_Stop

```

```

Exit_Position  disable_swi
               let           swi_mask=63
               set_swi_mask  swi_mask
               enable_swi
               return_sub

```

```

!-----
!
! Software Interrupt Routine to use a modified index to XFR 5 turns.
! Setup software interrupt mask to only allow XFR_DOWN to be active.
! Check to see that INIT_CMPT has been set.
!   If not skip index.
! Define axis motion parameters.
! Index XFR 5 turns.
! Wait for index to complete.
! Enable software interrupts
!-----

```

```

Mod_Idx_Xfr    let           swi_mask=32
               set_swi_mask  swi_mask
               enable_swi

               if_flag_off    INIT_CMPT,Exit_Mod_Idx
               mod_index      XFR,IDX_SPD,IDX_ACDC,IDX_DIST1,DEG
               gosub          Wait_Stop

```

```

Exit_Mod_Idx   disable_swi
               let           swi_mask=63
               set_swi_mask  swi_mask
               enable_swi
               return_sub

```

```

!-----
!
! Software Interrupt Routine to Position XFR to -5 turns using a
!   modified profile.
! Setup software interrupt mask to only allow XFR_DOWN to be active.
! Check to see that INIT_CMPT has been set.
!   If not skip position.
! Define axis motion parameters.
! Position XFR to -5 turns.
! Wait for index to complete.
! Enable software interrupts
!-----

Mod_Pos_Xfr      let          swi_mask=32
                  set_swi_mask swi_mask
                  enable_swi

                  if_flag_off  INIT_CMPT,Exit_Mod_Pos
                  set_speed     XFR,POS_SPD
                  set_ac_dc     XFR,POS_ACDC

                  mod_position  XFR,POS_SPD,POS_ACDC,POS1,DEG
                  gosub         Wait_Stop

Exit_Mod_Pos     disable_swi
                  let          swi_mask=63
                  set_swi_mask swi_mask
                  enable_swi
                  return_sub

!-----
!
! Subroutine to wait for motion to be completed.
!-----

Wait_Stop       if_stat_on   XFR_BUSY,Wait_Stop ! check for axis busy
                  return_sub

!-----
!
! Software Interrupt Routine used for a XFR fault condition.
! Turn off the System Ok output.
! Check to see that all motion has stopped.
! Wait for reset input, then restart at Main.
!-----

```

---

Fault	no_op	
	turn_off	SYS_OK
	f_decel	XFR
Wait_Fault	set_tmr	TIMER,200
	if_tmr_on	TIMER,Wait_Fault
Start_Over	if_io_off	RESET,Start_Over
	drive_off	XFR
	let	swi_mask=63
	set_swi_mask	swi_mask
	enable_swi	
	restart_at	Main

## Index with over\_draw

```

!-----
! TITLE:      Index with over_draw
!
! DATE:       12/8/97
!
! DESCRIPTION: This program illustrates the two overdraw modes and the
!              differences between them. The operator can observe
!              these differences by manually selecting the overdraw
!              mode and then triggering the sensor input during the
!              execution of the index.
!
! EQUIPMENT:  DeltaMax
!
! COMMANDS:  clr_local      disable_hwi      drive_off
!            drive_on       enable_hwi      get_com
!            get_pos        get_trap_pos    if_io_on
!            if_stat_off    over_draw      set_local
!            set_ovd_mode
!
! The above commands are commonly used in many programs. This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program. While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.
!-----

                declare      on

!-----
!
! Declare constants and variables
!-----

!
! Axis related constants
!
FEED            equ          1
BUSY            equ          78      ! busy flag offset
DOWN           equ          77      ! down flag offset
ARMED          equ          75      ! HWI armed flag
!                                     offset
INDEXING       equ          73      ! indexing flag offset

FEED_BUSY      equ          (FEED*16)+BUSY  ! busy flag - FEED
FEED_DOWN      equ          (FEED*16)+DOWN  ! down flag - FEED
FEED_ARMED     equ          (FEED*16)+ARMED  ! HWI armed flag -
!                                     FEED
FEED_INDEXING  equ          (FEED*16)+INDEXING ! indexing flag -
!                                     FEED
!

```

```

OD_MODE_0      equ      0      ! Overdraw mode - sensor always
!              active

OD_MODE_1      equ      1      ! Overdraw mode - sensor only
!              active during porch

!
! I/O and Flags
!

SENSOR         equ      0      ! Photo sensor (input)
INDEX          equ      1      ! Start index (input)
OVD_MODE       equ      2      ! Select overdraw mode
!              (input)
RESET          equ      6      ! Reset Fault (input)

SYS_OK         equ      16     ! System okay (output)

TIMER         equ      72     ! Timer used for delays.

!
! Variable definitions
!

com            integer     ! Stores the current 'get_com' value.
pos            integer     ! Stores the current 'get_pos' value.
tpos          integer     ! Stores the current 'get_trap_pos' value.
diff          integer     ! Variable used to measure differences.
end_com       integer     ! Used to store the ending com value.

end_pos       integer     ! Used to store the ending pos value.
temp          integer     ! Used as a temporary storage location.
idx_dist      integer     ! The index distance.
ovd_speed     integer     ! The speed at which the search occurs.
srch_dist     integer     ! The distance to search for sensor.
post_dist     integer     ! The distance travelled after the sensor
!              trips.

!-----
!
! Initialize variables
!
!-----

Defaults      let          ovd_speed=25
               let          srch_dist=8192
               let          post_dist=1024
               let          idx_dist=40960

!-----
!
! Program Setup
! Define FEED motion parameters.
!
!-----

```

```

Setup          set_ac_dc      FEED,50
               set_speed    FEED,200

!-----
!
! Main body of program
! Enable DRAW.
! Remain in Loop, waiting for transition on INDEX.
!-----

Main          drive_on      FEED

Loop          if_io_on      INDEX,Loop
Loop1         if_io_off     INDEX,Loop1
              if_io_on      OVD_MODE,Mode_1

!-----
!
! Routine for overdraw mode 0 (HWI is always active).
! Clear any local zero.
! Check status of HWI armed flag.
!   If flag on disarm HWI, otherwise continue.
! Setup the HWI for an overdraw of mode 0.
! Set a local zero in order to have an accurate start point.
! Make sure the FEED HWI is armed.
! Index the FEED and wait until motion is complete.
! Based on the status of the FEED_ARMED flag, determine if the
!   distances are correct.
!-----

Mode_0        clr_local      FEED
              if_stat_off   FEED_ARMED,No_Disable
              disable_hwi   FEED

No_Disable    set_ovd_mode   FEED,OD_MODE_0
              set_local     FEED

              enable_hwi
              over_draw     FEED,ovd_speed,srch_dist,post_dist

Not_Armed     if_stat_off   FEED_ARMED,Not_Armed

              index         FEED,idx_dist
              gosub         Wait_Stop

              if_stat_on    FEED_ARMED,Check_Dist
              get_com       FEED,end_com
              if            end_com>=idx_dist,Loop
              turn_off     SYS_OK
              sys_fault

```

```

Check_Dist      get_com      FEED,end_com
                 let          temp=idx_dist+srch_dist
                 if           end_com=temp,Loop

                 turn_off     SYS_OK
                 sys_fault

!-----
!
! Routine for overdraw mode 1 (HWI is only active in overdraw porch).
! Clear any local zero.
! Check status of HWI armed flag.
!   If flag on disarm HWI, otherwise continue.
! Setup the HWI for an overdraw of mode 1.
! Set a local zero in order to have an accurate start point.
! Make sure the FEED HWI is armed.
! Index the FEED and wait until motion is complete.
! Based on the status of the FEED_ARMED flag, determine if the
!   distances are correct.
!-----

Mode_1          clr_local     FEED
                 if_stat_off  FEED_ARMED,No_Disable1
                 disable_hwi  FEED

No_Disable1    set_ovd_mode  FEED,OD_MODE_1
                 set_local    FEED
                 get_pos       FEED,pos

                 enable_hwi
                 over_draw     FEED,25,8192,1024

Not_Armed1     if_stat_off  FEED_ARMED,Not_Armed1

                 index        FEED,40960

                 gosub        Wait_Stop

                 if_stat_on   FEED_ARMED,Check_Dist1
                 get_com      FEED,end_com
                 get_trap_pos  FEED,tpos
                 let          diff=end_com-tpos
                 if           diff=1024,Loop
                 turn_off     SYS_OK
                 sys_return

Check_Dist1    get_com      FEED,end_pos
                 let          temp=idx_dist+srch_dist

                 if           end_pos<>temp,Check_Dist1
                 if           end_pos=temp,Loop
                 turn_off     SYS_OK
                 sys_return

```

```

!-----
!
! Routine used for a FEED fault condition.
! Turn off the System Ok output.
! Check to see that all motion has stopped.
! Wait for reset input, then restart at Main.
!
!-----

```

```

Fault          no_op
               turn_off      SYS_OK
               f_decel       FEED

Wait_Fault     set_tmr        TIMER,200
               if_tmr_on    TIMER,Wait_Fault

Start_Over     if_io_off    RESET,Start_Over
               drive_off   FEED

               restart_at   Main

```

```

!-----
!
! Routine used to wait for motion to stop on FEED.
! Check the DOWN and INDEXING flags, and when index is complete return.
!
!-----

```

```

Wait_Stop     no_op
               if_stat_on   FEED_DOWN,Fault
               if_stat_on   FEED_INDEXING,Wait_Stop
               return_sub

```

## Programmable Limit Switch Functions

```

!-----
! TITLE:      Programmable Limit Switch Functions
!
! DATE:       12/8/97
!
! DESCRIPTION: This program demonstrates the Programmable Limit Switch
!              (PLS) functions. These functions include defining PLS,
!              PLS masking and creating an angular offset. Each of these
!              functions can be visually observed during program
!              execution.
!
! EQUIPMENT:  DeltaMax
!
! COMMANDS:  clr pls          get_pls_ang      get_pls_mask
!            get_pls_out     l track spd      preset
!            set_pls_ang     set_pls_cnt      set_pls_mask
!            track_spd
!
! The above commands are commonly used in many programs. This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program. While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.
!-----

                declare      on

!-----
!
! Declare constants and variables
!-----

!
! Axis related constants
!
PSEUDO      equ      2
PLS         equ      2

CALC_PLS    equ      106      ! Calculating flag on PLS

PSEUDO_MABA equ      10      ! PSEUDO sends data to
!                          MABA
PLS_MABA    equ      16      ! PLS receives data from
!                          MABA

MASTER      equ      30      ! Define PSEUDO as master
SLAVE       equ      22      ! Define PLS as slave

!
! I/O and Flags
!

```

```

DO_MASK      equ      0      ! Define output mask (input)

CLR_PLS      equ      1      ! Create an offset (input)
OFFSET       equ      2      ! Create an offset (input)
SYS_OK       equ      23     ! System okay (output)

TIMER        equ      72     ! Timer used for delays

FIRST_TIME   equ      251    ! Flag indicating first
!                                     time

!
! Variable definitions
!

map          integer     ! Used to configure the MASTER/SLAVE on
!                       the MAB.
map_back     integer     ! Return variable for the current 'map'
!                       setup.
map_stat     integer     ! Return variable for the current 'map'
!                       status.
mcf          integer     ! Used to configure the PSEUDO.
mcf_stat     integer     ! Current multi-function control
!                       status
mcf_back     integer     ! Return variable for the current 'mcf'
!                       setup.
on_angle     integer     ! The angle to turn on a module.

off_angle    integer     ! The angle to turn off a module.
hw_pls       integer     ! Used to define modules 16-19.
sw_pls       integer     ! Used to define modules 24-27.
clr_this_pls integer     ! Used to clear modules 16-19 and 24-27.
out_stat     integer     ! Return variable for 'get_pls_out'.
angle        integer     ! Return variable for 'get_angle'.
pls_cnt      integer     ! Define the counts per PLS cycle
time         integer     ! Determines the delay time for a timer.
mask         integer     ! Used to mask off specific pls modules.
com          integer

mask_back    integer     ! Return variable for 'get_pls_mask'.
offset       integer     ! The amount of offset added to the MAB.

!-----
!
! Initialize variables
!
!-----

Defaults    let          on_angle=0
            let          off_angle=1023
            let          hw_pls=16
            let          sw_pls=24
            let          clr_this_pls=16
            let          pls_cnt=8192
            let          mask=4294901760

```

```

!-----
!
! Program Setup
! Define the PLS parameters.
! Define axis motion parameters.
! Define software interrupts.
!-----

```

```

Define_Pls      gosub      Set_Config
                set_pls_cnt  PLS,pls_cnt
                gosub      Wait_Calc

                set_pls_ang  PLS,on_angle,off_angle,hw_pls

                gosub      Wait_Calc

                set_pls_ang  PLS,on_angle,off_angle,sw_pls
                gosub      Wait_Calc

                let         on_angle=on_angle+1024
                let         off_angle=off_angle+1024
                let         hw_pls=hw_pls+1
                let         sw_pls=sw_pls+1
                if          hw_pls<20,Define_Pls

                set_ac_dc   PSEUDO,20

                swi_if_on   0,DO_MASK,Define_Mask
                swi_if_on   1,CLR_PLS,Clear_Pls
                swi_if_on   2,OFFSET,Create_Offset
                enable_swi

                set_pls_mask PLS,mask

```

```

!-----
!
! Main body of program
! Start motion.
! Get current angle and PLS output information.
! Remain in Loop, waiting for software interrupts.
!-----

```

```

Main           no_op
                turn_on      SYS_OK
                track_spd    PSEUDO,100
!             l_track_spd    PSEUDO,100
!
! This command could be used in place of a 'track_spd' when slow
! or fractional speeds are required.

Loop           get_pls_out   PLS,out_stat
                get_com      PSEUDO,com
                get_pls_ang   PLS,angle
                gosub      Delay
                goto        Loop

```

```

!-----
!
! Software Interrupt Routine used to define a PLS output mask.
! Test to see if this is the first time executing this routine.
! Setup the PLS mask.
! Check for correct mask.
!   If mask is incorrect then stop system.
! Enable the software interrupts and return.
!-----

```

```

Define_Mask  no_op
              if_flag_on    FIRST_TIME, Skip_First
              let           mask=0
              set_bit       16, mask
              set_flag      FIRST_TIME

Skip_First   set_pls_mask   PLS, mask
              get_pls_mask  PLS, mask_back
              if            mask<>mask_back, Fault_Mask

              let           mask=mask{1
              if_bit_set    20, mask, Start_Hw_Mask
              if_bit_set    28, mask, Start_Sw_Mask
              goto          Exit_Mask

Start_Sw_Mask  clr_bit      28, mask
               set_bit      16, mask
               goto         Exit_Mask

Start_Hw_Mask  clr_bit      20, mask
               set_bit      24, mask
               goto         Exit_Mask

Fault_Mask    turn_off     SYS_OK
               sys_return

Exit_Mask     enable_swi
               return_sub

```

```

!-----
!
! Software Interrupt Routine to create an offset on the MAB.
! Define the amount of offset.
! Enable software interrupts and return.
!-----

```

```

Create_Offset no_op
              preset       PLS, offset
              gosub        Wait_Calc

              enable_swi
              return_sub

```

```

!-----
!
! Software Interrupt Routine to clear the next PLS being used.
! First clear 16-19, then 24-27.
! Enable software interrupts and return.
!-----

```

```

Clear_Pls      no_op
               if          clr_this_pls<28,Do_Clear_Pls
               let          clr_this_pls=16

Do_Clear_Pls   select      clr_this_pls
               case        16
                 clr_pls    2,16
                 exit_select
               case        17
                 clr_pls    2,17
                 exit_select
               case        18
                 clr_pls    2,18
                 exit_select
               case        19
                 clr_pls    2,19
                 exit_select

               case        24
                 clr_pls    2,24
                 exit_select
               case        25
                 clr_pls    2,25
                 exit_select
               case        26
                 clr_pls    2,26
                 exit_select
               case        27
                 clr_pls    2,27
                 exit_select
               end_select

               let          clr_this_pls=clr_this_pls+1

               if          clr_this_pls<20,Exit_Clear_Pls
               let          clr_this_pls=24

Exit_Clear_Pls enable_swi
               return_sub

```

```

!-----
!
! Subroutine to configure the MAB map and the MCF map.
! Set the appropriate bits, and check the results.
!-----

```

```

Set_Config      no_op
                let          mcf=0
                set_mcf      PSEUDO,mcf
                set_bit      PSEUDO_MABA,mcf
                set_bit      PLS_MABA,mcf
                set_mcf      PSEUDO,mcf
                get_mcf      PSEUDO,mcf_back
                get_mcf_stat PSEUDO,mcf_stat

                if          mcf<>mcf_back,Config_Fail
                if          mcf_stat<>0,Config_Fail

                let          map=0
                set_map      map
                set_bit      MASTER,map
                set_bit      SLAVE,map
                set_map      map

Exit_Config     return_sub

Config_Fail     turn_off      SYS_OK
                sys_return

```

```

!-----
!
! Subroutine to monitor the PLS CALCULATING flag.
! Wait until the card is finished calculating.
!-----

```

```

Wait_Calc      no_op
                if_stat_on    CALC_PLS,Wait_Calc
                return_sub

```

```

!-----
!
! Subroutine used to create a time delay.
! Wait until the timer times out.
!-----

```

```

Delay          set_tmr      TIMER,time
Wait_Time      if_tmr_on    TIMER,Wait_Time
                return_sub

```

## Piecewise Profile

```

!-----
! TITLE:      Piecewise Profile
!
! DATE:      12/8/97
!
! DESCRIPTION: This program illustrates the use of a piecewise profile,
!              and the methods by which to execute a profile.  The
!              time to execute the selected profile is compared to the
!              calculated time as a measure of performance.
!
! EQUIPMENT:  DeltaMax
!
! COMMANDS:  exec_profile      get_ms_time      get_pstat
!            get_time          prep_profile      set_trig_pw
!
! The above commands are commonly used in many programs.  This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program.  While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.
!-----

                declare      on

!-----
!
! Declare constants and variables
!-----

!
! Axis related constants
!

FEED      equ      1
MASTER    equ      2

BUSY      equ      78      ! busy flag offset
DOWN      equ      77      ! down flag offset
CALC      equ      74      ! calculating flag offset
LOCK      equ      79      ! lock flag offset
FEED_BUSY equ      (FEED*16)+BUSY ! busy flag - FEED

FEED_DOWN equ      (FEED*16)+DOWN ! down flag - FEED
FEED_CALC equ      (FEED*16)+CALC ! calculating flag - FEED
FEED_LOCK equ      (FEED*16)+LOCK ! lock flag - FEED

LK_MODE_3 equ      3      ! lock mode 3
MABA_TALKER equ      30    ! MASTER is talker on MABA
MABA_LISTEN equ      23    ! FEED is listener on MABA
PSEUDO_MABA equ      10    ! PSEUDO sends data to MABA

```

```

!
! I/O and Flags
!
EXEC_PROF      equ          0          ! Start profile execution
!              (input)
EXEC_TYPE      equ          1          ! Execution type (input)
!              ON=Lock;OFF=Normal
RESET          equ          6          ! Reset Fault (input)
SYS_OK         equ          16         ! System okay (output)

TIMER          equ          72         ! Timer used for delays.

!
! Variable Definitions
!
start_angle    integer      ! The start angle for the Lock to begin.
temp           integer      ! Used as a temporary storage variable.
prof_stat      integer      ! Stores the result of a get_pstat.
diff           integer      ! Stores the difference between two
!              variables.
error          integer      ! The error between measured and
!              calculated time.
exec_time      integer      ! The calculated execution time.

time           integer      ! Determines the delay time for a timer.
strt_time      integer      ! Stores the time value at start of
!              profile.
strt_ms_tm     integer
end_ms_tm      integer
diff_ms        integer

end_time       integer      ! Stores the time value at end of profile.
map            integer      ! Used to configure the MASTER/SLAVE on
!              the MAB.
map_back       integer      ! Returns the current 'map' setup.
map_stat       integer      ! Return the current 'map' status.

mcf            integer      ! Used to configure the PSEUDO.
mcf_back       integer      ! Returns the current 'mcf' setup.
mcf_stat       integer      ! Return the current 'mcf' status.

!
! Data array for piecewise profile
!
prodata        begin_data
                data         500,250,8192
                data         1000,250,8192
                data         250,100,8192
                data         0,100,8192
                end_data

```

```

!-----
!
! Initialize variables
!
!-----
Defaults      let          start_angle=1024
              let          exec_time=210

!-----
!
! Program Setup
! Configure map.
! Prepare piecewise profile.
! Define and enable software interrupts.
!
!-----
Setup         no_op

              gosub        Set_Config
              gosub        Calc_Profile

              swi_if_on     0,FEED_DOWN,Fault
              enable_swi

!-----
!
! Main body of program
! Enable FEED.
! Remain in Loop, waiting for transition on EXEC_PROF to execute
! profile.
!
!-----
Main          turn_on      SYS_OK
              drive_on     FEED
              delta_comp    FEED,1,1,30,0,1,6000

Loop         if_io_on      EXEC_PROF,Loop
Loop1       if_io_off      EXEC_PROF,Loop1
           if_io_on      EXEC_TYPE,With_Lock

!-----
!
! Routine to execute a piecewise profile.
! Execute the piecewise profile.
! Measure the time to complete the profile, and compare to calculated
! time. If not correct stop system.
! Otherwise return to Loop.
!
!-----
Profile      get_time      strt_time
              get_ms_time  strt_ms_tm
              exec_profile FEED
              gosub        Wait_Stop
              get_time      end_time
              get_ms_time   end_ms_tm

```

```

        let          diff=end_time-strt_time
        let          diff_ms=end_ms_tm-strt_ms_tm
        let          error=exec_time-diff
        let          temp=abs(error)
        if           temp<=2,Loop
        turn_off    SYS_OK
        sys_return

!-----
!
! Routine to execute piecewise profile using lock mode 3.
! Define the trigger angle and lock the FEED.
! Wait for motion to stop, and return to Loop.
!-----

With_Lock      set_trig_pw    FEED,start_angle
               lock          FEED,LK_MODE_3
               set_speed     MASTER,100
               set_ac_dc     MASTER,50
               jog_cw        MASTER
               gosub         Wait_Stop
               goto          Loop

!-----
!
! Software Interrupt Routine used for a FEED fault condition.
! Turn off the System Ok output.
! Check to see that all motion has stopped.
! Wait for reset input, then restart at Main.
!-----

Fault          no_op
               turn_off     SYS_OK
               f_decel      FEED
               f_decel      MASTER

Wait_Fault     set_tmr       72,200
               if_tmr_on    72,Wait_Fault

Start_Over     if_io_off    RESET,Start_Over
               drive_off    FEED
               enable_swi
               restart_at   Main

!-----
!
! Subroutine to configure the MAB map.
! Set the appropriate bits, and check the results.
!-----

```

```

Set_Config      let          map=0
                set_map     map
                set_bit     MABA_TALKER, map
                set_bit     MABA_LISTEN, map
                set_map     map
                get_map     map_back
                get_map_stat map_stat

                let          mcf=0
                set_mcf     MASTER, mcf

                set_bit     PSEUDO_MABA, mcf
                set_mcf     MASTER, mcf
                get_mcf     MASTER, mcf_back
                get_mcf_stat MASTER, mcf_stat

                if          map_stat<>0, Config_Fail
                if          map<>map_back, Config_Fail
                if          mcf_stat<>0, Config_Fail
                if          mcf<>mcf_back, Config_Fail

Exit_Config     return_sub

Config_Fail     sys_return

```

```

!-----
!
! Subroutine used to prepare the piecewise profile.
! Prepare the piecewise profile.
! Check the profile status. If correct return, otherwise stop program.
!
!-----

```

```

Calc_Profile   prep_profile   FEED, prodata

Calc_Busy      if_stat_on     FEED_CALC, Calc_Busy

                get_pstat    FEED, prof_stat
                if          prof_stat=0, Exit_Calc
                sys_fault

Exit_Calc      return_sub

```

```

!-----
!
! Subroutine used to create a time delay.
! Wait for timer to time out and return.
!
!-----

```

```

Delay          set_tmr       TIMER, time
Wait_Time      if_tmr_on     TIMER, Wait_Time
                return_sub

```

```
!-----  
!  
! Subroutine to wait for motion to be completed.      -  
!  
!-----  
Wait_Stop      no_op  
                if_stat_on      FEED_BUSY,Wait_Stop ! check for axis busy  
                return_sub
```

## Ratio Lock

```

!-----
! TITLE:      Ratio Lock
!
! DATE:       12/8/97
!
! DESCRIPTION: This program uses the fiber optic input channel as the
!              master data. The lock is a simple ratio lock, meaning
!              that the slave will track the master proportional to the
!              currently set ratio. With the use of the Analyzer, the
!              values of the ratio can be changed on the fly and when
!              the CHG_RATIO input is triggered, the new ratio will take
!              effect.
!
! EQUIPMENT:  DeltaMax
!
! COMMANDS:  delta_comp      digi_comp      get_act_spd
!            get_fol_err     get_for_ang   get_for_spd
!            ratio
!
! The above commands are commonly used in many programs. This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program. While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.
!-----

                declare      on

!-----
!
! Define constants and variables
!-----

!
! Axis related constants
!

SHEER      equ      1
FIBER      equ      2

BUSY       equ      78
DOWN       equ      77
SHEER_BUSY equ      (SHEER*16)+BUSY

SHEER_DOWN equ      (SHEER*16)+DOWN

LK_MODE_1  equ      1
FIBER_MABA equ      8      ! FIBER sends data to MABA
MABA_TALKER equ     30     ! FIBER is talker on MABA
MABA_LISTEN equ     23     ! SHEER is listener on MABA

!

```

```

! I/O and Flags
!
CHG_RATIO      equ      0      ! Input to change ratio.
RESET          equ      6      ! Input to reset a SHEER
!                               fault.

SYS_OK         equ      16     ! Output indicating system
!                               ok.

TIMER          equ      72     ! Timer used to create
!                               delays.
VG_CHK         equ      255    ! Flag indicating vgain
!                               set.

!
! Variable definitions
!
time           integer      ! Determines the delay time for a timer.

map            integer      ! Used to configure the MASTER/SLAVE on
!                               the MAB.
map_back       integer      ! Return variable for the current 'map'
!                               setup.
map_stat       integer      ! Return variable for the current 'map'
!                               status.
mcf            integer      ! Used to configure the FIBER.
mcf_back       integer      ! Return variable for the current 'mcf'
!                               setup.

mcf_stat       integer      ! Return variable for the current 'mcf'
!                               status.
ratio          integer      ! The current master/slave ratio.
aj2            integer      ! The load inertia mismatch.
aj3            integer      ! The high frequency response.
aj4            integer      ! The position gain in the system.
aj7            integer      ! The zero speed gain of the system.
aj8            integer      ! The velocity feed forward.
aj9            integer      ! The notch filter.
angle          integer      ! Stores the current fiber optic angle.
angle2         integer      ! Stores the old fiber optic angle.
error          integer      ! Stores the amount of following error.
temp           integer      ! Used as a temporary storage location.
scale          integer      ! The scale factor for the ratio.

sheer_spd      integer      ! The current SHEER speed.
cur_f_spd      integer      ! The current fiber optic speed.
new_f_spd      integer      ! The fiber optic speed scaled by the
!                               ratio.

!-----
!
! Initialize variables
!
!-----

```

```

Defaults      let          ratio=4096
              let          time=1
              let          aj2=1
              let          aj3=1
              let          aj4=30
              let          aj7=0
              let          aj8=1
              let          aj9=6000

!-----
!
! Program Setup
! Define axis motion parameters.
! Configure map.
! Wait for motion on fiber optic channel.
! Define software interrupts.
!
!-----

Setup         set_ac_dc      SHEER,400
              gosub        Set_Config
              get_for_ang   FIBER,1,angle

Wait_Angle    no_op
              get_for_ang   FIBER,1,angle2
              if            angle2=angle,Wait_Angle

              swi_if_on     0,SHEER_DOWN,Fault
              swi_if_on     1,CHG_RATIO,New_Ratio
              enable_swi

!-----
!
! Main body of program
! Enable SHEER.
! Get information about current speeds.
! Wait until speeds are the same, then check for vgain.
! If vgain has been set continue in Loop, otherwise calculate vgain.
!
!-----

Main          turn_on      SYS_OK
              drive_on     SHEER
              digi_comp     1,32,0,0
              ratio         SHEER,ratio
              lock          SHEER,LK_MODE_1
              let           scale=ratio*100
              let           scale=scale/4096

Loop          get_act_spd   SHEER,sheer_spd
              get_for_spd   FIBER,1,cur_f_spd
              get_fol_err    SHEER,error
              let           new_f_spd=cur_f_spd*scale

              let           new_f_spd=new_f_spd/100
              set_tmr        TIMER,time

```

```

Delay          if_tmr_on      TIMER,Delay
               if              sheer_spd<>new_f_spd,Loop
               if_flag_on     VG_CHK,Loop
               delta_comp     SHEER,aj2,aj3,aj4,aj7,aj8,aj9
               goto           Loop

!-----
!
! Software Interrupt Routine used for a SHEER fault condition.
! Turn off the System Ok output.
! Check to see that all motion has stopped.
! Wait for reset input, then restart at Main.
!
!-----

Fault          no_op
               turn_off      SYS_OK

               f_decel       SHEER

Wait_Fault     set_tmr        TIMER,200
               if_tmr_on     TIMER,Wait_Fault

Start_Over     if_io_off     RESET,Start_Over
               drive_off    SHEER
               enable_swi
               restart_at    Main

!-----
!
! Subroutine to configure the MAB map and the MCF map.
! Set the appropriate bits, and check the results.
!
!-----

Set_Config     let          map=0
               set_map      map
               set_bit      MABA_TALKER,map
               set_bit      MABA_LISTEN,map
               set_map      map
               get_map      map_back
               get_map_stat  map_stat

               if          map_stat<>0,Config_Fail
               if          map<>map_back,Config_Fail

Config_Pseudo  let          mcf=0
               set_mcf      FIBER,mcf

               set_bit      FIBER_MABA,mcf
               set_mcf      FIBER,mcf
               get_mcf      FIBER,mcf_back
               get_mcf_stat  FIBER,mcf_stat

               if          mcf_stat<>0,Config_Fail
               if          mcf<>mcf_back,Config_Fail

Exit_Config    return_sub

Config_Fail    sys_return

```

```
!-----  
!  
! Software Interrupt Routine used to change curretn ratio. -  
! Implement new ratio and scaling. -  
! Enable interrupts and return. -  
!  
!-----
```

```
New_Ratio      ratio      SHEER,ratio  
               let        scale=ratio*100  
               let        scale=scale/4096  
               enable_swi  
               return_sub
```

## CAMS with calc\_unit\_cam

```

!-----
! TITLE:          CAMS with calc_unit_cam
!
! DATE:          12/3/97
!
! DESCRIPTION:   This program implements the 'calc_unit_cam' feature to
!               calculate a cam of specified length.  The lock method
!               demonstrated is mode 9, which causes the slave to lock
!               at a specific angle of the master.  This particular lock
!               method unlocks after completing one cam cycle.  In this
!               program the lock will be reinitiated each time the cam
!               cycle is completed.
!
! EQUIPMENT:    DeltaMax
!
! COMMANDS:     begin_data          calc_cam_sum          calc_unit_cam
!               data                data_scale             dim
!               dim(card)          enable_swi             end_data
!               get_cam_sum        get_angle              let_byte
!               master_scale       set_trig_cam           swi_if_off
!               swi_if_on
!
! The above commands are commonly used in many programs.  This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program.  While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.
!-----

```

```

                declare          on

```

```

!-----
!
! Declare constants and variables
!-----

```

```

!
! Axis related constants
!

```

```

DRAW          equ          1
MASTER        equ          2

BUSY          equ          78          ! busy flag offset
DOWN          equ          77          ! down flag offset
CALC          equ          74          ! calculating flag offset
LOCK          equ          79          ! lock flag offset
DRAW_BUSY     equ          (DRAW*16)+BUSY ! busy flag - DRAW
DRAW_DOWN     equ          (DRAW*16)+DOWN ! down flag - DRAW
DRAW_CALC     equ          (DRAW*16)+CALC ! calculating flag - DRAW
DRAW_LOCK     equ          (DRAW*16)+LOCK ! lock flag - DRAW

MS            equ          6          ! 1/64

```

```

DS                equ            0            ! no multiply
LK_MODE_9        equ            9            ! lock mode 9
MABA_TALKER      equ            30           ! MASTER is talker on MABA
MABA_LISTEN      equ            23           ! DRAW is listener on MABA

!
!  I/O and Flags
!
SET_M_SCALE      equ            0            ! Change the master scale
SET_D_SCALE      equ            1            ! Change the data scale
RESET            equ            6            ! Reset Fault (input)
SYS_OK           equ            16           ! System okay (output)

TIMER            equ            72           ! Timer used for delays.

!
!  Variable Definitions
!

angle            integer         ! The angle of the master axis.
distance         integer         ! Defines the distance of the cam.
start_cam       integer         ! The position in memory to start the cam.
end_cam         integer         ! The ending position of the cam in memory.
num_elements    integer         ! The number of cam elements.
m_scale         integer         ! Defines the master scale.
d_scale         integer         ! Defines the data scale.

sum             integer         ! The sum of all the cam elements.
start_angle     integer         ! The start angle for the Lock to begin.
tmp             integer         ! Used as a temporary storage variable.
ctr             integer         ! Used as a loop counter.
ctr2            integer         ! Used as a loop counter.
time            integer         ! Determines the delay time for a timer.
time2           integer         ! Determines the delay time for a timer.
map             integer         ! Used to configure the MASTER/SLAVE on
!                               the MAB.
map_back        integer         ! Return variable for the current 'map'
!                               setup.
map_stat        integer         ! Return variable for the current 'map'
!                               status.
mcf             integer

!
!  Data arrays and unit cam table
!

cam             dim             DRAW,6750
table           dim             DRAW,130
copy            dim             300

trap            begin_data
data            0,14,87,205,357
data            568,744,976,1227,1496
data            1789,2097,2422,2761,3117
data            3487,3671,4267,4677,5100
data            5535,5882,6440,6909,7390
data            7661,8380,8890,9410,9940

```

```

data          10480,11030,11588,12153,12728
data          13310,13902,14501,15109,15725
data          16349,16961,17620,18266,18919
data          19579,20246,20919,21596,22281
data          22968,23659,24355,25052,25753
data          26454,27155,27856,28557,29258
data          29959,30660,31361,32062,32763
data          33464,34165,34866,35567,36288
data          36969,37670,38371,39072,39773
data          40474,41171,41867,42560,43247
data          43930,44609,45282,45949,46609
data          47262,47908,48547,49179,49803
data          50419,51027,51626,52218,52800
data          53375,53940,54498,55048,55586
data          56118,56638,57148,57647,58138
data          58619,59088,59546,59993,60428
data          60851,61261,61657,62041,62441
data          62767,63106,63431,63739,64030
data          64301,64552,64784,64990,65171
data          65323,65441,65514,65536,65536
end_data

!-----
!
! Initialize variables
!-----

Defaults      let          distance=16384
              let          num_elements=300
              let          start_cam=0
              let          end_cam=num_elements-1
              let          start_angle=1024
              let          m_scale=MS
              let          d_scale=DS

!-----
!
! Program Setup
! Setup the unit cam table.
! Configure map.
! Define and enable software interrupts.
!-----

Setup         no_op

              gosub          Setup_Unit_Cam
              gosub          Set_Config

              swi_if_on      0,DRAW_DOWN,Fault
              swi_if_off    1,DRAW_LOCK,Lock_Ang
              swi_if_on      2,SET_M_SCALE,New_m_scale
              swi_if_on      3,SET_D_SCALE,New_d_scale
              enable_swi

```

```

!-----
!
! Main body of program
! Enable DRAW.
! Setup DRAW for lock in mode 9.
! Get status for DRAW.
! Remain in Loop, waiting for software interrupts.
!-----
Main      turn_on      SYS_OK
          drive_on    DRAW
          delta_comp  DRAW,1.0,1.0,30,0,1.0,6000  ! default values
          cam_data    DRAW,cam,MS,DS

          set_trig_cam DRAW,start_angle
          lock        DRAW,LK_MODE_9

Loop      no_op
          get_angle   DRAW,angle
          goto        Loop

!-----
!
! Software Interrupt Routine indicating that the cam has completed
! and the DRAW has been unlocked.
! Lock the DRAW axis in mode 9.
! Enable the software interrupts and return.
!-----
Lock_Ang  no_op
          set_trig_cam DRAW,start_angle
          lock        DRAW,LK_MODE_9
          enable_swi
          return_sub

!-----
!
! Software Interrupt Routine used for a DRAW fault condition.
! Turn off the System Ok output.
! Check to see that all motion has stopped.
! Wait for reset input, then restart at Main.
!-----
Fault     no_op
          turn_off    SYS_OK
          f_decel     DRAW

Wait_Fault set_tmr      TIMER,200
          if_tmr_on   TIMER,Wait_Fault

Start_Over if_io_off    RESET,Start_Over
          drive_off  DRAW
          enable_swi
          restart_at Main

```

```

!-----
!
! Subroutine to configure the MAB map.
! Set the appropriate bits, and check the results.
!-----

Set_Config      let          map=0
                set_map     map
                set_bit     MABA_TALKER, map
                set_bit     MABA_LISTEN, map
                set_map     map
                get_map     map_back
                get_map_stat map_stat

                let          mcf=0
                set_mcf     MASTER, mcf
                set_bit     8, mcf
                set_mcf     MASTER, mcf

                if          map_stat<>0, Config_Fail
                if          map<>map_back, Config_Fail

Exit_Config     return_sub

Config_Fail     sys_return

!-----
!
! Subroutine to prepare and create the unit cam.
! Clear the contents of the cam array.
! Load the unit cam array into memory on DRAW.
! Calculate the cam based on the distance, starting location, and
!   number of elements.
! Calculate the cam sum and compare it to the desired distance.
!   If the sum does not equal the distance, then stop system.
! To observe the cam elements they are loaded into memory on the MSC.
!-----

Setup_Unit_Cam no_op
                let          ctr=0
Clr_Cam         let          cam[ctr]=0
                let          ctr=ctr+1
                if          ctr<6750, Clr_Cam

Load_Table     let          ctr=0
Load_Loop      let          tmp=trap[ctr]
                let          table[ctr]=tmp
                let          ctr=ctr+1
                if          ctr<130, Load_Loop

Calc_Busy      calc_unit_cam DRAW, distance, num_elements, start_cam
                if_stat_on  DRAW_CALC, Calc_Busy

                calc_cam_sum DRAW, start_cam, end_cam

```

```

Sum_Busy      if_stat_on      DRAW_CALC, Sum_Busy
              get_cam_sum     DRAW, sum
              if              sum=distance, Copy

Calc_Err      sys_fault

Copy          let              ctr=0
Load_Copy     let_byte        tmp=cam[ctr]
              let_byte        copy[ctr]=tmp
              let              ctr=ctr+1
              if              ctr<300, Load_Copy
              return_sub

```

```

!-----
!
! Subroutine to modify the master scale of the cam
! Each time the routine is executed the master scale will toggle.
!
!-----

```

```

New_m_scale   no_op
              if              m_scale=6, Change_5
              let              m_scale=6
              master_scale     DRAW, m_scale
              goto            Ex_m_scale

Change_5      let              m_scale=5
              master_scale     DRAW, m_scale

Ex_m_scale    enable_swi
              return_sub

```

```

!-----
!
! Subroutine to modify the data scale of the cam
! Each time the routine is executed the data scale will toggle.
!
!-----

```

```

New_d_scale   no_op
              if              d_scale=0, Change_1
              let              d_scale=0
              data_scale       DRAW, d_scale
              goto            Ex_d_scale

Change_1      let              d_scale=1
              data_scale       DRAW, d_scale

Ex_d_scale    enable_swi
              return_sub

```

## I/O Functions

```

!-----
! TITLE:      I/O functions
!             bus to select a particular type of motion.
!
! DATE:       12/5/97
!
! EQUIPMENT:  Hardware is wired in the following manner;
!             DeltaMax
!
!             Outputs  Inputs
!             IO#16 -> IO#0
!             IO#17 -> IO#1
!             IO#18 -> IO#2
!
! COMMANDS:  blk_io_in      blk_io_out      if_tmr_off
!             vel_ccw       vel_cw
!
! The above commands are commonly used in many programs.  This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program.  While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.
!-----

                declare      on

!-----
!
!   Declare constants and variable
!-----

!
!   Axis related constants
!

ROLL_1          equ          1

BUSY            equ          78
DOWN           equ          77
ROLL_1_BUSY    equ          (ROLL_1*16)+BUSY

ROLL_1_DOWN    equ          (ROLL_1*16)+DOWN

!
!   I/O and Flags
!

BLK_OUT        equ          16      ! start of output IO block
!                                     (8 IO's)
BLK_IN         equ          0      ! start of input IO block
!                                     (8 IO's)
RESET          equ          8      ! Reset Fault (input)
TIMER         equ          72      ! Timer Flag

```

```

!
!   Variable Definition
!
code           integer           ! output variable to IO
!                               ! block
copy           integer           ! input variable to IO
!                               ! block
ac_dc          integer           ! acceleration, deceleration
!                               ! ratio
speed          integer           ! speed
time_delay     integer           ! variable carrying
!                               ! required delay
ctr            integer           ! array indexer (counter)

!
!   Array Definition
!
c_array        begin_data        ! array with codes (binary)
               data              1,2,3,4
               end_data

!-----
!
!   Initialize variables
!-----
!-----

Defaults      no_op
               let               ac_dc=89
               let               speed=200
               let               ctr=0

!-----
!
!   Program Setup
!   Define ROLL_1 motion parameters.
!   Define and enable software interrupt.
!-----
!-----

Setup         no_op
               set_ac_dc         ROLL_1,ac_dc  ! set accel. decel. for
!                               ! roll 1
               set_speed         ROLL_1,speed  ! set speed for roll 1

               swi_if_on         0,ROLL_1_DOWN,Fault
               enable_swi

```

```

!-----
!
!      Main body of the program.
!      Send a binary code from array through the output IO's.
!      Read code into 'copy' through the 8 input IO's
!      Compare and direct to motion routine.
!      Increment array counter, get next value and loop again.
!-----
Main          no_op
              drive_on          ROLL_1

Start         no_op
              let                code=c_array[ctr]
              blk_io_out        BLK_OUT,code

              let                time_delay=0
              gosub             Delay

Block_Read   no_op
              let                time_delay=2000
              blk_io_in        BLK_IN,copy
              if                copy=1,Run_Roll1
              if                copy=2,Run_Roll2
              if                copy=3,Run_Roll1ccw
              if                copy=4,Run_Roll2ccw
              goto             Block_Read

Run_Roll1    no_op
              vel_cw            ROLL_1
              gosub             Delay
              f_decel          ROLL_1

Wait_Stop1   no_op
              if_stat_on        ROLL_1_BUSY,Wait_Stop1
              goto             Do_Next

Run_Roll2    no_op
              jog_cw            ROLL_1
              gosub             Delay
              f_decel          ROLL_1

Wait_Stop2   no_op
              if_stat_on        ROLL_1_BUSY,Wait_Stop2
              goto             Do_Next

Run_Roll1ccw no_op
              vel_ccw          ROLL_1
              gosub             Delay
              f_decel          ROLL_1

Wait_Stop1ccw no_op
              if_stat_on        ROLL_1_BUSY,Wait_Stop1ccw
              goto             Do_Next

Run_Roll2ccw no_op
              jog_ccw          ROLL_1
              gosub             Delay
              f_decel          ROLL_1

```

```

Wait_Stop2ccw  no_op
                if_stat_on      ROLL_1_BUSY,Wait_Stop2ccw
                goto            Do_Next

Do_Next        no_op
                let             ctr=ctr+1
                if              ctr>3,Program_End
                goto            Start

Program_End    no_op
                let             ctr=0
                goto            Start

```

```

!-----
!
! Subroutine used to create a time delay.
! Wait until the timer times out.
!-----

```

```

Delay          no_op
                set_tmr         TIMER,time_delay
Wait_Tmr       if_tmr_off      TIMER,Exit_Delay
                goto            Wait_Tmr

Exit_Delay     no_op
                return_sub

```

```

!-----
!
! Software Interrupt Routine used for a ROLL_x fault condition.
! Turn off the System Ok output.
! Check to see that all motion has stopped.
! Reset 'ctr' and place controller in test mode.
! Wait for reset input, then restart at Main.
!-----

```

```

Fault          no_op
                f_decel         ROLL_1

Wait_Fault     set_tmr         TIMER,200
                if_tmr_on      TIMER,Wait_Fault

Start_Over     if_io_off       RESET,Start_Over
                drive_off      ROLL_1
                let             ctr=0
                enable_swi
                restart_at      Main

```

## Offset Methods

```

!-----
! TITLE:      Offset methods
!
! DATE:       12/8/97
!
! DESCRIPTION: This program uses MASTER-SLAVE ratios to demonstrate
!              the offset and speed control of a master axis.
!
! EQUIPMENT:  DeltaMax
!
! COMMANDS:   incr_com          offset_master      read_offset
!              set_offset
!
! The above commands are commonly used in many programs.  This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program.  While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.
!-----

                declare      on

!-----
!
!  Declare constants and variables
!-----

!
!  Axis related constants
!

CONVEYOR      equ          1
PSEUDO        equ          2

BUSY          equ          78
DOWN          equ          77
CONVEYOR_BUSY equ          (CONVEYOR*16)+BUSY
PSEUDO_BUSY  equ          (PSEUDO*16)+BUSY

CONVEYOR_DOWN equ          (CONVEYOR*16)+DOWN

MABA_TALKER   equ          30          ! PSEUDO is talker
!                                     on MABA
MABA_LISTEN1  equ          23          ! CONVEYOR listen
!                                     to MABA
PSEUDO_MABA   equ          10          ! PSEUDO talks to
!                                     MABA

!
!  I/O and Flags
!

```

```

INCREMENT      equ          0      ! Activate Inc. Conv.Pos.
!              (input)
ADVANCE        equ          1      ! Activate offset master
!              (input)
POSITIONING    equ          2      ! Activate positioning
!              (input)
RESET          equ          6      ! Reset Fault (input)
SYS_OK         equ         16      ! System okay (output)
TIMER         equ         72      ! Timer used for delays.
WATCHDOG      equ         73      ! Timer used for watchdog

!
! Data tables
!

POS_ARRAY      begin_data
data          10240,-40960,20480,0,40960,0
end_data

!
! Misc. Constants
!
WATCHDOG_TIME equ          50      !      mSec

!
! Variable definitions
!

map            integer        ! Var for configuring
!              Hardware
map_copy      integer        ! Var used to verify config.
map_stat      integer        ! map_stat = 0 if map OK,
!              <> 0 if error.
mcf           integer        ! Var used to setup MCF
mcf_copy      integer        ! Var used to verify MCF
!              setup
mcf_stat      integer        ! mcf_stat = 0 if mcf OK,
!              <> 0 if error.
time_delay    integer        ! Var with delay requirement
ac_dc         integer        ! Accel decel
speed         integer        ! Speed
offset        integer        ! Var used to offset master
offset_copy   integer        ! Angle read back from
!              offset
conv_offset   integer        ! Var used to inc. pos
!              for Conv.
advance       integer        ! Var used to move master
!              offset
advance_copy  integer        ! Used to verify move by
!              advance
ctr           integer        ! counter, index of pos
!              array
actual_pos    integer        ! Var containing value
!              from array

```

```

time_mark      integer      ! Test variable used for
!              !           time test
delta_time     integer      ! Var used to calc.
!              !           interval
start_pos      integer      ! Var used to get starting
!              !           pos
conv_pos       integer      ! Var used to get commanded
!              !           pos
delta_pos      integer      ! Var used to measure
!              !           displacement
no_of_times    integer      ! Software trap for one
!              !           time usage
millisec      integer      ! Motor interrupts in mSec.

```

```

!-----
!
!   Initialize variables
!
!-----

```

```

Defaults      no_op
               let      ac_dc=300
               let      speed=1000
               let      offset=1024
               let      conv_offset=1024
               let      advance=2048
               let      millisec=200
               let      ctr=0
               let      no_of_times=0
               let      time_mark=0
               let      conv_pos=0
               let      start_pos=0

```

```

!-----
!
!   Program setup
!   Define motion parameters.
!   Configure map.
!   Define software interrupts.
!
!-----

```

```

Setup         no_op
               set_ac_dc  PSEUDO, ac_dc
               set_speed  PSEUDO, speed
               set_ac_dc  CONVEYOR, ac_dc
               set_speed  CONVEYOR, speed

               gosub      Set_Config

               swi_if_on  0, CONVEYOR_DOWN, Fault
               swi_if_on  2, INCREMENT, Inc_Conveyor
               swi_if_on  3, ADVANCE, Set_Advance
               swi_if_on  4, POSITIONING, Positioning
               enable_swi

```

```

!-----
!
! Main body of the program.
! Start timed motion.
! Start Position of Master.
!-----

```

```

Main          no_op
              turn_on          SYS_OK
              drive_on         CONVEYOR
              delta_comp       CONVEYOR,1.0,1.0,30,0,1.0,6000
Stay          goto            Stay

```

```

!-----
!
! Increment Offset Conveyor
! Test for proper displacement.
!-----

```

```

Inc_Conveyor  no_op
              let              conv_pos=0
              let              start_pos=0
              get_com          CONVEYOR,start_pos
              incr_com         CONVEYOR,conv_offset,millisecond

Get_Inc_Pos   set_tmr          WATCHDOG,WATCHDOG_TIME
              get_com          CONVEYOR,conv_pos
              let              delta_pos = conv_pos - start_pos
              if_tmr_off       WATCHDOG,Fail_Inc
              if                delta_pos<>conv_offset,Get_Inc_Pos

              enable_swi
              return_sub

Fail_Inc      no_op
              gosub            Invalid_Ofst

```

```

!-----
!
! Set Advance (Correction) for Master
! Only to be used once per operation.
! Note:Cycle power before running to clear angle position.
!-----

```

```

Set_Advance    no_op
               if          no_of_times<>0,Exit_Advance
               let          no_of_times=1
               lock         CONVEYOR,1

               let          time_delay=20
               gosub         Delay

               offset_master PSEUDO,advance

               let          time_delay=20
               gosub         Delay

               get_angle     CONVEYOR,advance_copy
               if            advance_copy<>advance,Invalid_Ofst

!
!  Move to Offset Location
!

Wait_Ready     set_offset     PSEUDO,offset
               if_stat_on    PSEUDO_BUSY,Wait_Ready
               read_offset   PSEUDO,offset_copy
               if            offset<>offset_copy,Invalid_Ofst

Exit_Advance   unlock         CONVEYOR,0
               enable_swi
               return_sub

!-----
!
!  Positioning of master (and Slaves) with corrections (offsets)
!-----
!

Positioning    no_op
               lock         CONVEYOR,1
               let          actual_pos=POS_ARRAY[ctr]
               position     PSEUDO,actual_pos
Wait_Position  if_stat_on    PSEUDO_BUSY,Wait_Position
               let          ctr=ctr+1
               if            ctr<6,Return_Main

!
!  End of routine
!
               let          ctr=0

Return_Main    unlock         CONVEYOR,0
               enable_swi
               return_sub

```

```

!-----
!
! Subroutine used to configure the MAB map and the MCF map.
! Set the appropriate bits, and check the results.
!-----

```

```

Set_Config      let          map=0
                set_map     map
                set_bit     MABA_TALKER, map
                set_bit     MABA_LISTEN1, map
                set_map     map
                let         time_delay=30
                gosub       Delay

                get_map     map_copy
                get_map_stat map_stat

                if          map<>map_copy, Config_Fail
                if          map_stat<>0, Config_Fail

```

```

Config_Pseudo  no_op
                let          mcf=0
                set_mcf     PSEUDO, mcf
                set_bit     PSEUDO_MABA, mcf
                set_mcf     PSEUDO, mcf

                let         time_delay=30
                gosub       Delay

                get_mcf     PSEUDO, mcf_copy
                get_mcf_stat PSEUDO, mcf_stat

                if          mcf<>mcf_copy, Config_Fail
                if          mcf_stat<>0, Config_Fail

                enable_swi
                return_sub

```

```

Config_Fail    no_op
                sys_return

```

```

!-----
!
! Subroutine used to create a time delay.
! Wait until the timer times out.
!-----

```

```

Delay          no_op
               set_tmr          TIMER,time_delay
Wait_Time      if_tmr_on        TIMER,Wait_Time
               return_sub

```

```

!-----
!
! Subroutine used to halt operation on erroneous offset
!
!-----

```

```

Invalid_Ofst   no_op
               f_decel          PSEUDO
Wait_Stop      if_stat_on       PSEUDO_BUSY,Wait_Stop
               f_decel          CONVEYOR
Wait_Loop      no_op
               if_stat_on       CONVEYOR_DOWN,Exit_Ofst
               if_stat_on       CONVEYOR_BUSY,Wait_Loop

Exit_Ofst      sys_return

```

```

!-----
!
! Software Interrupt Routine used to handle fault conditions .
! Turn off the System Ok output.
! Check to see that all motion has stopped.
! Wait for reset input, then restart at Main.
!
!-----

```

```

Fault          no_op
               turn_off        SYS_OK
               f_decel          CONVEYOR

Wait_Fault     set_tmr          TIMER,200
               if_tmr_on       TIMER,Wait_Fault

Start_Over     if_io_off        RESET,Start_Over
               drive_off       CONVEYOR
               enable_swi
               restart_at      Main

```

## Clear Software Interrupts

```

!-----
! TITLE:          Clear Software Interrupts
!
! DATE:           12/3/97
!
! DESCRIPTION:    This program was written to demonstrate the usage of
!                interrupt managing and predefined-function hardware
!                interrupt usage (trap_pos).
!
! EQUIPMENT:     DeltaMax
!
! COMMANDS:      clr_all_swi          clr_swi          set_ms_tmr
!                trap_pos
!
! The above commands are commonly used in many programs.  This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program.  While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.
!-----
!
!                declare          on
!
!-----
!
! Declare constants and variables
!-----
!
! Axis related constants
!
WHEEL          equ          1
BUSY           equ          78
DOWN          equ          77
WHEEL_BUSY    equ          (WHEEL*16)+BUSY
WHEEL_DOWN    equ          (WHEEL*16)+DOWN
WHEEL_IDX     equ          89
!
! I/O and Flags
!
EMERGENCY      equ          6          ! Input
DIRECTION      equ          7          ! Input
TIMER          equ          72         ! Timer flag
HWI_ARMED_1    equ          91         ! Got position
!
! Variable definitions
!

```

```

speed          integer
ac_dc          integer
time_delay    integer
next_bottle   integer
bottle        integer
pos_trapped   integer

```

```

!-----
!
! Initialize variables
!
!-----

```

```

Defaults      no_op
               let          ac_dc=50
               let          speed=1000
               let          bottle=40960
               let          next_bottle=40960
               let          time_delay=50

```

```

!-----
!
! Program setup
!
!-----

```

```

Setup         no_op
               gosub        Grab_Pos_1
               set_ac_dc    WHEEL,ac_dc
               set_speed    WHEEL,speed
               drive_on     WHEEL
               delta_comp   WHEEL,1.0,1.0,30,0,1.0,6000
               swi_if_on    0,EMERGENCY,Emergency
               swi_if_on    1,DIRECTION,Do_Forward
               swi_if_off   2,HWI_ARMED_1,Grab_Pos_1
               enable_swi

```

```

!-----
!
! Main body of the program.
! This routine has only a loop to allow the interrupts to work
!
!-----

```

```

Main          no_op
               goto         Main

```

```

!-----
!
! This routine was created to do a forward motion based on the level
! of the IO (7) as s. interrupt signal.
!
!-----

```

```

Do_Forward    no_op
              let          next_bottle=bottle
              clr_swi      1
              swi_if_on    1,DIRECTION,Do_Reverse
              enable_swi
Idx_Loop      no_op
              index       WHEEL,next_bottle
Wait_Idx      if_stat_on  WHEEL_IDX,Wait_Idx

              goto        Idx_Loop

              return_sub

```

```

!-----
!
! This routine was created to do a reverse motion based on the level
! of the IO (7) as s. interrupt signal.
!
!-----

```

```

Do_Reverse    no_op
              clr_swi      1
              swi_if_on    1,DIRECTION,Do_Forward
              enable_swi
Idx_Loop_R    no_op
              let          next_bottle=0-bottle
              index       WHEEL,next_bottle
Wait_Idx_R    if_stat_on  WHEEL_IDX,Wait_Idx_R

              goto        Idx_Loop_R

              return_sub

```

```

!-----
!
! Subroutine used to create a time delay of 50ms.
! Wait until the timer times out.
!
!-----

```

```

Delay         no_op
              set_ms_tmr   TIMER,time_delay
Wait_Time     if_tmr_on    TIMER,Wait_Time
              return_sub

```

```

!-----
!
! Routine created to capture the present position of the motor when a
! hardware interrupt comes in.
!
!-----

```

```

Grab_Pos_1    no_op
              get_trap_pos    WHEEL,pos_trapped

              enable_hwi
              trap_pos        WHEEL

              enable_swi
              return_sub

```

```

!-----
!
! Subroutine used to service emergency stop.
!
!-----

```

```

Emergency    no_op
              clr_all_swi

Wt_Emrq_Stop    f_decel        WHEEL
                if_stat_on    WHEEL_DOWN,End_Emergency
                if_stat_on    WHEEL_BUSY,Wt_Emrq_Stop

End_Emergency  drive_off      WHEEL
                sys_return

```

## Operator Interface

```

!-----
! TITLE:      Operator Interface
!
! DATE:       12/8/97
!
! DESCRIPTION: This program will prompt the operator to enter speed,
!              accel/decel rate and an absolute position
!              (as motor turns xx.xx) and then execute a move to that
!              position with the parameters specified.
!
!              As each entry is made, the program will verify that it is
!              within the proper range and will alert the operator if
!              not.
!
! EQUIPMENT:  DeltaMax
!
! COMMANDS:  case          default          end_select
!            exit_select   if_char         if_no_char
!            input         port_set       print
!            print_num     select         stop_input
!            text
!
! The above commands are commonly used in many programs.  This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program.  While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.
!-----

```

```

                declare      off
AXIS_1          equ          1
DOWN_1         equ          93
BUSY_1         equ          94

TIMER_1        equ          72
BITS_TURN      equ          4096

DEF_SPEED      equ          10
MIN_SPEED      equ          1
MAX_SPEED      equ          2000

DEF_ACDC       equ          100
MIN_ACDC       equ          5
MAX_ACDC       equ          800

DEF_TURNS      equ          0
MIN_TURNS      equ          -9999      ! -99.99 turns
MAX_TURNS      equ          9999       ! 99.99 turns

PORT           equ          2

MINUS_1        equ          -1
ZERO           equ          48

```

F1	equ	65
F2	equ	66
F3	equ	67
F4	equ	68
NEXT	equ	78
PREV	equ	80
ENTER	equ	255
MENU_1_1	text	"F1 SETUP<13><10>"
MENU_1_2	text	"F2 RUN<13><10>"
MENU_1_3	text	"<13><10>"
MENU_1_4	text	"F4 STOP PROG<13><10>"
SPEED_IN	text	"SPEED:           "
ACDC_IN	text	"AC/DC:           "
TURNS_IN	text	"TURN:            "
POSITIONING	text	"POSITIONING ... "
ERR_1	text	"ENTRY:<13><10>"
ERR_2	text	"  OUT OF RANGE<13><10>"
ERR_3	text	"  TO<13><10>"
ERR_4	text	"  PRESS ANY KEY  "
E1_TXT	text	"DRIVE FAULT"
E2_TXT	text	"POSITION ERROR"
E3_TXT	text	"PRESS F4 TO RESET"
NO_MATCH	text	"ERR-NO MATCH"
CRLF	text	"<13><10>"
NULL	text	" "
CURSOR_POS	text	"<27>I "
BACKLIGHT	text	"<27>V"
C_ON	text	"<27>bA"
C_OFF	text	"<27>b@"
C_HOME	text	"<27>H"
C_DOWN	text	"<27>B"
C_RIGHT	text	"<27>C"
CLR_SCREEN	text	"<27>E<27>H"
AUTO_WRAP	text	"<27>R@"
AUTO_SCROLL	text	"<27>S@"
AUTO_L_FEED	text	"<27>T@"
SET_CUR	text	"<27>bA"
CLR_TO_END	text	"<27>J"
!-----		
!		
! ----- PROGRAM SETUP -----		
!		
!-----		
drive_on	AXIS_1	
set_g1_ccw	AXIS_1	

```

gosub      opi_setup
let        speed=DEF_SPEED
let        acdc=DEF_ACDC
let        turns=DEF_TURNS

```

```

!-----
!
! ----- MAIN MENU -----
!
!-----

```

```

main      print      CLR_SCREEN
          print      MENU_1_1
          print      MENU_1_2
          print      MENU_1_3
          print      MENU_1_4

main_key  gosub      ret_f_key
          if         key=F1,set_speed
          if         key=F2,run
          if         key=F4,exit
          goto       main_key

```

```

!-----
!
! ----- SETUP SPEED -----
!
!-----

```

```

set_speed print      CLR_SCREEN
          print      SPEED_IN
          print_num  4,0,speed
          print      CRLF
          let        temp=speed

speed_wt  input      NULL,7,0,temp,ENTER
          if_flag_off ENTER,speed_wt
          if         temp>MAX_SPEED,speed_err
          if         temp<MIN_SPEED,speed_err
          let        speed=temp
          goto       set_acdc

speed_err gosub      err_screen
          let        row=0
          let        col=9
          gosub      cursor
          print_num  7,0,temp

          let        row=2
          let        col=0
          gosub      cursor
          print_num  4,0,MIN_SPEED

          let        row=2
          let        col=12

```

```

        gosub      cursor
        print_num  4,0,MAX_SPEED
        gosub      press_key
        goto       set_speed

!-----
!
! ----- SETUP ACCEL/DECEL RATE -----
!
!-----

set_acdc      print      CLR_SCREEN
               print      ACDC_IN
               print_num   4,0,acdc
               print      CRLF

               let        temp=acdc
acdc_wt       input      NULL,7,0,temp,ENTER
               if_flag_off ENTER,acdc_wt
               if        temp>MAX_ACDC,acdc_err
               if        temp<MIN_ACDC,acdc_err
               let        acdc=temp
acdc_err      goto       set_turns
               gosub      err_screen
               let        row=0
               let        col=9
               gosub      cursor
               print_num   7,0,temp
               let        row=2
               let        col=0
               gosub      cursor
               print_num   3,0,MIN_ACDC

               let        row=2
               let        col=13
               gosub      cursor
               print_num   3,0,MAX_ACDC
               gosub      press_key
               goto       set_acdc

!-----
!
! ----- SETUP POSITION IN TURNS -----
!
!-----

set_turns     print      CLR_SCREEN
               print      TURNS_IN
               print_num   8,2,turns
               print      CRLF
               let        temp=turns

turns_wt      input      NULL,8,2,temp,ENTER
               if_flag_off ENTER,turns_wt
               if        temp>MAX_TURNS,turns_err
               if        temp<MIN_TURNS,turns_err
               let        turns=temp
               goto       main

```

```

turns_err      gosub      err_screen
                let        row=0
                let        col=9
                gosub      cursor
                print_num  7,2,temp

                let        row=2
                let        col=0
                gosub      cursor
                print_num  6,2,MIN_TURNS

                let        row=2
                let        col=10
                gosub      cursor
                print_num  6,2,MAX_TURNS
                gosub      press_key
                goto       set_turns

```

```

!-----
!
! ----- RUN MODE -----
!
!-----

```

```

run            print      CLR_SCREEN
               print      POSITIONING
               set_speed  AXIS_1,speed
               set_ac_dc  AXIS_1,acdc
               gosub      turns_to_bits

run_busy       position   AXIS_1,turn_bits
               if_stat_off DOWN_1,r_b1
               let        error=1
               gosub      fault
               goto       main

r_b1           if_stat_on  BUSY_1,run_busy
               get_pos    AXIS_1,one_pos
               let        check_pos=turn_bits-one_pos
               let        check_pos=abs(check_pos)
               if         check_pos<5,main
               let        error=2
               gosub      fault
               goto       main

```

```

!-----
!
! ----- CONVERT TURNS TO BITS -----
!
!-----

```

```

turns_to_bits let        turn_bits=0
               if         turns=0,ttb_end
               let        whole_turn=turns/100
               let        turn_bits=whole_turn*BITS_TURN
               let        whole_turn=whole_turn*100
               let        frac_turn=turns-whole_turn
               let        r_value=frac_turn*BITS_TURN
               gosub      round      ! intentionally 'round' twice
               gosub      round      ! due to turns to hundredths
               let        turn_bits=turn_bits+r_value

```

```
ttb_end      return_sub
```

```
!-----  
!  
! ----- ROUND function -----  
!  
!-----
```

```
round      let      result=r_value/10  
           let      new_result=result*10  
           let      diff=r_value-new_result  
           let      r_value=result  
           if      diff<5,end_round  
           let      r_value=result+1  
end_round  return_sub
```

```
!-----  
!  
! ----- EXIT PROGRAM -----  
!  
!-----
```

```
exit      f_decel      AXIS_1  
           let      time=200  
           gosub     pause  
           drive_off  AXIS_1  
           print     CLR_SCREEN  
           sys_return
```

```
!-----  
!  
! ----- AXIS FAULT ENCOUNTERED -----  
!  
!-----
```

```
fault      f_decel      AXIS_1  
           let      time=200  
           gosub     pause  
           gosub     display_err  
           drive_off  AXIS_1  
           gosub     pause  
           drive_on   AXIS_1,1305  
           goto      main
```

```
!-----
!  
! ----- OPI SETUP -----  
!
```

```
opi_setup      port_set      2,9600,8  
               let          time_1=10  
               print        BACKLIGHT  
               gosub        pause  
               print        AUTO_WRAP  
               gosub        pause  
               print        AUTO_L_FEED  
               gosub        pause  
               print        AUTO_SCROLL  
               gosub        pause  
               print        SET_CUR  
               gosub        pause  
op_exit        return_sub
```

```
!-----  
!  
! ----- RETURNS THE SELECTED FUNCTION KEY -----  
!
```

```
ret_f_key      print        C_OFF  
               input        NULL,0,0,key,ENTER  
rfk_wait       if_flag_off  ENTER,rfk_wait  
  
               let          err=0  
               if          key=F1,rfk_ok  
               if          key=F2,rfk_ok  
               if          key=F3,rfk_ok  
               if          key=F4,rfk_ok  
               if          key=NEXT,rfk_ok  
               if          key=PREV,rfk_ok  
               if          key=ENTER,rfk_ok  
               goto        ret_f_key  
  
rfk_ok         print        C_ON  
               return_sub
```

```
!-----  
!  
! ----- PRESS ANY KEY TO CONTINUE -----  
!
```

```
press_key      stop_input  
               input        NULL,0,0,key,ENTER  
pk_wait        if_flag_off  ENTER,pk_wait  
               return_sub
```

```
!-----  
!  
! ----- POSITION CURSOR FUNCTION -----  
!
```

```

cursor      print      C_HOME

c_next_col  let          ctr=0
            if          ctr=col,c_row
            print      C_RIGHT
            let          ctr=ctr+1
            goto       c_next_col

c_row       let          ctr=0
c_next_row  if          ctr=row,c_done
            print      C_DOWN
            let          ctr=ctr+1
            goto       c_next_row

c_done      return_sub

```

```

!-----
!
! ----- TEMPLATE FOR ERROR DISPLAY -----
!
!-----

```

```

err_screen  print      CLR_SCREEN
            print      ERR_1
            print      ERR_2
            print      ERR_3
            print      ERR_4
            return_sub

```

```

!-----
!
! Subroutine to display error.
! Use a select structure to determine the error to be displayed.
! Print the error message and return.
! To return the selected key.
! Clear out the input buffer.
! Wait for a key to be pressed.
! Check if key is valid, and repeat if not valid or return.
!
!-----

```

```

display_err print      CLR_SCREEN
            select     error
            case      1
                print  E1_TXT
                exit_select
            case      2
                print  E2_TXT
                exit_select
            default
                print  NO_MATCH
                exit_select
            end_select

            let          time_1=200
            gosub       pause
            print      E3_TXT

```

```
de_ret_fkey    if_no_char    PORT,de_cont_fkey
de_clr_key     input         NULL,0,0,key,ENTER
de_wait_clr    if_flag_off   ENTER,de_wait_clr
               gosub         pause
               if_char    PORT,de_clr_key

de_cont_fkey   print        C_OFF

               input         NULL,0,0,key,ENTER
de_rfk_wait    if_flag_off   ENTER,de_rfk_wait
               if            key=F4,de_rfk_ok
               goto         de_ret_fkey

de_rfk_ok      print        C_ON
               return_sub
```

```
!-----
!  
!           Timer routine -  
!  
!-----
pause        set_tmr      TIMER_1,time_1
pausing      if_tmr_on    TIMER_1,pausing
               return_sub
```

## Floating Point Numbers

```

!-----
! TITLE:      Floating Point Numbers
!
! DATE:       12/3/97
!
! DESCRIPTION: This program indexes AXIS_1 1" to 10" in 1" increments.
!              The roll diameter is 3.48" .
!
! EQUIPMENT:  DeltaMax
!
! COMMANDS:   float      float_dim
!
! The above commands are commonly used in many programs.  This
! illustration provides the context and syntax required to successfully
! integrate these commands into a complete program.  While the use of
! these commands varies from program to program, the following example
! will give the programmer an indication of a typical usage.
!-----

                declare      on

AXIS_1          equ          1
DOWN_1         equ          93
BUSY_1         equ          94

RESET          equ          0          ! resets system faults (input)
SYS_OK         equ          16         ! indicates system OK (output)

TIMER_1        equ          72
BITS_TURN      equ          4096

PI             equ          3.14159
ROLL_DIA       equ          3.48       ! Feed Roll diameter

cht            integer
cth            integer
feed           integer

feedbits       float
index_dis      float_dim      10      ! index distance array

start          let          cht=0
               let          cth=1

loop           let          feedbits=PI*ROLL_DIA
               let          feedbits=cth/feedbits
               let          feedbits=feedbits*BITS_TURN

               let          index_dis[cht]=feedbits
               let          cht=cht+1
               let          cth=cth+1
               if           cht<10,loop

```

```

        set_speed      AXIS_1,1000
        set_ac_dc      AXIS_1,200

        swi_if_on      0,DOWN_1,fault
        enable_swi
        drive_on       AXIS_1
        delta_comp     AXIS_1,1,1,30,0,1,6000

loop1    let          cht=0
        let          feed=index_dis[cht]

        index       AXIS_1,feed

wait1    if_stat_on  BUSY_1,wait1

wait2    set_tmr     TIMER_1,50
        if_tmr_on   TIMER_1,wait2

        let          cht=cht+1
        if          cht<10,loop1
        let          cht=0

        goto        loop1

!-----
!
! Subroutine used to handle a motor fault
!
!-----

fault    turn_off    SYS_OK
        f_decel     AXIS_1

wait_fault  set_tmr     TIMER_1,200
        if_tmr_on   TIMER_1,wait_fault


start_over  if_io_off  RESET,start_over
        drive_off  AXIS_1
        restart_at start

```

# MACROPRO II<sup>TM</sup>

FOR WINDOWS<sup>TM</sup>

Section 7 - Glossary



INDUSTRIAL INDEXING SYSTEMS, INC.

## SECTION 7 - GLOSSARY

<b>ACCEL/DECEL</b>	The rate of change to achieve a desired speed. Unit of measure is revs/sec <sup>2</sup> .
<b>ACTUATOR</b>	A device which creates mechanical motion by converting various forms of energy to mechanical energy.
<b>AXIS</b>	An independent motor/drive unit which is controlled by an IIS type controller
<b>AXIS CONTROLLER</b>	A controller which contained within the DeltaMax to control an independent motor/drive unit
<b>CLOSED LOOP</b>	A regulating device in which the actuator position is sensed, and a signal proportional to this position (feedback position) is compared with a signal proportional to the desired actuator position (command position). The difference between these signals is the error signal. The error signal causes a change in the actuator so as to force this signal to be zero.
<b>COMMAND SIGNAL GENERATOR</b>	A device that supplies a command position signal to an automatic control system. This signal represents the desired motion of the actuator that is required to accomplish a task such as making a part. This signal is usually in the form of an electrical signal.
<b>COMMUNICATIONS</b>	The transmission of information from one device to another. The information can take many forms such as command signals, device status and fault conditions.
<b>COMMUTATOR</b>	The part of the rotating armature of a motor that causes the electrical current to be switched to various armature windings. The proper sequenced switching of the windings creates the motor torque. The commutator also provides the means to transmit the electrical current from the stationary body of the motor to moving rotor.
<b>COMPARATOR</b>	A device where the feedback signal is subtracted from the command signal. The difference output of the comparator is called the error signal.
<b>DC DRIVE</b>	An electronic control unit for running DC motors. The DC drive converts AC line current to a variable DC current to control a DC motor. The DC drive has a signal input that controls the torque and speed of the motor.

<b>ENCODER</b>	A type of feedback device which converts mechanical motion into electrical signals to indicate actuator position. Typical encoders are designed with a printed disc and a light source. As the disc turns with the actuator shaft, the light source shines through the printed pattern onto a sensor. The light transmission is interrupted by the patterns on the disk. These interruptions are sensed and converted to electrical pulses. By counting these pulses, actuator shaft position is determined.
<b>FLAG</b>	A bit in memory used by the programmer to evaluate action to be taken. A program branch may be executed depending on the true or false result of a bit test. There are four types of flags supported by the IIS programming language; axis status flags, I/O status flags, timer status flags and user flags.
<b>HOME</b>	A known point of reference frequently referred to as "global zero". Used as a point of reference for absolute positioning.
<b>HOST</b>	A computer system whose function is to monitor and coordinate the processes of other devices. A host computer will typically coordinate motion control functions as well as their interaction with other machine processes.
<b>I/O</b>	The reception and transmission of information (Input/Output) between control devices. In modern control systems, I/O has two distinct forms. In one, it refers to switches, relays, etc. In the other form, I/O refers to analog signals that are continuous in nature such as speed, temperature, flow, etc.
<b>INDEX</b>	An <b>index</b> instruction will move the motor shaft an absolute distance relative to the current position.
<b>INERTIA</b>	The measure of an object's resistance to a change in its current velocity.
<b>INITIALIZE</b>	To execute a series of program instructions in order to teach the DeltaMax motor axis controller an absolute zero reference.
<b>INSTRUCTION</b>	A program command to the DeltaMax. All instructions have the following format:  <i>label</i> instruction parameters comment
<b>INSTABILITY</b>	Undesirable motion of an actuator that is different from the commanded motion. Instability can take the form of irregular speed or hunting of the final rest position.

---

<b>JOG</b>	A <b>jog</b> instruction will move the motor shaft in the specified direction using the predefined speed and accel/decel rates. Once at speed, the motor will continue to jog until commanded to stop.
<b>LINE SHAFT</b>	A shaft rotated by the primary motor drive. The line shaft transmits power from the motor to a load or series of loads. In the multiple load case, the motions of the loads are synchronized to one another because they are driven from a common shaft.
<b>MACROPRO II</b>	The Windows-based software package used to edit, compile, and analyze programs developed for DeltaMax controllers.
<b>MICROPROCESSOR</b>	<p>A miniaturized computer system that executes instructions in a sequential manner. The sequential instructions form a control strategy for devices that may be connected to the system.</p> <p>The sequential instructions are loaded into the microprocessor and can be easily changed or modified. Modern microprocessors are small electronic devices that execute a wide range of instructions at speeds as high as 1,000,000 instructions per second.</p>
<b>MOTOR DIRECTION</b>	The direction that a motor shaft is turning is determined by the facing the front of the motor shaft. From this perspective, direction is determined to be clockwise or counter-clockwise.
<b>OPEN-LOOP SYSTEM</b>	A system where a command signal results in actuator movement which is not sensed and therefore not corrected for error. The term "open loop" essentially means there is no feedback.
<b>OPERATOR INTERFACE</b>	A device that allows the operator to communicate with a machine. This device typically has a keyboard or thumbwheel to enter instructions into the machine. It may also have a display device that allows the machine to display messages. An example of an operator interface is the OPI-1.
<b>OSCILLATION</b>	Undesirable motion of an actuator that is different from the command motion. See INSTABILITY.

---

<b>PARAMETER</b>	A value required for correct execution of an instruction. Each instruction has a parameter list which is used by the controller to execute the instruction. An example would be the <b>index</b> instruction. The controller needs to know which axis to index and the distance to index.
<b>PERIPHERAL</b>	Various kinds of devices that operate in conjunction with a DeltaMax controller. Examples of these are PLC's, joysticks, computers, and operator interfaces.
<b>POSITION ERROR</b>	The difference between the present actuator position (feedback) and the desired position (command).
<b>POSITION FEEDBACK</b>	Present actuator position as measured by a position transducer.
<b>PROGRAM / MACROPROGRAM</b>	A program written in IIS's basic-like language for the DeltaMax and MSC-family of motion controllers.
<b>PROGRAMMABLE LOGIC CONTROLLER (PLC)</b>	(PLC) An electronic device that scans discrete (on/off) type inputs and controls discrete (on/off) type outputs. The relationship between the inputs and outputs are logical statements that are programmable by the user.
<b>RESOLVER</b>	A type of feedback device which converts mechanical position into an electrical signal. A resolver is a variable transformer that divides the impressed AC signal into two outputs, referred to as sine and cosine output signals. The comparison of these two signals is used to determine the absolute position of the resolver shaft.
<b>ROTOR</b>	The rotating part of a magnetic structure. In a motor, the rotor is connected to the motor shaft.
<b>SERVO</b>	An automatic control device for controlling large amounts of power by means of very small amounts of power and automatically correcting the performance of the mechanism. Servo systems are closed loop systems.
<b>SERVO AMPLIFIER</b>	An electronic device which produces the winding current for a servo motor. The amplifier converts a low level control signal into high voltage and current levels to produce torque in the motor.

**SERVO MOTOR**

An actuator which converts electrical energy (winding current) to mechanical energy (torque). Servo motor construction is optimized to provide maximum torque with minimum rotor inertia.



# MACROPRO II<sup>TM</sup>

FOR WINDOWS<sup>TM</sup>

Section 8 - Appendix



INDUSTRIAL INDEXING SYSTEMS, INC.

**SECTION 8 - APPENDIX****Table of Contents**

<i>Adjustment Parameters</i> _____	<b>3</b>
<i>Electronic Data Sheet (EDS)</i> _____	<b>4</b>
<i>DeltaMax Device Data</i> _____	<b>6</b>
<b>General Device Data</b> _____	<b>6</b>
<b>Identity Object</b> _____	<b>7</b>
<b>Message Router Object</b> _____	<b>8</b>
<b>DeviceNet Object</b> _____	<b>9</b>
<b>Connection Object - Explicit Message</b> _____	<b>10</b>
<b>Connection Object - Polled I/O</b> _____	<b>12</b>
<b>Connection Object - Bit Strobed I/O</b> _____	<b>13</b>
<b>Assembly Object</b> _____	<b>14</b>

*This page is intentionally left blank.*

## Adjustment Parameters

<u>ADJUSTMENT PARAMETER</u>	<u>SYMBOL</u>	<u>DRIVE RANGE</u>	<u>DELTAMAX DEFAULT</u>	<u>DESCRIPTION</u>
LOAD INERTIA RATIO	AJ2	0-100.0 TIMES	1.0 TIMES	Sets the baseline frequency response of the driver using the ratio of the load inertia/motor inertia for a rigidly coupled load. If the load is not rigidly coupled, the value entered may vary from the calculated value. If the value is set too high, the motor and driver may become unstable and oscillate.
HIGH FREQUENCY RESPONSE	AJ3	0.1-20.0	1.0	Sets the high frequency response of the driver. The higher the number the more responsive. If the value is set too high, the motor and driver may become unstable and oscillate. The value in AJ3 is unitless and works in concert with AJ2.
POSITION LOOP DC GAIN	AJ4	1-200 RAD/SEC	30 RAD/SEC	Sets the DC gain of the position control loop. A higher value in AJ4 results in stiffer, faster response. If the value is set too high, the motor and driver may become unstable & oscillate.
ZERO SPEED GAIN REDUCTION	AJ7	0-10000	0	Sets the amount of gain reduction at zero speed.
FEED FORWARD GAIN	AJ8	0-2.0 TIMES	1.0 TIMES	Sets the feed forward gain in the position loop. A value of 1.0 results in 0.0 following error. Less than 1.0 will produce a lag between the actual motor position and the commanded position and greater than 1.0 produces a lead. The lead or lag will be proportional to speed at non 1.0 settings.
NOTCH FILTER FREQUENCY	AJ9	100-20000 RAD/SEC	6000 RAD/SEC	Sets the notch frequency of a velocity loop anti-resonance filter. This filter can be used to cancel machine or servo resonance. Power must be turned OFF then ON for this parameter to take effect.

## Electronic Data Sheet (EDS)

The Electronic Data Sheet (EDS) allows a configuration tool to automate the DeviceNet device configuration process. An EDS contains vendor specific and/or MacroProgram specific information defined for a particular application. The EDS file may be used to easily get a DeltaMax up on the DeviceNet Network.

An EDS definition is available by contacting ODVA, or obtaining Section 2 Chapter 4 of the ODVA DeviceNet Specification.

The following EDS file example was generated using DeviceNet Manager and a simple text editor. DeviceNet Manager is a DeviceNet software tool distributed by Allen Bradley. The example is intended to work with the MacroProgram example without a parameter object, herein.

If a parameter object is macroprogrammed into the DeltaMax then a EDS file maybe generated automatically from a DeviceNet such as DeviceNet Manager. The tool extracts the necessary information from the DeltaMax, then writes the file to the PC.

### EDS File Example

```
$ DeviceNet Manager Generated Electronic Data Sheet
$

[File]

[Device]
  VendCode      = 89;                $ Vendor Code
  ProdType      = 0;                $ Product Type
  ProdCode      = 1;                $ Product Code

  MajRev        = 1;                $ Major Rev
  MinRev        = 0;                $ Minor Rev
  VendName      = "Industrial Indexing Systems, Inc";
  ProdTypeStr   = "Generic";
  ProdName      = "DeltaMax";
  Catalog       = "0";

[IO_Info]
  Default       = 0X0000;

[ParamClass]
  MaxInst=4;
  Descriptor=0;
  CfgAssembly=0;

[Params]

  $ Flags Object Parameters
  Param1=      $ class:0x64,Inst:0x21,Attr:0x3
                $ parameter value slot
                0,                $ link path size and path
                6, "20 64 24 21 30 03", $ descriptor: enumerated
                0x0002,            $ data type: BOOLEAN
                4,                $ data size: 1 for BOOLEAN
                1,                $ parameter name
                "RUN INPUT",      $ units string
                "",               $ help string
                "",
```

```

0, 1, 0,           $ min, max, default
1, 1, 1, 0,       $ mult, div, base, offset scaling
0, 0, 0, 0, 0 ;   $ scaling links and precision

$ Integer Object Dynamic Parameters
Param2=           $ class:0x65,Inst:0x01,Attr:0x3
0,               $ parameter value slot
6, "20 65 24 01 30 03", $ link path size and path
0x0000,         $ descriptor: none
6,             $ data type: DINT
4,             $ data size: 4 for DINT
"Speed",       $ parameter name
"rpm",         $ units string
"",           $ help string
0, 3000, 100,  $ min, max, default
1, 1, 1, 0,   $ mult, div, base, offset scaling
0, 0, 0, 0, 0 ; $ scaling links and precision

Param3=          $ class:0x65,Inst:0x03,Attr:0x3
0,              $ parameter value slot
6, "20 65 24 03 30 03", $ link path size and path
0x0000,         $ descriptor: none
6,             $ data type: DINT
4,             $ data size: 4 for DINT
"Multiplier",  $ parameter name
"",           $ units string
"",           $ help string
0, 4, 1,       $ min, max, default
1, 1, 1, 0,   $ mult, div, base, offset scaling
0, 0, 0, 0, 0 ; $ scaling links and precision

Param4=          $ class:0x65,Inst:0x0d,Attr:0x3
0,              $ parameter value slot
6, "20 65 24 0d 30 03", $ link path size and path
0x0010,         $ descriptor: readonly
6,             $ data type: DINT
4,             $ data size: 4 for DINT
"Angle * Multiplier", $ parameter name
"bits(4096bits/rev)", $ units string
"",           $ help string
0, 4095, 0,    $ min, max, default
1, 1, 1, 0,   $ mult, div, base, offset scaling
0, 0, 0, 0, 0 ; $ scaling links and precision

[EnumPar]

$ Flags Object Parameters Enumerations
Param1=          $ Bit Definitions for Param 1
"OFF",
"ON";

[Groups]

```

## DeltaMax Device Data

### General Device Data

Device Data																																																													
<b>General Device Data</b>	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">Conforms to Devicenet Specification</td> <td>Volume I – Release <u>1.3</u></td> </tr> <tr> <td>Vendor Name</td> <td><u>1.2</u></td> </tr> <tr> <td>Device Profile Name</td> <td><u>Industrial Indexing Systems, Inc.</u></td> </tr> <tr> <td>Product Name</td> <td><u>Generic Device</u></td> </tr> <tr> <td>Product Catalog Number</td> <td><u>DeltaMax</u></td> </tr> <tr> <td>Product Revision</td> <td><u>0</u></td> </tr> <tr> <td></td> <td><u>1</u></td> </tr> </table>	Conforms to Devicenet Specification	Volume I – Release <u>1.3</u>	Vendor Name	<u>1.2</u>	Device Profile Name	<u>Industrial Indexing Systems, Inc.</u>	Product Name	<u>Generic Device</u>	Product Catalog Number	<u>DeltaMax</u>	Product Revision	<u>0</u>		<u>1</u>																																														
Conforms to Devicenet Specification	Volume I – Release <u>1.3</u>																																																												
Vendor Name	<u>1.2</u>																																																												
Device Profile Name	<u>Industrial Indexing Systems, Inc.</u>																																																												
Product Name	<u>Generic Device</u>																																																												
Product Catalog Number	<u>DeltaMax</u>																																																												
Product Revision	<u>0</u>																																																												
	<u>1</u>																																																												
<b>DeviceNet Physical Conformance Data</b>	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">Network Power Consumption (Max)</td> <td><u>0.12</u> A@11V dc (worst case)</td> </tr> <tr> <td>Connector Style</td> <td> <table style="width: 100%; border-collapse: collapse;"> <tr> <td>Open–Hardwired</td> <td><input type="checkbox"/></td> <td>Sealed-Mini</td> <td><input type="checkbox"/></td> </tr> <tr> <td>Open–Pluggable</td> <td><input checked="" type="checkbox"/></td> <td>Sealed-Micro</td> <td><input type="checkbox"/></td> </tr> </table> </td> </tr> <tr> <td>Isolated Physical Layer</td> <td> <table style="width: 100%; border-collapse: collapse;"> <tr> <td>Yes</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>No</td> <td><input type="checkbox"/></td> </tr> </table> </td> </tr> <tr> <td>LEDs Supported</td> <td> <table style="width: 100%; border-collapse: collapse;"> <tr> <td>Module</td> <td><input type="checkbox"/></td> <td>Combo Mod/Net</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>Network</td> <td><input type="checkbox"/></td> <td>I/O</td> <td><input type="checkbox"/></td> </tr> </table> </td> </tr> <tr> <td>MAC ID Setting</td> <td> <table style="width: 100%; border-collapse: collapse;"> <tr> <td>DIP Switch</td> <td><input type="checkbox"/></td> <td>Software Settable</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td colspan="4">Other <u>MacroProgrammable</u></td> </tr> </table> </td> </tr> <tr> <td>Default MAC ID</td> <td><u>63</u></td> </tr> <tr> <td>Communication Rate Setting</td> <td> <table style="width: 100%; border-collapse: collapse;"> <tr> <td>DIP Switch</td> <td><input type="checkbox"/></td> <td>Software Settable</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td colspan="4">Other <u>MacroProgrammable</u></td> </tr> </table> </td> </tr> <tr> <td>Communication Rates Supported</td> <td> <table style="width: 100%; border-collapse: collapse;"> <tr> <td>125k bit/s</td> <td><input checked="" type="checkbox"/></td> <td>500k bit/s</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>250k bit/s</td> <td><input checked="" type="checkbox"/></td> <td></td> <td></td> </tr> </table> </td> </tr> </table>	Network Power Consumption (Max)	<u>0.12</u> A@11V dc (worst case)	Connector Style	<table style="width: 100%; border-collapse: collapse;"> <tr> <td>Open–Hardwired</td> <td><input type="checkbox"/></td> <td>Sealed-Mini</td> <td><input type="checkbox"/></td> </tr> <tr> <td>Open–Pluggable</td> <td><input checked="" type="checkbox"/></td> <td>Sealed-Micro</td> <td><input type="checkbox"/></td> </tr> </table>	Open–Hardwired	<input type="checkbox"/>	Sealed-Mini	<input type="checkbox"/>	Open–Pluggable	<input checked="" type="checkbox"/>	Sealed-Micro	<input type="checkbox"/>	Isolated Physical Layer	<table style="width: 100%; border-collapse: collapse;"> <tr> <td>Yes</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>No</td> <td><input type="checkbox"/></td> </tr> </table>	Yes	<input checked="" type="checkbox"/>	No	<input type="checkbox"/>	LEDs Supported	<table style="width: 100%; border-collapse: collapse;"> <tr> <td>Module</td> <td><input type="checkbox"/></td> <td>Combo Mod/Net</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>Network</td> <td><input type="checkbox"/></td> <td>I/O</td> <td><input type="checkbox"/></td> </tr> </table>	Module	<input type="checkbox"/>	Combo Mod/Net	<input checked="" type="checkbox"/>	Network	<input type="checkbox"/>	I/O	<input type="checkbox"/>	MAC ID Setting	<table style="width: 100%; border-collapse: collapse;"> <tr> <td>DIP Switch</td> <td><input type="checkbox"/></td> <td>Software Settable</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td colspan="4">Other <u>MacroProgrammable</u></td> </tr> </table>	DIP Switch	<input type="checkbox"/>	Software Settable	<input checked="" type="checkbox"/>	Other <u>MacroProgrammable</u>				Default MAC ID	<u>63</u>	Communication Rate Setting	<table style="width: 100%; border-collapse: collapse;"> <tr> <td>DIP Switch</td> <td><input type="checkbox"/></td> <td>Software Settable</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td colspan="4">Other <u>MacroProgrammable</u></td> </tr> </table>	DIP Switch	<input type="checkbox"/>	Software Settable	<input checked="" type="checkbox"/>	Other <u>MacroProgrammable</u>				Communication Rates Supported	<table style="width: 100%; border-collapse: collapse;"> <tr> <td>125k bit/s</td> <td><input checked="" type="checkbox"/></td> <td>500k bit/s</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>250k bit/s</td> <td><input checked="" type="checkbox"/></td> <td></td> <td></td> </tr> </table>	125k bit/s	<input checked="" type="checkbox"/>	500k bit/s	<input checked="" type="checkbox"/>	250k bit/s	<input checked="" type="checkbox"/>		
Network Power Consumption (Max)	<u>0.12</u> A@11V dc (worst case)																																																												
Connector Style	<table style="width: 100%; border-collapse: collapse;"> <tr> <td>Open–Hardwired</td> <td><input type="checkbox"/></td> <td>Sealed-Mini</td> <td><input type="checkbox"/></td> </tr> <tr> <td>Open–Pluggable</td> <td><input checked="" type="checkbox"/></td> <td>Sealed-Micro</td> <td><input type="checkbox"/></td> </tr> </table>	Open–Hardwired	<input type="checkbox"/>	Sealed-Mini	<input type="checkbox"/>	Open–Pluggable	<input checked="" type="checkbox"/>	Sealed-Micro	<input type="checkbox"/>																																																				
Open–Hardwired	<input type="checkbox"/>	Sealed-Mini	<input type="checkbox"/>																																																										
Open–Pluggable	<input checked="" type="checkbox"/>	Sealed-Micro	<input type="checkbox"/>																																																										
Isolated Physical Layer	<table style="width: 100%; border-collapse: collapse;"> <tr> <td>Yes</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>No</td> <td><input type="checkbox"/></td> </tr> </table>	Yes	<input checked="" type="checkbox"/>	No	<input type="checkbox"/>																																																								
Yes	<input checked="" type="checkbox"/>																																																												
No	<input type="checkbox"/>																																																												
LEDs Supported	<table style="width: 100%; border-collapse: collapse;"> <tr> <td>Module</td> <td><input type="checkbox"/></td> <td>Combo Mod/Net</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>Network</td> <td><input type="checkbox"/></td> <td>I/O</td> <td><input type="checkbox"/></td> </tr> </table>	Module	<input type="checkbox"/>	Combo Mod/Net	<input checked="" type="checkbox"/>	Network	<input type="checkbox"/>	I/O	<input type="checkbox"/>																																																				
Module	<input type="checkbox"/>	Combo Mod/Net	<input checked="" type="checkbox"/>																																																										
Network	<input type="checkbox"/>	I/O	<input type="checkbox"/>																																																										
MAC ID Setting	<table style="width: 100%; border-collapse: collapse;"> <tr> <td>DIP Switch</td> <td><input type="checkbox"/></td> <td>Software Settable</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td colspan="4">Other <u>MacroProgrammable</u></td> </tr> </table>	DIP Switch	<input type="checkbox"/>	Software Settable	<input checked="" type="checkbox"/>	Other <u>MacroProgrammable</u>																																																							
DIP Switch	<input type="checkbox"/>	Software Settable	<input checked="" type="checkbox"/>																																																										
Other <u>MacroProgrammable</u>																																																													
Default MAC ID	<u>63</u>																																																												
Communication Rate Setting	<table style="width: 100%; border-collapse: collapse;"> <tr> <td>DIP Switch</td> <td><input type="checkbox"/></td> <td>Software Settable</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td colspan="4">Other <u>MacroProgrammable</u></td> </tr> </table>	DIP Switch	<input type="checkbox"/>	Software Settable	<input checked="" type="checkbox"/>	Other <u>MacroProgrammable</u>																																																							
DIP Switch	<input type="checkbox"/>	Software Settable	<input checked="" type="checkbox"/>																																																										
Other <u>MacroProgrammable</u>																																																													
Communication Rates Supported	<table style="width: 100%; border-collapse: collapse;"> <tr> <td>125k bit/s</td> <td><input checked="" type="checkbox"/></td> <td>500k bit/s</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>250k bit/s</td> <td><input checked="" type="checkbox"/></td> <td></td> <td></td> </tr> </table>	125k bit/s	<input checked="" type="checkbox"/>	500k bit/s	<input checked="" type="checkbox"/>	250k bit/s	<input checked="" type="checkbox"/>																																																						
125k bit/s	<input checked="" type="checkbox"/>	500k bit/s	<input checked="" type="checkbox"/>																																																										
250k bit/s	<input checked="" type="checkbox"/>																																																												
<b>DeviceNet Communication Data</b>	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">Device Network Behavior</td> <td>Group 2 Client</td> <td><input type="checkbox"/></td> <td>Group 2 Only Client</td> <td><input type="checkbox"/></td> </tr> <tr> <td>Check All That Apply</td> <td>Group 2 Server</td> <td><input type="checkbox"/></td> <td>Group 2 Only Server</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td></td> <td>Peer-to-Peer</td> <td><input type="checkbox"/></td> <td>Tool (not a device)</td> <td><input type="checkbox"/></td> </tr> <tr> <td>UCMM Explicit Message Groups Supported</td> <td>Group 1</td> <td><input type="checkbox"/></td> <td>Group 2</td> <td><input type="checkbox"/></td> </tr> <tr> <td>Dynamic I/O Message Groups</td> <td>Group 1</td> <td><input type="checkbox"/></td> <td>Group 2</td> <td><input type="checkbox"/></td> </tr> <tr> <td>Typical I/O Data Address Path</td> <td>Input: Class <u>4</u></td> <td>Inst. <u>1</u></td> <td>Attr. <u>3</u></td> <td></td> </tr> <tr> <td></td> <td>Output: Class <u>4</u></td> <td>Inst. <u>2</u></td> <td>Attr. <u>3</u></td> <td></td> </tr> <tr> <td>Fragmented Explicit Messaging Implemented</td> <td>Yes</td> <td><input checked="" type="checkbox"/></td> <td>No</td> <td><input type="checkbox"/></td> </tr> <tr> <td>If yes, Acknowledge Time Out</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Typical Target Addresses (decimal)</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Consumption</td> <td>Service <u>16</u></td> <td>Class <u>1</u></td> <td>Inst. <u>1</u></td> <td>Attr. <u>7</u></td> </tr> <tr> <td>Production</td> <td>Service <u>16</u></td> <td>Class <u>1</u></td> <td>Inst. <u>1</u></td> <td>Attr. <u>7</u></td> </tr> </table>	Device Network Behavior	Group 2 Client	<input type="checkbox"/>	Group 2 Only Client	<input type="checkbox"/>	Check All That Apply	Group 2 Server	<input type="checkbox"/>	Group 2 Only Server	<input checked="" type="checkbox"/>		Peer-to-Peer	<input type="checkbox"/>	Tool (not a device)	<input type="checkbox"/>	UCMM Explicit Message Groups Supported	Group 1	<input type="checkbox"/>	Group 2	<input type="checkbox"/>	Dynamic I/O Message Groups	Group 1	<input type="checkbox"/>	Group 2	<input type="checkbox"/>	Typical I/O Data Address Path	Input: Class <u>4</u>	Inst. <u>1</u>	Attr. <u>3</u>			Output: Class <u>4</u>	Inst. <u>2</u>	Attr. <u>3</u>		Fragmented Explicit Messaging Implemented	Yes	<input checked="" type="checkbox"/>	No	<input type="checkbox"/>	If yes, Acknowledge Time Out					Typical Target Addresses (decimal)					Consumption	Service <u>16</u>	Class <u>1</u>	Inst. <u>1</u>	Attr. <u>7</u>	Production	Service <u>16</u>	Class <u>1</u>	Inst. <u>1</u>	Attr. <u>7</u>
Device Network Behavior	Group 2 Client	<input type="checkbox"/>	Group 2 Only Client	<input type="checkbox"/>																																																									
Check All That Apply	Group 2 Server	<input type="checkbox"/>	Group 2 Only Server	<input checked="" type="checkbox"/>																																																									
	Peer-to-Peer	<input type="checkbox"/>	Tool (not a device)	<input type="checkbox"/>																																																									
UCMM Explicit Message Groups Supported	Group 1	<input type="checkbox"/>	Group 2	<input type="checkbox"/>																																																									
Dynamic I/O Message Groups	Group 1	<input type="checkbox"/>	Group 2	<input type="checkbox"/>																																																									
Typical I/O Data Address Path	Input: Class <u>4</u>	Inst. <u>1</u>	Attr. <u>3</u>																																																										
	Output: Class <u>4</u>	Inst. <u>2</u>	Attr. <u>3</u>																																																										
Fragmented Explicit Messaging Implemented	Yes	<input checked="" type="checkbox"/>	No	<input type="checkbox"/>																																																									
If yes, Acknowledge Time Out																																																													
Typical Target Addresses (decimal)																																																													
Consumption	Service <u>16</u>	Class <u>1</u>	Inst. <u>1</u>	Attr. <u>7</u>																																																									
Production	Service <u>16</u>	Class <u>1</u>	Inst. <u>1</u>	Attr. <u>7</u>																																																									

# Identity Object

DeviceNet		Identity Object 0x01					
<b>Required Object Implementation</b>	<b>Object Class</b>		<b>ID</b>	<b>Description</b>	<b>Get</b>	<b>Set</b>	<b>Value Limits</b>
	Attributes	Open	1	Revision	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
			2	Max instance	<input type="checkbox"/>	<input type="checkbox"/>	_____
	<input type="checkbox"/> None Supported		6	Max ID of class attributes	<input type="checkbox"/>	<input type="checkbox"/>	_____
			7	Max ID of instance attributes	<input type="checkbox"/>	<input type="checkbox"/>	_____
			<b>DeviceNet Services</b>		<b>Parameter Options</b>		
Services			<input type="checkbox"/>	Get_Attribute_All	_____		
			<input type="checkbox"/>	Reset	_____		
<input type="checkbox"/> None Supported			<input checked="" type="checkbox"/>	Get_Attribute_Single	_____		
			<input type="checkbox"/>	Find_Next_Object_Instance	_____		
<b>Object Instance</b>	<b>Object Class</b>		<b>ID</b>	<b>Description</b>	<b>Get</b>	<b>Set</b>	<b>Value Limits</b>
	Attributes	Open	1	Vendor	<input checked="" type="checkbox"/>	<input type="checkbox"/>	89
			2	Product type	<input checked="" type="checkbox"/>	<input type="checkbox"/>	0
	<input type="checkbox"/> None Supported		3	Product code	<input checked="" type="checkbox"/>	<input type="checkbox"/>	0
			4	Revision	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1
			5	Status	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
			6	Serial number	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
			7	Product name	<input checked="" type="checkbox"/>	<input type="checkbox"/>	DeltaMax
			8	State	<input type="checkbox"/>	<input type="checkbox"/>	_____
			<b>DeviceNet Services</b>		<b>Parameter Options</b>		
Services			<input type="checkbox"/>	Get_Attribute_All	_____		
<input type="checkbox"/> None Supported			<input checked="" type="checkbox"/>	Reset	0		
			<input checked="" type="checkbox"/>	Get_Attribute_Single	_____		
Vendor Specific Additions			If yes, fill out the Vendor Specific Additions form on page F- 7.		Yes	<input type="checkbox"/>	
					No	<input checked="" type="checkbox"/>	

## Message Router Object

DeviceNet		Message Router Object 0x02					
<b>Required Object Implementation</b>	<b>Object Class</b>		<b>ID</b>	<b>Description</b>	<b>Get</b>	<b>Set</b>	<b>Value Limits</b>
	Attributes	Open	1	Revision	<input type="checkbox"/>	<input type="checkbox"/>	___
			4	Optional attribute list	<input type="checkbox"/>	<input type="checkbox"/>	___
			5	Optional service list	<input type="checkbox"/>	<input type="checkbox"/>	___
			6	Max ID of class attributes	<input type="checkbox"/>	<input type="checkbox"/>	___
			7	Max ID of instance attributes	<input type="checkbox"/>	<input type="checkbox"/>	___
			<b>DeviceNet Services</b>		<b>Parameter Options</b>		
	Services		<input type="checkbox"/>	Get_Attribute_All	___		
			<input type="checkbox"/>	Get_Attribute_Single	___		
			None Supported				
	<b>Object Instance</b>		<b>ID</b>	<b>Description</b>	<b>Get</b>	<b>Set</b>	<b>Value Limits</b>
	Attributes	Open	1	Object list	<input type="checkbox"/>	<input type="checkbox"/>	___
			2	Maximum connections supported	<input type="checkbox"/>	<input type="checkbox"/>	___
			3	Number of active connections	<input type="checkbox"/>	<input type="checkbox"/>	___
			4	Active connections list	<input type="checkbox"/>	<input type="checkbox"/>	___
			<b>DeviceNet Services</b>		<b>Parameter Options</b>		
Services		<input type="checkbox"/>	Get_Attribute_All	___			
		<input type="checkbox"/>	Get_Attribute_Single	___			
		None Supported					
	Vendor Specific Additions		If yes, fill out the Vendor Specific Additions form on page F- 7.		Yes	<input type="checkbox"/>	
					No	<input checked="" type="checkbox"/>	

## DeviceNet Object

DeviceNet		DeviceNet Object 0x03					
Required	Object Class		ID	Description	Get	Set	Value Limits
Object Implementation	Attributes	Open	1	Revision	<input type="checkbox"/>	<input type="checkbox"/>	—
	None Supported						
			DeviceNet Services		Parameter Options		
	Services		<input type="checkbox"/>	Get_Attribute_Single	—		
	None Supported						
Object Instance			ID	Description	Get	Set	Value Limits
Attributes		Open	1	MAC ID	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 to 63
			2	Baud rate	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0 to 2
	<input type="checkbox"/> None Supported		3	BOI	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—
			4	Bus-off counter	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
			5	Allocation information	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—
			6	MAC ID switch changed	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—
			7	Baud rate switch changed	<input type="checkbox"/>	<input type="checkbox"/>	—
			8	MAC ID switch value	<input type="checkbox"/>	<input type="checkbox"/>	—
			9	Baud rate switch value	<input type="checkbox"/>	<input type="checkbox"/>	—
			DeviceNet Services		Parameter Options		
	Services		<input checked="" type="checkbox"/>	Get_Attribute_Single	—		
			<input checked="" type="checkbox"/>	Set_Attribute_Single	—		
	<input type="checkbox"/> None Supported		<input checked="" type="checkbox"/>	Allocate M/S connection set	—		
			<input checked="" type="checkbox"/>	Release M/S connection set	—		
Vendor Specific Additions			If yes, fill out the Vendor Specific Additions form on page F- 7.		Yes	<input type="checkbox"/>	
					No	<input checked="" type="checkbox"/>	

## Connection Object - Explicit Message

DeviceNet		Connection Object 0x05					
Required	Object Class	ID	Description	Get	Set	Value Limits	
Object	Attributes	Open	1	Revision	<input type="checkbox"/>	<input type="checkbox"/>	—
Implementation	None Supported						
		DeviceNet Services		Parameter Options			
Services	<input type="checkbox"/>		Reset	—			
	<input type="checkbox"/>		Create	—			
	<input type="checkbox"/>		Delete	—			
	<input type="checkbox"/>		Get_Attribute_Single	—			
	<input type="checkbox"/>		Find_Next_Object_Instance	—			
Total Active Connections Possible		<b>3</b>					

Object Instance 1	Section	Information	Max Instance
<i>The Object Instance section must be completed for each combination of Instance type, Production trigger, Transport type, and Transport class supported</i>	Instance type	Explicit Message	<u>1</u>
		Polled I/O	<input type="checkbox"/>
		Bit Strobed I/O	<input type="checkbox"/>
		Dynamic I/O	<input type="checkbox"/>
	Production trigger	Cyclic	<input type="checkbox"/>
		Change of State	<input type="checkbox"/>
		Application Triggered	<input type="checkbox"/>
	Transport type	Server	<input type="checkbox"/>
		Client	<input type="checkbox"/>
	Transport class	0	<input type="checkbox"/>
	2	<input type="checkbox"/>	
	3	<input type="checkbox"/>	

Attributes	Open	ID	Description	Get	Set	Value Limits
		1	State		<input type="checkbox"/>	—
		2	Instance type		<input type="checkbox"/>	—
		3	Transport class trigger		<input type="checkbox"/>	—
		4	Produced connection ID		<input type="checkbox"/>	—
		5	Consumed connection ID		<input type="checkbox"/>	—
		6	Initial comm. characteristics		<input type="checkbox"/>	—
		7	Produced connection size		<input type="checkbox"/>	—
		8	Consumed connection size		<input type="checkbox"/>	—
		9	Expected packet rate			—
		12	Watchdog time-out action		<input type="checkbox"/>	—
		13	Produced connection path length		<input type="checkbox"/>	—
		14	Produced connection path		<input type="checkbox"/>	—
		15	Consumed connection path length		<input type="checkbox"/>	—
		16	Consumed connection path		<input type="checkbox"/>	—

	DeviceNet Services	Parameter Options
Services	<input checked="" type="checkbox"/> Reset	---
	<input type="checkbox"/> Delete	---
	<input type="checkbox"/> Apply_Attributes	---
	<input checked="" type="checkbox"/> Get_Attribute_Single	---
	<input checked="" type="checkbox"/> Set_Attribute_Single	---
Vendor Specific Additions	If yes, fill out the Vendor Specific Additions form on page F- 7.	Yes <input type="checkbox"/> No <input checked="" type="checkbox"/>

## Connection Object - Polled I/O

Connection Object 0x05 (Continued)								
Object Instance 2	Section	Information			Max Instance			
<i>The Object Instance section must be completed for each combination of Instance type, Production trigger, Transport type, and Transport class supported</i>	Instance type	Explicit Message	<input type="checkbox"/>		<u>1</u>			
		Polled I/O	<input checked="" type="checkbox"/>					
		Bit Strobed I/O	<input type="checkbox"/>					
		Dynamic I/O	<input type="checkbox"/>					
	Production trigger	Cyclic		<input type="checkbox"/>				
		Change of State		<input type="checkbox"/>				
		Application Triggered		<input type="checkbox"/>				
	Transport type	Server		<input type="checkbox"/>				
		Client		<input type="checkbox"/>				
	Transport class	0		<input type="checkbox"/>				
2			<input type="checkbox"/>					
3			<input type="checkbox"/>					
Attributes	Open	<b>ID</b>	<b>Description</b>	<b>Get</b>	<b>Set</b>	<b>Value Limits</b>		
		1	State	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		2	Instance type	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		3	Transport class trigger	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		4	Produced connection ID	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		5	Consumed connection ID	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		6	Initial comm. characteristics	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		7	Produced connection size	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		8	Consumed connection size	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		9	Expected packet rate	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	—		
		12	Watchdog time-out action	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		13	Produced connection path length	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		14	Produced connection path	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		15	Consumed connection path length	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		16	Consumed connection path	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		Services	<b>DeviceNet Services</b>		<b>Parameter Options</b>			
			<input checked="" type="checkbox"/>	Reset	—			
<input type="checkbox"/>	Delete		—					
<input type="checkbox"/>	Apply_Attributes		—					
<input checked="" type="checkbox"/>	Get_Attribute_Single		—					
Vendor Specific Additions	If yes, fill out the Vendor Specific Additions form on page F- 7.		Yes	<input type="checkbox"/>				
			No	<input checked="" type="checkbox"/>				

## Connection Object - Bit Strobed I/O

Connection Object 0x05 (Continued)								
Object Instance 3	Section	Information			Max Instance			
<i>The Object Instance section must be completed for each combination of Instance type, Production trigger, Transport type, and Transport class supported</i>	Instance type	Explicit Message	<input type="checkbox"/>		<u>1</u>			
		Polled I/O	<input type="checkbox"/>					
		Bit Strobed I/O	<input checked="" type="checkbox"/>					
		Dynamic I/O	<input type="checkbox"/>					
	Production trigger	Cyclic		<input type="checkbox"/>				
		Change of State		<input type="checkbox"/>				
		Application Triggered		<input type="checkbox"/>				
	Transport type	Server		<input type="checkbox"/>				
		Client		<input type="checkbox"/>				
	Transport class	0		<input type="checkbox"/>				
2			<input type="checkbox"/>					
3			<input type="checkbox"/>					
Attributes	Open	<b>ID</b>	<b>Description</b>	<b>Get</b>	<b>Set</b>	<b>Value Limits</b>		
		1	State	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		2	Instance type	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		3	Transport class trigger	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		4	Produced connection ID	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		5	Consumed connection ID	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		6	Initial comm. characteristics	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		7	Produced connection size	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		8	Consumed connection size	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		9	Expected packet rate	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	—		
		12	Watchdog time-out action	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		13	Produced connection path length	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		14	Produced connection path	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		15	Consumed connection path length	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		16	Consumed connection path	<input checked="" type="checkbox"/>	<input type="checkbox"/>	—		
		Services	<b>DeviceNet Services</b>		<b>Parameter Options</b>			
			<input checked="" type="checkbox"/>	Reset	—			
<input type="checkbox"/>	Delete		—					
<input type="checkbox"/>	Apply_Attributes		—					
<input checked="" type="checkbox"/>	Get_Attribute_Single		—					
	<input checked="" type="checkbox"/>	Set_Attribute_Single	—					
Vendor Specific Additions	If yes, fill out the Vendor Specific Additions form on page F- 7.		Yes	<input type="checkbox"/>				
			No	<input checked="" type="checkbox"/>				

# Assembly Object

DeviceNet	OBJECT NAME <u>Assembly Object</u>		OBJECT ID <u>0x04</u>				
<b>Open</b>	<b>Object Class</b>	<b>ID</b>	<b>Description</b>	<b>Get</b>	<b>Set</b>	<b>Value Limits</b>	
<b>Object</b>	Attributes	Open	1 Revision	<input type="checkbox"/>	<input type="checkbox"/>	1	
<b>Implementation</b>	<input checked="" type="checkbox"/> None Supported		2 Max instance	<input type="checkbox"/>	<input type="checkbox"/>	—	
			<b>DeviceNet Services</b>	<b>Parameter Options</b>			
Services			<input type="checkbox"/> Create	—			
<input checked="" type="checkbox"/> None Supported			<input type="checkbox"/> Delete	—			
			<input checked="" type="checkbox"/> Get_Attribute_Single	—			
<b>Object Instance</b>			<b>Section</b>	<b>Information</b>	<b>Max Instance</b>		
<i>The Object Instance section must be completed for each combination of Instance type.</i>			Instance type	Static Input	<input type="checkbox"/>		
<input type="checkbox"/> None Supported				Static Output	<input type="checkbox"/>		
				Static I/O	<input checked="" type="checkbox"/>		
				Static Configuration	<input type="checkbox"/>		
			<b>ID</b>	<b>Description</b>	<b>Get</b>	<b>Set</b>	<b>Value Limits</b>
Attributes			Open	1 Number of members in list	<input type="checkbox"/>	<input type="checkbox"/>	—
<input type="checkbox"/> None Supported				2 Member list	<input type="checkbox"/>	<input type="checkbox"/>	—
				3 Data	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	—
			<b>DeviceNet Services</b>	<b>Parameter Options</b>			
Services			<input type="checkbox"/> Delete	—			
<input type="checkbox"/> None Supported			<input checked="" type="checkbox"/> Get_Attribute_Single	—			
			<input checked="" type="checkbox"/> Set_Attribute_Single	—			
			<input type="checkbox"/> Add_Member	—			
			<input type="checkbox"/> Delete_Member	—			
<b>Vendor Specific Additions</b>			If yes, fill out the Vendor Specific Additions form on page F- 7.	Yes	<input type="checkbox"/>		
				No	<input checked="" type="checkbox"/>		