

IB-19B003

DELTA SERIES

JUNE 2003

DELTA MAX



INSTRUCTION BOOK

INDUSTRIAL INDEXING SYSTEMS, Inc.

Revision - D
Approved By:

Proprietary information of Industrial Indexing Systems, Inc. furnished for customer use only.
No other uses are authorized without the prior written permission of
Industrial Indexing Systems, Inc.

TABLE OF CONTENTS

List of Illustrationvii

Introduction ix

SECTION 1 - OVERVIEW

1.1	Identifying DeltaMax Packages	1 - 1
1.2	Identifying DeltaMax Drives	1 - 2
1.3	Identifying DeltaMax Motors	1 - 3

SECTION 2 - DESCRIPTION

2.1	Components	2 - 2
2.1.1	Status Indicators	2 - 2
2.1.2	Connectors	2 - 2

SECTION 3 - DELTAMAX SPECIFICATIONS

3.1	Motor Output	3 - 1
3.2	Power Supply	3 - 2
3.3	Control Performance	3 - 3
3.4	Environment	3 - 3
3.5	Digital I/O Signals	3 - 4
3.6	Analog I/O Signals	3 - 5
3.7	Communication Ports	3 - 5
3.8	Protection	3 - 5
3.9	Motor Specifications	3 - 6
3.9.1	General	3 - 6
3.9.2	Feedback Device	3 - 6
3.9.3	Other	3 - 6

SECTION 4 - THE DELTA DRIVE MENU

4.1	Navigating the Driver's Menu.....	4 - 2
4.1.1	Status Display Menu Loop	4 - 4
4.1.2	Diagnostic Display Menu Loop	4 - 6
4.1.3	Adjustment Parameter Menu Loop.....	4 - 8
4.1.4	User Parameter Menu Loop.....	4 - 8

SECTION 5 - DELTAMAX WIRING

5.1	Digital I/O.....	5 - 1
5.2	Analog I/O.....	5 - 2
5.3	Port 1 & Port 2.....	5 - 2
5.4	DeviceNet/CAN Bus (optional).....	5 - 3
5.5	Monitor Output.....	5 - 3
5.6	Feedback Interface	5 - 4
5.7	Absolute Resolver/Encoder Interface.....	5 - 5
5.8	Absolute Encoder Interface	5 - 6

SECTION 6 - OPERATION

6.1	Firmware Downloading.....	6 - 1
6.2	Control Program.....	6 - 1
6.3	Drive Parameters	6 - 2

SECTION 7 - POWER WIRING

7.1	Circuit Breaker.....	7 - 1
7.2	Contactors.....	7 - 1
7.3	Wire Sizes	7 - 1
7.4	Transformers	7 - 2
7.5	Branch Circuit Protection for Control Voltage R0, S0	7 - 3
7.6	Wiring Practices and Grounding.....	7 - 4
7.7	Power Sequencing.....	7 - 5

SECTION 8 - DRIVE TUNING

8.1	Tuning Procedure	8 - 2
8.2	Notch Filter Adjustment.....	8 - 2

SECTION 9 - REGEN RESISTOR SELECTION

9.1	DeltaMax Driver Regeneration Capacities	9 - 1
9.2	Selection of Regeneration Resistor	9 - 2
9.3	Standard Regeneration Resistor Packages.....	9 - 6

SECTION 10 - DYNAMIC BRAKES

SECTION 11 - MECHANICAL BRAKES

11.1	No Mechanical Braking	11 - 1
11.2	Mechanical Braking With Soft Deceleration.....	11 - 1
11.3	Mechanical Brake Power Supply.....	11 - 6

SECTION 12 - ALARM & STATUS CODES

12.1	Alarm Codes.....	12 - 1
12.2	Controller Status	12 - 4

APPENDIX A - MOTOR/DRIVER SPECIFICATIONS

A.1	Motors with Resolvers.....	A - 1
A.2	Motors with Mechanical Brakes.....	A - 3
A.3	Motors with Encoders	A - 4
A.4	Motor/Driver Speed Torque Curves	A - 5
A.5	Driver Mounting and Dimensions	A - 98
A.6	Resolver Motor Dimensions	A - 123
A.7	Brake Motor Dimensions	A - 174
A.8	Encoder Motor Dimensions	A - 199

APPENDIX B - CABLES AND ACCESSORIES

B.1 Cable Part Numbers For Motors with Resolvers B - 1

B.2 Cable Part Numbers For Motors with Mechanical Brakes..... B - 3

B.3 Cable Part Numbers For Motors with Encoders B - 4

B.4 Accessories B - 5

APPENDIX C - ABSOLUTE DELTAMAX MOTOR AND DRIVE APPLICATION NOTE

LIST OF ILLUSTRATIONS

SECTION 1 - OVERVIEW

SECTION 2 - DESCRIPTION

Figure 2.1	DeltaMax Layout.....	2 - 1
------------	----------------------	-------

SECTION 3 - DRIVER SPECIFICATIONS

Figure 3.1	Standard	3 - 4
Figure 3.2	Optional.....	3 - 4
Figure 3.3	DeltaMax Overload Protection Characteristic	3 - 7
Figure 3.4	Standard Resolver Wiring Connections for DBM-XXX/15R, DBM-500/30R and Larger	3 - 8
Figure 3.5	Alternate Resolver Wiring Connections for DBM-XXX/15R, DBM-500/30R and Larger	3 - 8
Figure 3.6	Standard Resolver Wiring Connections for DBM-120/30R, DBM-200/30R, DBM-400/30R, DBM-BXXX/30R, DBM-D30/30R and DBM-D50/30R.....	3 - 9
Figure 3.7	Alternate Resolver Wiring Connections for DBM-120/30R, DBM-200/30R and DBM-400/30R.....	3 - 9
Figure 3.8	Standard Resolver Wiring Connections for DBM-D100/30R Through DBM-D800/30R	3 - 10

SECTION 4 - THE DELTA DRIVE MENU

Figure 4.1	DeltaMax Keypad and Display.....	4 - 1
Figure 4.2	Main Menu Loop and Minor Loops	4 - 3

SECTION 5 - DELTAMAX WIRING

Figure 5.1	Digital I/O	5 - 1
Figure 5.2	Input & Output Configurations.....	5 - 1
Figure 5.3	Analog I/O	5 - 2
Figure 5.4	Port 1 & Port 2	5 - 2
Figure 5.5	DeviceNet/CAN Bus	5 - 3
Figure 5.6	Monitor Output.....	5 - 3
Figure 5.7	Feedback Interface.....	5 - 4
Figure 5.8	Battery Pack and Resolver/Encoder Wiring	5 - 5
Figure 5.9	Battery Pack and Encoder Wiring.....	5 - 6

SECTION 6 - OPERATION

SECTION 7 - POWER WIRING

Figure 7.1	Grounding Technique.....	7 - 4
Figure 7.2	DMAX-1.5/RB Through DMAX-8.5/RB Power Wiring.....	7 - 5
Figure 7.3	DMAX-1.5/RA Through DMAX-17.5/RA Power Wiring.....	7 - 6
Figure 7.4	DMAX-35/RA Through DMAX-115/RA Power Wiring.....	7 - 7

SECTION 8 - DRIVE TUNING

Table 8.1	Adjustment Parameters.....	8 - 1
-----------	----------------------------	-------

SECTION 9 - REGEN RESISTOR SELECTION

Figure 9.1	Time	9 - 2
Figure 9.2	Connection of an External Regen Resistor for DeltaMax Driver Sizes DMAX-1.5 Through DMAX-17.5	9 - 3
Figure 9.3	Connection of an External Regen Resistor for DeltaMax Driver Sizes DMAX-35 and Larger	9 - 4
Table 9.1	Energy Absorption Capabilities.....	9 - 1
Table 9.2	External Resistor Specifications	9 - 3

SECTION 10 - DYNAMIC BRAKES

Figure 10.1	Dynamic Brake Connection for the DMAX-1.5 Through DMAX-17.5 Drivers	10 - 1
Figure 10.2	Dynamic Brake Connection for the DMAX-35 Through DMAX-115 Drivers	10 - 2
Figure 10.3	Dynamic Braking Control Signals	10 - 3

SECTION 11 - MECHANICAL BRAKES

Figure 11.1	Mechanical Brake Connection for the DMAX-1.5 Through DMAX-17.5 Drivers with a Sourcing I/O Board.....	11 - 2
Figure 11.2	Mechanical Brake Connection for the DMAX-35 Through DMAX-115 Drivers..	11 - 3
Figure 11.3	Mechanical Brake Sequencing for Soft Decel.....	11 - 4

SECTION 12 - ALARM & STATUS CODES

Figure 12.1	Controller Status.....	12 - 4
-------------	------------------------	--------

APPENDIX A - MOTOR/DRIVER SPECIFICATIONS

APPENDIX B - CABLES AND ACCESSORIES

APPENDIX C - ABSOLUTE DELTAMAX MOTOR AND DRIVE APPLICATION NOTE